Q Series QnU CPU Ethernet Driver

1	System Configuration	
2	External Devices Selection	7
3	Communication Settings	8
4	Setup Items	14
5	Supported Devices	
6	Device Code and Address Code	26
7	Error Messages	

Introduction

This manual describes how to connect the Display and the External Device (target PLC).

In this manual, the connection procedure is described in the sections identified below:



1 System Configuration

The following table lists system configurations for connecting Mitsubishi Electric Corp. External Devices and the Display.

Series	CPU	Link I/F	SIO Type	Setting Example
	Q03UDECPU Q04UDEHCPU Q06UDEHCPU	Ethernet connector on the CPU unit	Ethernet (UDP)	Setting Example 1 (page 8)
	Q13UDEHCPU Q20UDEHCPU Q26UDEHCPU		Ethernet (TCP)	Setting Example 2 (page 11)
	Q03UDCPU Q04UDHCPU Q06UDHCPU	PU Ethernet connector on PU Universal Model built-in PU Ethernet port QCPU ^{*1} PU Ethernet connector on Universal Model built-in	Ethernet (UDP)	Setting Example 1 (page 8)
MELSEC-Q	Q13UDHCPU Q20UDHCPU Q26UDHCPU		Ethernet (TCP)	Setting Example 2 (page 11)
Series	Q02CPU Q02HCPU Q06HCPU		Ethernet (UDP)	Setting Example 1 (page 8)
	Q12HCPU Q25HCPU	Ethernet port QCPU ^{*2}	Ethernet (TCP)	Setting Example 2 (page 11)
	Q172DCPU	Ethernet connector on	Ethernet (UDP)	Setting Example 1 (page 8)
	Q173DCPU	Ethernet port QCPU ^{*3}	Ethernet (TCP)	Setting Example 2 (page 11)

- *1 Since the Universal Model QCPU (Q03UDCPU, Q04UDHCPU, Q06UDHCPU, Q10UDHCPU, Q13UDHCPU, Q20UDHCPU, Q26UDHCPU) cannot be directly connected to the Display, use it with a Multi CPU System.
- *2 Since the High Performance model QCPU (Q02CPU, Q02HCPU, Q06HCPU, Q12HCPU, Q25HCPU) cannot be directly connected to the Display, use it with a Multi CPU System.
- *3 Since the motion CPU (Q172DCPU, Q173DCPU) cannot be directly connected to the Display, use it with a Multi CPU System.

Connection Configuration

NOTE

• Use Straight cables for Ethernet cables.

Crossing cables can also be used for connecting the External Device with the Display directly using an Ethernet cable.

• 1:1 Connection

<HUB Connection>



<Direct Connection>



• 1:n Connection



Maximum 32 units for UDP/IP Maximum 16 units for TCP/IP n:1 Connection



Maximum 16 units

n:m Connection



Maximum 32 units for UDP/IP Maximum 16 units connect to one Display for TCP/IP

• Multi-CPU System



NOTE

- For the CPU unit numbers, the number "1" is assigned to the CPU slot, and any subsequent units are aligned to the right and assigned "2", "3", "4", in order.
- The multi-CPU system enables you to access a CPU that is not directly connected. For External Devices that can be used in a multi-CPU system, refer to the External Device manual.

2 External Devices Selection

Select the External Device to be connected to the Display.

💰 New Project File					×
G2-2co	Device/PLI	с			
	Maker	Mitsubishi Electric Co	rporation	•	
	Series	Q Series QnU CPU E	thernet	•	
	🗖 Use S	ystem Area		Refer to the manual of this Device/PLC	
	Connection	Method			
	Port	Ethernet (UDP)	•		
				Go to Device/PLC Manua	
Back	<u>B)</u> Con	nmunication Settings	New Log	ic New Screen Cancel	1

Setup Items	Setup Description		
Maker	Select the maker of the External Device to be connected. Select "Mitsubishi Electric Corporation".		
Series	Select a model (series) of the External Device to be connected and connection method. Select "Q Series QnU CPU Ethernet". In System configuration, check to make sure the external device to which you are connecting is supported in "Q Series QnU CPU Ethernet".		
	Check this option to synchronize the system data area of the Display and the device (memory) of the External Device. When they are synchronized, you can use the ladder program of the External Device to switch the display or to display a window on the Display.		
Use System Area	Cf. GP-Pro EX Reference Manual "Appendix 1.4 LS Area (Direct Access Method)"		
	This can also be set in GP-Pro EX or in the Display's off-line mode.		
	Cf. GP-Pro EX Reference Manual "5.17.6 [System Settings] Setting Guide, [Display Unit] Settings Guide, System Area Settings"		
	Cf. Maintenance/Troubleshooting Manual "2.15.1 Settings common to all Display models, [Main Unit Settings] Settings Guide, System Area Settings"		
Port	Select the Display port to be connected to the External Device.		

3 Communication Settings

This section provides examples of communication settings recommended by Pro-face for the Display and the External Device.

3.1 Setting Example 1

GP-Pro EX Settings

Communication Settings

To display the setup screen, from the [System Settings] workspace, select [Device/PLC].

Device/PLC 1		
Summary		Change Device/PLC
Maker Mitsubishi Electric Corporation	Series Q Series QnU CPU Ethernet	Port Ethernet (UDP)
Text Data Mode 2 Change		
Communication Settings		
Port No. 1024 💼		
Timeout 3 📑 (sec)		
Retry 2		
Wait To Send 🛛 🚺 🗰 (ms)	Default	
Device-Specific Settings		
Allowable Number of Devices/PLCs 32		
Number Device Name	Settings	
👗 1 PLC1	IP Address=192.168.000.001	

- When directly connecting an External Device (1:1 connection) using the cross cable, you need to set 6 (sec) or more for [Timeout].
 - In the case of "n:1" or "n:m" connection, you need to set 3 (sec) or more for [Timeout] and 2 or more for [Retry].
 - When communication is made from the Display before the initialization processing in the External Device is completed, the communication error occurs to the Display. In this case, adjust the time in [Timeout].

When the motion CPU is used in the multiple CPU system especially, adjust [Timeout] to 10 (sec) or more.

Device Setting

To display the [Individual Device Settings] dialog box, select the external device and click []. [Settings] from [Device-Specific Settings] in the [Device/PLC] window. To connect multiple External Devices, click []. [Device-Specific Settings] in the [Device/PLC] window to add another External Device.

💰 Individual	Device	Settin	gs		×
PLC1					
IP Address	192.	168.	0.	1	
			Def	ault	
	OK (O)		Car	icel	

Notes

- Check with the network administrator about the IP address.
- Be sure not to duplicate IP addresses on the same network.
- Set the IP address of the External Device under [Individual Device Settings].
- You need to set the IP address of the Display in its off-line mode.

External Device Settings

Use the ladder software (GX-Developer Ver.8.68W or later) for the External Device communication settings. Refer to your External Device manual for details.

- 1 Start up the ladder software.
- **2** From the [Project] menu, select [New project] to display the [New Project] dialog box.
- **3** Select the External Device you want to use from [PLC Type], and then click [OK].
- 4 Double-click [PLC Parameter] in the tree view to display the [Q parameter setting] dialog box.
- 5 Select the [Built-in Ethernet port] tab.
- 6 Enter "192.168.0.1" in [IP address].
- 7 Click [Open settings] to display the [Built-in Ethernet port open setting] dialog box.
- 8 Set each item as follows:

Protocol	Open Method
UDP	MELSOFT connection

9 Click [End].

- 10 Click [End] in the [Q parameter setting] dialog box.
- **11** Transfer the communication settings to the External Device.

This completes the External Device setup.

- Notes
 - Check with the network administrator about the IP address.
 - Be sure not to duplicate IP addresses on the same network.

3.2 Setting Example 2

- GP-Pro EX Settings
- Communication Settings

To display the setup screen, from the [System Settings] workspace, select [Device/PLC].

Device/PLC 1
Summary Change Device/PLC
Maker Mitsubishi Electric Corporation Series Q Series QnU CPU Ethernet Port Ethernet (TCP)
Text Data Mode 2 Change
Communication Settings
Port No. 1024 🗾 🔽 Auto
Timeout 3 🕂 (sec)
Retry 0 🛨
Wait To Send 0 🕂 (ms) Default
Device-Specific Settings
Allowable Number of Devices/PLCs 16
Number Device Name Settings
L IP Address=192.168.000.001

- When directly connecting an External Device (1:1 connection) using the cross cable, you need to set 6 (sec) or more for [Timeout].
 - In the case of "n: 1" or "n:m" connection, you need to set 3 (sec) or more for [Timeout].
 - When communication is made from the Display before the initialization processing in the External Device is completed, the communication error occurs to the Display. In this case, adjust the time in [Timeout].
 When the motion CPU is used in the multiple CPU system especially, adjust [Timeout] to 10 (sec) or more.

Device Setting

To display the [Individual Device Settings] dialog box, select the external device and click []. [Settings] from [Device-Specific Settings] in the [Device/PLC] window. To connect multiple External Devices, click []. [Device-Specific Settings] in the [Device/PLC] window to add another External Device.

💰 Individual	Device	Settin	gs		×
PLC1					
IP Address	192.	168.	0.	1	
			Def	ault	
	OK (O)		Can	icel	

Notes

- Check with the network administrator about the IP address.
- Be sure not to duplicate IP addresses on the same network.
- Set the IP address of the External Device under [Individual Device Settings].
- You need to set the IP address of the Display in its off-line mode.

External Device Settings

Use the ladder software (GX-Developer Ver.8.68W or later) for the External Device communication settings. Refer to your External Device manual for details.

- 1 Start up the ladder software.
- **2** From the [Project] menu, select [New project] to display the [New Project] dialog box.
- **3** Select the External Device you want to use from [PLC Type], and then click [OK].
- 4 Double-click [PLC Parameter] in the tree view to display the [Q parameter setting] dialog box.
- 5 Select the [Built-in Ethernet port] tab.
- 6 Enter "192.168.0.1" in [IP address].
- 7 Click [Open settings] to display the [Built-in Ethernet port open setting] dialog box.
- 8 Set each item as follows:

Protocol	Open Method
TCP	MELSOFT connection

9 Click [End].

- 10 Click [End] in the [Q parameter setting] dialog box.
- **11** Transfer the communication settings to the External Device.

This completes the External Device setup.

- Notes
 - Check with the network administrator about the IP address.
 - Be sure not to duplicate IP addresses on the same network.

4 Setup Items

Set up the Display's communication settings in GP Pro-EX or in the Display's off-line mode.

The setting of each parameter must match that of the External Device.

"3 Communication Settings" (page 8)

• You need to set the IP address of the Display in its off-line mode. NOTE Cf. Maintenance/Troubleshooting Manual "2.5 Ethernet Settings"

4.1 Setup Items in GP-Pro EX

Communication Settings

To display the setup screen, from the [System Settings] workspace, select [Device/PLC].

Device/PLC 1
Summary Change Device/PLC
Maker Mitsubishi Electric Corporation Series Q Series QnU CPU Ethernet Port Ethernet (TCP)
Text Data Mode 2 Change
Communication Settings
Port No. 1024 🗾 🔽 Auto
Timeout 3 (sec)
Retry 0 🔹
Wait To Send 0 🔆 (ms) Default
Device-Specific Settings
Allowable Number of Devices/PLCs 16
Number Device Name Settings Number Device Name Settings 1 PLC1 III III Address=192.168.000.001

Setup Items	Setup Description
	Use an integer from 1024 to 65534 to enter the port No. of the Display. If you check [Auto], the port No. is automatically set.
Port No.	 NOTE The [Auto] option can be set only when you select "Ethernet (TCP)" under [Connecting Method].
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.
Wait To Send	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands.

Device Setting

To display the [Individual Device Settings] dialog box, select the external device and click [[6] [Settings] from [Device-Specific Settings] in the [Device/PLC] window. To connect multiple External Devices, click [16] from [Device-Specific Settings] in the [Device/PLC] window to add another External Device.

💣 Individual Device Settings					
PLC1					
IP Address	192.	168.	0.	1	
			Def	ault	
	OK (O)		Car	icel	

Setup Items	Setup Description				
IP Address	Set the IP address of the External Device. NOTE				
	Check with the network administrator about the IP address.Be sure not to duplicate IP addresses on the same network.				

4.2 Setup Items in Off-line Mode

NOTE

• Refer to the Maintenance/Troubleshooting manual for information on how to enter off-line mode or about the operation.

Cf. Maintenance/Troubleshooting Manual "2.2 Off-line Mode"

Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Equipment Settings] in off-line mode. Touch the External Device you want to set from the displayed list.

Comm.	Device			
Q Series QnU CF	V Ethernet		[UDP]	Page 1/1
	Port No.	🔿 Fixed	• Auto	
			1024 💌 🔺	·]
	Timeout(s) Retry		3 ▼ ▲ 2 ▼ ▲	
	Wait To Send(ms)		0 🔻 🔺	
	1			
	Exit		Back	2008/07/03 11:48:43

Setup Items	Setup Description				
Port No.	Set the Port No. of the Display. With the UDP connection, the entered port No. is assigned regardless of whether you select [Fixed] or [Auto]. With the TCP connection, select either [Fixed] or [Auto]. If you select [Fixed], use an integer from 1024 to 65534 to enter the port No. of the Display. If you select [Auto], the port No. is automatically assigned regardless of the entered value.				
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the Display waits for the response from the External Device.				
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.				
Wait To Send	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands.				

Device Setting

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Equipment Settings]. Touch the External Device you want to set from the displayed list, and touch [Device].

Comm.	Device						
Q Series QnU CP	U Ethernet					[UDP]	Page 1/1
Devic	e/PLC Name	PLC1		_	_		
IP Ad	dress	192	168	0	1	1	
	Exit					Back	2008/07/03 11:48:50

Setup Items	Setup Description
Device/PLC Name	Select the External Device to set. Device/PLC name is the title of the External Device set with GP-Pro EX. (Initial value [PLC1])
IP Address	 Set the IP address of the External Device. NOTE Check with the network administrator about the IP address. Be sure not to duplicate IP addresses on the same network.

5 Supported Devices

The following table shows the range of supported device addresses. Please note that the actual supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your External Device.

Enter the External Device address in the dialog box below.



- 1. Unit number Use an integer from 1 to 4 to enter the unit number of the CPU with which to communicate. To access a CPU that is directly connected, as in a single CPU system, select "0".
- 2. Device Select a device.
- 3. Address Set the address.

5.1 Q03UDCPU / Q03UDECPU / Q04UDHCPU / Q04UDEHCPU / 06UDHCPU / 06UDEHCPU / Q10UDHCPU / Q10UDEHCPU / Q13UDHCPU / Q13UDEHCPU / Q20UDHCPU / Q20UDEHCPU / Q26UDHCPU/ Q26UDEHCPU

Device	Bit Address	Word Address	32 bits	Remarks
Input Relay	X0000-X1FFF	X0000-X1FF0		*** 0
Output Relay	Y0000-Y1FFF	Y0000-Y1FF0		*** 0
Internal Roley	M00000-M32767	M00000-M32752		÷16) *1
Internal Relay	M00000-M61439 M00000-M61424			÷16) *2
Special Relay	SM0000-SM2047	SM0000-SM2032		÷ 16)
Latch Relay	L00000-L32767	L00000-L32752		÷16)
Annunciator	F00000-F32767	F00000-F32752		÷ 16)
Edge Relay	V00000-V32767	V00000-V32752		÷16)
Step Relay	S0000-S8191	S0000-S8176		÷16)
Link Balay	B0000-B7FFF	B0000-B7FF0	-	*** () *1
LINK Relay	B0000-BEFFF	B0000-BEFF0		*** () *2
Special Link Relay	SB0000-SB7FFF	SB0000-SB7FFF SB0000-SB7FF0		***0
	TS00000-TS25023			*1
Timer (Contact)	TS00000-TS25471		[L/H]	*2
Timer (Ceil)	TC00000-TC25023			*1
	TC00000-TC25471			*2
Detentive Timer (Contact)	SS00000-SS25023			*1
Relentive Timer (Contact)	SS00000-SS25471			*2
	SC00000-SC25023			*1
Retentive Timer (Coll)	SC00000-SC25471			*2
Countor (Contact)	CS00000-CS25023			*1
Counter (Contact)	CS00000-CS25471	CS00000-CS25471		*2
Counter (Coil)	CC00000-CC25023			*1
Counter (Coll)	CC00000-CC25471	·CC25471		*2
		TN00000-TN25023		*1
Timer (Current Value)		TN00000-TN25471		*2

: This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Remarks
Retentive Timer (Current		SN00000-SN25023		*1
Value)		SN00000-SN25471		*2
Counter (Current Value)		CN00000-CN25023		*1
Counter (Current value)		CN00000-CN25471	ļ	*2
Data Register		D0000000-D4212223		B i t F) *3
Special Register		SD0000-SD2047	ſ	_{вit} F
Link Register		W000000-W4047FF		Bit
Special Link Register		SW0000-SW6DFF		_{віt} F) *1
		SW0000-SW6FFF		Bit F] *2
File Register (Normal)		R00000-R32767		Bit F
File Register (Serial)		ZR000000- ZR4184063		Bit
		0R00000-0R32767	[L/H]	Bit
		1R00000-1R32767		Bit
File Register		2R00000-2R32767		Bit
(0R to 31R) ^{*4}	:	:		:
		30R00000-30R32767	-	Bit
		31R00000-31R32767		Bit
Common device for Multiple CPU ^{*5}		U3E0-10000- U3E0-24335		_{вit} F
		U3E1-10000- U3E1-24335		вit
		U3E2-10000- U3E2-24335		_{вit} F
		U3E3-10000- U3E3-24335		_{вit} F

*1 For the universal model QCPU with a serial number whose first 5 digits is less than "10042".

*2 For the universal model QCPU with a serial number whose first 5 digits is "10042" or more.

*3 You can set the multi-CPU system in the system data area as well.

*4 Set the block number at the beginning of the device name. This is a device notation compatible with GP-Pro/PBIII for Windows. When you specify a new device, we recommend using the file register (serial).

*5 For the Multi CPU System configuration, the available points should be as follows:

2 CPUs: 14k points or less

3 CPUs: 13k points or less

4 CPUs: 12k points or less



5.2 Q02CPU / Q02HCPU / Q06HCPU / Q12HCPU / Q25HCPU

: This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Remarks
Input Relay	X0000-X1FFF	X0000-X1FF0		*** 0
Output Relay	Y0000-Y1FFF	Y0000-Y1FF0		*** 0
Internal Relay	M00000-M32767	M00000-M32767 M00000-M32752		÷16)
Special Relay	SM0000-SM2047	SM0000-SM2032		÷16)
Latch Relay	L00000-L32767	L00000-L32752		÷16)
Annunciator	F00000-F32767	F00000-F32752		÷16)
Edge Relay	V00000-V32767	V00000-V32752		÷16)
Step Relay	S0000-S8191	S0000-S8176		÷16)
Link Relay	B0000-B7FFF	B0000-B7FF0		*** 0
Special Link Relay	SB000-SB7FF	SB000-SB7F0		*** 0
Timer (Contact)	TS00000-TS23087			
Timer (Coil)	TC00000-TC23087			
Retentive Timer (Contact)	SS00000-SS23087		1	
Retentive Timer (Coil)	SC00000-SC23087			
Counter (Contact)	CS00000-CS23087	CS00000-CS23087		
Counter (Coil)	CC00000-CC23087	0-CC23087		
Timer (Current Value)		TN00000-TN23087		
Retentive Timer (Current Value)		SN00000-SN23087		
Counter (Current Value)		CN00000-CN23087		
Data Register		D00000-D25983		_{віt} F) *1
Special Register		SD0000-SD2047		Bit F
Link Register		W0000-W657F		Bit F
Special Link Register		SW000-SW7FF		Bit F
File Register (Normal)		R00000-R32767		Bit F
File Register (Serial)		ZR0000000- ZR1042431		Bit

Device	Bit Address	Word Address	32 bits	Remarks
File Register (0R to 31R) ^{*2}				Bit
				Bit
		2R00000-2R32767		Bit F
	:	:	[L / H]	:
				Bit F
		31R00000-31R26623		вit F

*1 You can set the multi-CPU system in the system data area as well.

*2 Set the block number at the beginning of the device name. This is a device notation compatible with GP-Pro/PBIII for Windows. When you specify a new device, we recommend using the file register (serial).

NOTE

• The address notation varies depending on the unit number you select.

(Example) When "0" is selected for the unit number:



(Example) When "1" is selected for the unit number:



• For system data area, refer to the GP-Pro EX Reference Manual.

Cf. GP-Pro EX Reference Manual "Appendix 1.4 LS Area (Direct Access Method)"

• Refer to the precautions on manual notation for icons in the table.

"Manual Symbols and Terminology"

5.3 Q172DCPU / Q173DCPU

: This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Remarks
Input Relay	X0000-X1FFF	X0000-X1FF0		<u>***</u> 0]
Output Relay	Y0000-Y1FFF	Y0000-Y1FF0		<u>***</u> 0]
Internal Relay	M00000-M08191	M00000-M08176		÷16)
Special Relay	SM0000-SM2255	SM0000-SM2240		÷16)
Annunciator	F00000-F02047	F00000-F02032		÷16)
Link Relay	B0000-B1FFF	B0000-B1FF0		<u>***</u> 0]
Data Register		D0000000-D0008191		Bit F
Special Register		SD0000-SD2255		Bit F
Link Register		W0000-W1FFF	[L/H]	Bit F
		U3E0-10000- U3E0-24335		Bit F
Common device for Multiple CPU ^{*1}		U3E1-10000- U3E1-24335		Bit F
		U3E2-10000- U3E2-24335		Bit F
		U3E3-10000- U3E3-24335		BitF
Motion Register (#) ^{*2}		%MR00000- %MR12287 ^{*3}		_{віt} F)

*1 For the Multi CPU System configuration, the available points should be as follows:
 2 CPUs: 14k points or less
 3 CPUs: 13k points or less

4 CPUs: 12k points or less

*2 No. 2 to No. 4 can be allocated to the motion CPU.

*3 Device name with motion CPU is #.



6 Device Code and Address Code

Use device code and address code when you set "Device Type & Address" for the address type of the data display or other devices.

Device	Device Name	Device Code (HEX)	Address Code
	Х	0080	
	1/X	0180	
Input Relay	2/X	0280	Value of word address divided by 0x10
	3/X	0380	
	4/X	0480	
	Y	0081	
	1/Y	0181	
Output Relay	2/Y	0281	Value of word address divided by 0x10
	3/Y	0381	
	4/Y	0481	
	М	0082	
	1/M	0182	
Internal Relay	2/M	0282	Value of word address divided by 16
	3/M	0382	
	4/M	0482	
	SM	0083	
	1/SM	0183	
Special Relay	2/SM	0283	Value of word address divided by 16
	3/SM	0383	
	4/SM	0483	
	L	0084	
Latch Relay	1/L	0184	
	2/L	0284	Value of word address divided by 16
	3/L	0384	
	4/L	0484	

Device	Device Name	Device Code (HEX)	Address Code
Annunciator	F	0085	
	1/F	0185	
	2/F	0285	Value of word address divided by 16
	3/F	0385	
	4/F	0485	
	V	0086	
	1/V	0186	
Edge Relay	2/V	0286	Value of word address divided by 16
	3/V	0386	
	4/V	0486	
	S	0087	
	1/S	0187	
Step Relay	2/S	0287	Value of word address divided by 16
	3/S	0387	
	4/S	0487	
	В	0088	Value of word address divided by 0x10
	1/B	0188	
Link Relay	2/B	0288	
	3/B	0388	
	4/B	0488	
Special Link Relay	SB	0089	
	1/SB	0189	
	2/SB	0289	Value of word address divided by 0x10
	3/SB	0389	
	4/SB	0489	
	TN	0060	
	1/TN	0160	
Timer (Current Value)	2/TN	0260	Word address
	3/TN	0360	
	4/TN	0460	

Device	Device Name	Device Code (HEX)	Address Code
	SN	0062	
	1/SN	0162	
Retentive Timer (Current Value)	2/SN	0262	Word address
,	3/SN	0362	
	4/SN	0462	
	CN	0061	
	1/CN	0161	
Counter (Current Value)	2/CN	0261	Word address
	3/CN	0361	
	4/CN	0461	
	D	0000	
	1/D	0100	
Data Register	2/D	0200	Word address
	3/D	0300	
	4/D	0400	
	SD	0001	
	1/SD	0101	
Special Register	2/SD	0201	Word address
	3/SD	0301	
	4/SD	0401	
	W	0002	
Link Register	1/W	0102	
	2/W	0202	Word address
	3/W	0302	
	4/W	0402	
	SW	0003	
	1/SW	0103	
Special Link Register	2/SW	0203	Word address
	3/SW	0303	
	4/SW	0403	

Device	Device Name	Device Code (HEX)	Address Code
File Register (Normal)	R	000F	
	1/R	010F	
	2/R	020F	Word address
	3/R	030F	
	4/R	040F	
File Register (Serial)	ZR	000E	
	1/ZR	010E	
	2/ZR	020E	Word address
	3/ZR	030E	
	4/ZR	040E	

Device	Device Name	Device Code (HEX)	Address Code
	OR	0010	
	1/0R	0110	
	2/0R	0210	Word address
	3/0R	0310	
	4/0R	0410	
	1R	0011	
	1/1R	0111	
	2/1R	0211	Word address
	3/1R	0311	
	4/1R	0411	
	2R	0012	
	1/2R	0112	
File Register	2/2R	0212	Word address
(0R to 31R)	3/2R	0312	
	4/2R	0412	
	:	:	:
	30R	002E	
	1/30R	012E	
	2/30R	022E	Word address
	3/30R	032E	
	4/30R	042E	
	31R	002F	
	1/31R	012F	
	2/31R	022F	Word address
	3/31R	032F	
	4/31R	042F	
	2/% MR	0234	
Motion Register (#)	3/% MR	0334	Word address
	4/% MR	0434	

Device	Device Name	Device Code (HEX)	Address Code
	U3E0-	0035	
	1/U3E0-	0135	
	2/U3E0-	0235	
	3/U3E0-	0335	
	4/U3E0-	0435	
	U3E1-	0036	
Common device for Multiple CPU	1/U3E1-	0136	Word address
	2/U3E1-	0236	
	3/U3E1-	0336	
	4/U3E1-	0436	
	U3E2-	0037	
	1/U3E2-	0137	
	2/U3E2-	0237	
	3/U3E2-	0337	
	4/U3E2-	0437	
	U3E3-	0038	
	1/U3E3-	0138	
	2/U3E3-	0238	
	3/U3E3-	0338	
	4/U3E3-	0438	

7 Error Messages

Error messages are displayed on the Display screen as follows: "No. : Device Name: Error Message (Error Occurrence Area)". Each description is shown below.

Item	Description		
No.	Error number		
Device Name	Name of the External Device where an error has occurred. Device/PLC name is the title of the External Device set with GP Pro-EX. (Initial value [PLC1])		
Error Message	Displays messages related to an error that has occurred.		
	Displays the IP address or device address of the External Device where an error has occurred, or error codes received from the External Device.		
Error Occurrence Area	 NOTE IP addresses are displayed as "IP address (Decimal): MAC address (Hex)". Device addresses are displayed as "Address: Device address". Received error codes are displayed as "Decimal [Hex]". 		

Display Examples of Error Messages

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 2[02H])"

• Refer to your External Device manual for details on received error codes.
• Refer to "When an error is displayed (Error Code List)" in "Maintenance/Troubleshooting Manual" for details on the error messages common to the driver.

■ Error Messages Unique to the External Device

Error No.	Error Message	Description
RHxx128	(Node Name): The specified CPU unit could not be accessed (Address: Device Address)	Appears if you access a CPU number that is not assigned.