ODVA

DeviceNet Slave Driver

1	System Configuration	3
2	Selection of External Device	7
3	Example of Communication Setting	8
4	Setup Items	10
5	Supported Device	12
6	Device Code and Address Code	13
7	Error Messages	14

PREFACE

This manual describes how to connect the Display (GP3000 series) and the External Device (target PLC).

In this manual, the connection procedure will be described by following the below sections:

1	System Configuration This section shows the types of External Devices which can be connected and SIO type.	"1 System Configuration" (page 3)
2	Selection of External Device Select a model (series) of the External Device to be connected and connection method.	"2 Selection of External Device" (page 7)
3	Example of Communication Settings This section shows setting examples for communicating between the Display and the External Device.	"3 Example of Communication Setting" (page 8)
4	Setup Items This section describes communication setup items on the Display. Set communication settings of the Display with GP-Pro EX or in off-line mode.	"4 Setup Items" (page 10)
	Operation	

1 System Configuration

The system configuration in the case when the Display and the DeviceNet master are connected is shown.

Maker	Series	CPU	Link I/F	Setting Example	SIO Type
	SLC500	SLC 5/03 SLC 5/04 SLC 5/05	1747-SDN		
	PLC-5	PLC-5/20	1771-SDN		
Rockwell Automation, Inc.	ControlLogix	All CPUs that support the link I/F on the right	1756-DNB		
	MicroLogix	MicroLogix 1500	1769-SDN		
	CompactLogix	All CPUs that support the link I/F on the right	1769-SDN		
OMRON Corporation	SYSMAC α	C200HE-CPU11 C200HE-CPU32 C200HE-CPU32 C200HG-CPU33 C200HG-CPU33 C200HG-CPU33 C200HG-CPU33 C200HX-CPU32 C200HX-CPU34 C200HX-CPU34 C200HX-CPU53 C200HX-CPU54 C200HX-CPU54 C200HE-CPU11-Z C200HE-CPU32-Z C200HE-CPU32-Z C200HG-CPU33-Z C200HG-CPU33-Z C200HG-CPU32-Z C200HG-CPU32-Z C200HG-CPU32-Z C200HG-CPU32-Z C200HX-CPU32-Z C200HX-CPU32-Z C200HX-CPU33-Z C200HX-CPU33-Z C200HX-CPU32-Z C2	C200HW- DRM21-V1	"3.1 Setting Example 1" (page 8)	Device Net

Continue to the next page

Maker	Series	CPU	Link I/F	Setting Example	SIO Type
		CS1G-CPU42 CS1G-CPU43 CS1G-CPU44 CS1G-CPU45 CS1H-CPU63 CS1H-CPU64 CS1H-CPU65 CS1H-CPU66 CS1H-CPU67	CS200HW- DRM21-V1		
OMRON Corporation	SYSMAC CS1	CS1G-CPU42 CS1G-CPU43 CS1G-CPU43 CS1G-CPU45 CS1H-CPU63 CS1H-CPU64 CS1H-CPU65 CS1H-CPU66 CS1H-CPU67 CS1G-CPU42H CS1G-CPU42H CS1G-CPU43H CS1G-CPU45H CS1H-CPU63H CS1H-CPU65H CS1H-CPU66H CS1H-CPU67H	CS1W-DRM21	"3.1 Setting Example 1" (page 8)	Device Net
	CJ1M-CPU11 CJ1M-CPU12 CJ1M-CPU12 CJ1M-CPU13 CJ1M-CPU21 CJ1M-CPU21 CJ1M-CPU23 CJ1M-CPU23 CJ1G-CPU44 CJ1G-CPU45 CJ1G-CPU43H CJ1G-CPU44H CJ1G-CPU45H CJ1H-CPU65H CJ1H-CPU66H	CJ1W-DRM21			
		LQP800 LOP000	LQE070		
Hitachi, Ltd.	S10mini	LQP010 LQP011 LQP120	LQE575		
	S10V	LQP510	LQE575		

Continue to the next page

Maker	Series	CPU	Link I/F	Setting Example	SIO Type
YOKOGAWA Electric Corporation	FA-M3	F3SP20-0N F3SP21-0N F3SP25-2N F3SP28-3N F3SP30-0N F3SP35-5N F3SP38-6N F3SP53-4H F3SP58-6H F3SP36-3N F3SP28-3S F3SP38-6S F3SP53-4S F3SP53-4S F3SP58-6S F3SP59-7S	F3LD01-0N	"3.1 Setting Example 1" (page 8)	Device Net

• To use a DeviceNet slave driver, you need a DeviceNet slave unit (CA6-DNSALL/EX-01) from Digital Electronics Corp. For more information about the cable diagram between the Display (DeviceNet slave unit) and the DeviceNet master and about the DeviceNet slave unit, please refer to "DeviceNet Slave Unit Hardware Manual".

Connection Configuration

Connection Image



Data Transfer Through DeviceNet

Slave I/O communication allows the Display to communicate with the DeviceNet master.

◆ Slave I/O communication

Slave I/O communication is the feature that converts I/O data automatically between the External Device installed with the master unit and the Display.

Slave I/O uses a special link method that does not allow a user to access an External Device directly.

The master's output area is allocated to the Display's output area, and the master's input area is allocated to the Display's input area.



MEMO • The Display is used as a slave unit.

• Explicit message communication is not supported.

2 Selection of External Device

Select the External Device to be connected to the Display.

💰 New Project File		×
GP-Pro	Device/PLC	
	Maker ODVA	<u> </u>
	Driver DeviceNet Slave	▼
	🗖 Use System Area 🛛 🖪	er to the manual of this Device/PLC
	Connection Method	
	Port Extended Unit	
		<u>Go to Device/PLC Manual</u>
Back (B) Communication Settings New Logic	New Screen Cancel

Setup Items	Setup Items Setup Description	
Maker	Select the maker of the External Device to be connected. Select "ODVA".	
Driver	Select a model (series) of the External Device to be connected and connection method. Select "DeviceNet Slave". Check the External Device which can be connected in "DeviceNet Slave" in system configuration. ** "1 System Configuration" (page 3)	
Port	Select the Display port to be connected to the External Device.	

3 Example of Communication Setting

Examples of communication settings of the Display and the External Device, recommended by Digital Electronics Corp., are shown.

3.1 Setting Example 1

Settings of GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC 1				
Summary			<u>Cł</u>	hange Device/PLC
Maker ODVA	Driver	DeviceNet Slave	Port	Extended Unit
Text Data Mode 1 Change				
Communication Settings				
Node Number 1 💼				
Baud Rate Auto 🔽 🗹 Auto				
Slave I/O				
Input Area Size 32 📑 (words)				
Output Area Size 32 📑 (words)				
Input and Output size should match with the DeviceNet Master configuration for this slave.				
Default				
Device-Specific Settings				
Allowable No. of Device/PLCs 1 Unit(s)				
I PLC1				

♦ Device Setting

There is no setting on the External Device.

Notes

• The input and output area sizes must be identical to the settings on the DeviceNet master.

Settings of External Device

With the External Device to be used as a DeviceNet master, register the Display (DeviceNet slave unit) as a DeviceNet slave, and then conform the DiveceNet master's input and output area sizes to the settings on the Display.

Please refer to the maker's manual of the External Device for more details on how to register as a slave.

• You can use an EDS file when registering the Display as a slave. The EDS file for the Display is stored in the [\Fieldbus\DeviceNet] folder on the CD-ROM of GP-Pro EX. Please refer to the manual of the External Device (master) for more details on how to use EDS files.

4 Setup Items

Set communication settings of the Display with GP-Pro Ex or in off-line mode of the Display. The setting of each parameter must be identical to that of the External Device.

³ "3 Example of Communication Setting" (page 8)

4.1 Setup Items in GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC1	
Summary	Change Device/PLC
Maker ODVA Driver DeviceNet Slave	Port Extended Unit
Text Data Mode 1 Change	
Communication Settings	
Node Number 1	
Baud Rate Auto	
Slave I/O	
Input Area Size 32 📑 (words)	
Output Area Size 32 😴 (words)	
Input and Output size should match with the DeviceNet Master configuration for this slave.	
Default	
Device-Specific Settings	
Allowable No. of Device/PLCs 1 Unit(s)	
No. Device Name Securgs I PLC1 Image: Securgs	

Setup Items	Setup Description	
Node Number	Use an integer from "0 to 63" to enter the node No.	
Baud RateSelect the communication speed between the External Device and the Display. If you check [Auto], the port will be automatically set.		
Slave I/O Input Area Size	Set the input area size from "0" to "128" in word unit.	
Slave I/O Output Area Size	Set the output area size from "0" to "128" in word unit.	

4.2 Setup Items in Off-Line Mode

MEMO

• Please refer to Maintenance/Troubleshooting for more information on how to enter off-line mode or about operation.

Cf. Maintenance/Troubleshooting "2.2 Offline Mode"

Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Equipment Settings] in the off-line mode. Touch the External Device you want to set from the displayed list.



Setup Items	Setup Description
Node Number	Use an integer from "0 to 63" to enter the node No.
Baud Rate	Select the communication speed between the External Device and the Display. Select either "Fixed" or "Auto". If you select "Fixed", select the communication speed. If you select "Auto", the communication speed will be automatically set, regardless of the set value.
Input Area Size	Set the input area size from "0" to "128" in word unit.
Output Area Size	Set the output area size from "0" to "128" in word unit.

5 Supported Device

Range of supported device address is shown in the table below. Note that the actually supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your External Device.

■ Slave I/O

Device Bit Address		Word Address	32 bits	Remarks
Input	I000.00 - I127.15	I000 - I127		*1 *3
Output	O000.00 - O127.15	O000 - O127	<u>[[] H</u>	*2 *3

*1 Indicates Display's input area in the DeviceNet master (External Device). Write data to this area of the DeviceNet master (External Device) with the application on the Display.

*2 Indicates Display's output area in the DeviceNet master (External Device). Read data from this area of the DeviceNet master (External Device) with the application on the Display. Data cannot be written to but can be read from this area with the application on the Display.

*3 The above indicates the maximum range supported by DeviceNet slave unit. Actual maximum values depend on the input and output area sizes assigned to the Display by the DeviceNet master (External Device).



6 Device Code and Address Code

Use device code and address code if you select "Device Type & Address" for the address type in data displays.

Device	Word Address	Device Code (HEX)	Address Code
Input	Ι	0084	Word Address
Output	0	0085	Word Address

7 Error Messages

Error messages are displayed on the Display screen as follows: "No.: Device Name: Error Message (Error Occurrence Area)". Each description is shown below.

Item	Description		
No.	Error No.		
Device Name	Name of the External Device where error occurs. Device name is a title of the External Device set with GP-Pro EX. (Initial value [PLC1])		
Error Message	Displays messages related to the error which occurs.		
Error Occurrence Area	 Displays IP address or device address of the External Device where error occurs, or error codes received from the External Device. MEMO IP address is displayed such as "IP address (Decimal): MAC address (Hex)". Device address is displayed such as "Address: Device address". 		
	• Received error codes are displayed such as "Decimal [Hex]".		

Display Examples of Error Messages

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 2 [02H])"

MEMO
Please refer to the manual of the External Device for more detail of received error codes.
Please refer to "If the error is displayed (Error Code List)" in "Maintenance/Troubleshooting Guide" for more detail of the error messages common to the driver.

Error Messages Specific to the External Device

Error No.	Message	Solution
RHxx128	Error During Initialization of Interface Module	This is a hardware problem. Check the module.
RHxx129	Illegal Initialization Parameter	Reduce the size of the input or output area.
RHxx130	Incorrect Interface Module Detected	Connect the correct module.
RHxx131	Network Communication Error, LED Status: [0x%x]	Check the cable, baud rate settings, input and output sizes, master (scanner) settings. Check the LED status for more details. ^{*1}

*1 For more information about the LED status, please refer to "DeviceNet Slave Unit Hardware Manual".