Mitsubishi Electric Corporation MITFXLNK\_32 3/2025

# FX Series Computer Link Driver

1	System Configuration	
2	Selection of External Device	
3	Example of Communication Setting	13
4	Setup Items	20
5	Cable Diagram	25
6	Supported Device	58
7	Device Code and Address Code	60
8	Error Messages	61

IMPORTANT ·	The below Displays are no longer sold nor maintained by Pro-face. To reduce unplanned downtime due to aged hardware and to maximize your cyber security environment we recommend replacing your devices with a new, successor model. For details, please visit our homepage for "Recommended Substitution". Discontinued from GP-Pro EX 5.00 onwards: GP3000 Series, LT3000 Series,
•	ST3000 Series, GP-4100 Series (Monochrome model), PL Series, PS3000/4000 Series, PE4000 Series. For details on the Displays supported by the driver, please check the "Connectable
	Devices" on our website

http://www.pro-face.com/trans/en/manual/1064.html

#### Introduction

This manual describes how to connect Display and External Device (target PLC).

In this manual, the connection procedure will be described by following the below sections:

1	System Configuration This section shows the types of External Device which can be connected and SIO type.	"1 System Configuration" (page 3)
2	Selection of External Device Select a model (series) of the External Device to be connected and connection method	"2 Selection of External Device" (page 12)
3	Example of Communication Settings This section shows setting examples for communicating between the display and the External Device.	"3 Example of Communication Setting" (page 13)
4	Setup Items This section describes communication setup items on the display. Set communication settings of Display with GP-Pro Ex or in offline mode.	ঞ্চি"4 Setup Items" (page 20)
	Cable Diagram	

5	Cable Diagram This section shows cables and adapters for connecting the display and the External Device.	<sup>ভেল</sup> "5 Cable Diagram" (page 25)
	Operation	

# 1 System Configuration

The system configuration in the case when the External Device of Mitsubishi Electric Corporation and the display are connected is shown.

Series	CPU	Link I/F <sup>*1</sup>	SIO Type	Setting Example	Cable Diagram
		FX0N-232ADP	RS232C	Setting Example 1 (page 13)	Cable Diagram 2 (page 27)
		FX2NC-232ADP	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)
	FX0N <sup>*2</sup> FX1NC		RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)
	FX2NC	FX0N-485ADP, FX2NC-485ADP	RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)
			RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)
		FX1N-232-BD, FX2NC-232ADP+FX1N-CNV-BD	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)
	FX1S FX1N	FX0N-232ADP+FX1N-CNV-BD	RS232C	Setting Example 1 (page 13)	Cable Diagram 2 (page 27)
FX Series		XIS XIN FX1N-485-BD, FX0N-485ADP+FX1N-CNV-BD, FX2NC-485ADP+FX1N-CNV-BD	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)
			RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)
			RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)
		FX2N-232-BD, FX2NC-232ADP+FX2N-CNV-BD	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)
		FX0N-232ADP+FX2N-CNV-BD		Setting Example 1 (page 13)	Cable Diagram 2 (page 27)
	FX2N *3	FX2N <sup>*3</sup> FX2N-485-BD, FX0N-485ADP+FX2N-CNV-BD, FX2NC-485ADP+FX2N-CNV-BD	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)
			RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)
				RS422/485 (2wire)	Setting Example 2 (page 16)

Series	CPU	Link I/F <sup>*1</sup>	SIO Type	Setting Example	Cable Diagram
	FX3UC- 32MT-	*When using channel 1 (Ch1) FX3U-232-BD, FX3U-232ADP+FX3U-CNV-BD *When using channel 2 (Ch2) FX3U-232ADP+FX3U-□□□-BD, FX3U-232ADP <sup>*5</sup> +FX3U-■■ADP +FX3U-CNV-BD	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)
	LT(-2) <sup>4</sup> FX3U <sup>*4</sup>	*When using channel 1 (Ch1) FX3U-485-BD, FX3U-485ADP+FX3U-CNV-BD *When using channel 2 (Ch2)	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)
			RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)
		$FX3U-485ADP^{*6} + FX3U-\blacksquare \blacksquare ADP + FX3U-CNV-BD$	RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)
FX Series	FX3UC (D,DSS)	*When using channel 1 (Ch1) FX3U-232ADP *When using channel 2 (Ch2) FX3U-232ADP <sup>*5</sup> +FX3U-■■ ADP	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)
		C S) *When using channel 1 (Ch1) FX3U-485ADP *When using channel 2 (Ch2) FX3U-485ADP <sup>*6</sup> +FX3U-■ ■ ADP	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)
			RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)
			RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)
	FX3G (14,24 points type)	FX3G-232-BD, FX3U-232ADP+ FX3G-CNV-ADP	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)
		G 24 hts FX3G-485-BD, FX3U-485ADP+FX3G-CNV-ADP	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)
			RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)
			RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)

Series	CPU	CPU Link I/F <sup>*1</sup>		Setting Example	Cable Diagram	
	FX3G (40,60	*When using channel 1 (Ch1) FX3G-232-BD (When connecting to Connector 1 for optional units), FX3U-232ADP+FX3G-CNV-ADP *When using channel 2 (Ch2) FX3G-232-BD (When connecting to Connector 2 for optional units), FX3U-232ADP <sup>*5</sup> +FX3U-■ ■ ADP +FX3G-CNV-ADP	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)	
	points type) <sup>*4</sup>	*When using channel 1 (Ch1) FX3G-485-BD (When connecting to	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)	
		Connector 1 for optional units), FX3U-485ADP+FX3G-CNV-ADP *When using channel 2 (Ch2)	RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)	
		FX3G-485-BD (When connecting to Connector 2 for optional units), FX3U-485ADP <sup>*6</sup> +FX3U-■ ■ ADP +FX3G-CNV-ADP	RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)	
FX	FX3GC	RS-232C Connector on FX3U-232ADP	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)	
Series		Terminal Block for connecting RS-485 device on FX3U-485ADP	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)	
			RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)	
			RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)	
	FX3S		FX3G-232-BD, FX3U-232ADP + FX3S-CNV-ADP, FX3U-232ADP-MB + FX3S-CNV- ADP	RS232C	Setting Example 1 (page 13)	Cable Diagram 1 (page 25)
		FX3G-485-BD, FX3U-485ADP + FX3S-CNV-ADP, FX3U-485ADP-MB + FX3S-CNV- ADP	RS422/485 (4wire)	Setting Example 3 (page 18)	Cable Diagram 3 (page 28)	
			RS422/485 (4wire) Multilink	Setting Example 3 (page 18)	Cable Diagram 5 (page 50)	
			RS422/485 (2wire)	Setting Example 2 (page 16)	Cable Diagram 4 (page 37)	

\*1 Any of 232, 422, 485 and USB is shown in □ □ □. Either of 232 or 485 is shown in ■ ■.

\*2 System version 1.20 or higher for External Device is required. You can monitor the special register D8001 to check the system version for External Device. Please refer to the manual of External Device for more details.

\*3 System version 1.06 or higher for External Device is required. You can monitor the special register D8001 to check the system version for External Device. Please refer to the manual of External Device for more details.

\*4 Simultaneous communication of Ch1 and Ch2 is available.

- \*5 FX3U-232ADP is assigned to Ch2.
- \*6 FX3U-485ADP is assigned to Ch2.
  - **NOTE** When the time of the Displays is automatically updated in [Clock Update Settings] of GP-Pro EX, there are some restrictions as shown below.

For details on [Clock Update Settings], refer to GP-Pro EX Reference Manual.

- FX0N does not support automatic update of the time. Specify [Customize] in [Clock Update Settings].
- When the time is automatically updated in FX2NC, the real time clock function board or the E2PROM memory with the real time clock function is required.

# Connection Configuration

• 1:1 Connection



1:n Connection

Maximum number of connectable units : 16 units



• n:1 Connection (Multilink connection)

Maximum number of connectable units: 16 units

**NOTE** • The maximum number of connectable Displays is 16 units. However, keeping performance in consideration, the number of Displays that can be substantially used is up to 4.

n:m Connection (Multilink connection)

•



**NOTE** • The maximum number of connectable Displays is 16 units. However, keeping performance in consideration, the number of Displays that can be substantially used is up to 4.

# ■ IPC COM Port

When connecting IPC with an External Device, the COM port used depends on the series and SIO type. Please refer to the IPC manual for details.

#### Usable port

Sorios	Usable Port			
Genes	RS-232C	RS-422/485(4 wire)	RS-422/485(2 wire)	
PS-2000B	COM1 <sup>*1</sup> , COM2, COM3 <sup>*1</sup> , COM4	-	-	
PS-3450A, PS-3451A, PS3000-BA, PS3001-BD	COM1, COM2 <sup>*1*2</sup>	COM2 <sup>*1*2</sup>	COM2 <sup>*1*2</sup>	
PS-3650A (T41 model), PS-3651A (T41 model)	COM1 <sup>*1</sup>	-	-	
PS-3650A (T42 model), PS-3651A (T42 model)	COM1 <sup>*1*2</sup> , COM2	COM1 <sup>*1*2</sup>	COM1 <sup>*1*2</sup>	
PS-3700A (Pentium®4-M) PS-3710A	COM1 <sup>*1</sup> , COM2 <sup>*1</sup> , COM3 <sup>*2</sup> , COM4	COM3 <sup>*2</sup>	COM3 <sup>*2</sup>	
PS-3711A	COM1 <sup>*1</sup> , COM2 <sup>*2</sup>	COM2 <sup>*2</sup>	COM2 <sup>*2</sup>	
PS4000 <sup>*3</sup>	COM1, COM2	-	-	
PL3000	COM1 <sup>*1*2</sup> , COM2 <sup>*1</sup> , COM3, COM4	COM1 <sup>*1*2</sup>	COM1*1*2	
PE-4000B Atom N270	COM1, COM2	-	-	
PE-4000B Atom N2600	COM1, COM2	COM3 <sup>*4</sup> , COM4 <sup>*4</sup> , COM5 <sup>*4</sup> , COM6 <sup>*4</sup>	COM3 <sup>*4</sup> , COM4 <sup>*4</sup> , COM5 <sup>*4</sup> , COM6 <sup>*4</sup>	
PS5000 (Slim Panel Type Core i3 Model) *5*6	COM1, COM2 <sup>*4</sup>	COM2 <sup>*4</sup>	COM2 <sup>*4</sup>	
PS5000 (Slim Panel Type Atom Model) *5 *6	COM1, COM2 <sup>*7</sup>	COM2 <sup>*7</sup>	COM2 <sup>*7</sup>	
PS5000 (Enclosed Panel Type) <sup>*8</sup>	COM1	-	-	
PS5000 (Modular Type PFXPU/PFXPP) <sup>*5 *6</sup> PS5000 (Modular Type PFXPL2B5-6)	COM1 <sup>*7</sup>	COM1 <sup>*7</sup>	COM1 <sup>*7</sup>	
PS5000 (Modular Type PFXPL2B1-4)	COM1, COM2 <sup>*7</sup>	COM2 <sup>*7</sup>	COM2 <sup>*7</sup>	
PS6000 (Advanced Box) PS6000 (Standard Box)	COM1 <sup>*9</sup>	*10	*10	
PS6000 (Basic Box)	COM1 <sup>*9</sup>	COM1 <sup>*9</sup>	COM1 <sup>*9</sup>	

\*1 The RI/5V can be switched. Use the IPC's switch to change if necessary.

\*2 Set up the SIO type with the DIP Switch. Please set up as follows according to SIO type to be used.

- \*3 When making communication between an External Device and COM port on the Expansion slot, only RS-232C is supported. However, ER (DTR/CTS) control cannot be executed because of the specification of COM port. For connection with External Device, use user-created cables and disable Pin Nos. 1, 4, 6 and 9. Please refer to the IPC manual for details of pin layout.
- \*4 Set up the SIO type with the BIOS. Please refer to the IPC manual for details of BIOS.
- \*5 When setting up communication between an External Device and the RS-232C/422/485 interface module, use the IPC (RS-232C) or PS5000 (RS-422/485) cable diagrams. However, when using PFXZPBMPR42P2 in a RS-422/485 (4-wire) configuration with no flow control, connect 7.RTS+ and 8.CTS+, and connect 6.RTS- and 9.CTS-. When using RS-422/485 communication with External Devices, you may need to reduce the

When using RS-422/485 communication with External Devices, you may need to reduce the transmission speed and increase the TX Wait time.

\*6 To use RS-422/485 communication on the RS-232C/422/485 interface module, the DIP Switch setting is required. Please refer to "Knowledge Base" (FAQs) on the support site. (http://www.pro-face.com/trans/en/manual/1001.html)

Settings	FAQ ID
PFXZPBMPR42P2, RS422/485 change method	FA263858
PFXZPBMPR42P2 termination resistor setting	FA263974
PFXZPBMPR44P2, RS422/485 change method	FA264087
PFXZPBMPR44P2 termination resistor setting	FA264088

- \*7 Set up the SIO type with the DIP Switch. Please refer to the IPC manual for details of DIP Switch. The BOX Atom has not a switch to set the RS-232C, RS-422/485 mode. Use the BIOS for the setting.
- \*8 For the connection with the External Device, on the user-created cable read as if the connector on the Display-side is a M12 A-coding 8 pin socket. The pin assignment is the same as described in the cable diagram. For the M12 A-coding connector, use PFXZPSCNM122.
- \*9 In addition to COM1, you can also use the COM port on the optional interface.
- \*10 Install the optional interface in the expansion slot.

#### DIP Switch settings (PL3000 / PS3000 Series)

RS-232C

DIP Switch	Setting	Description	
1	OFF <sup>*1</sup>	Reserved (always OFF)	
2	OFF	SIQ type: RS-232C	
3	OFF	510 type. R5-2520	
4	OFF	Output mode of SD (TXD) data: Always output	
5	OFF	Terminal resistance (220 $\Omega$ ) insertion to SD (TXD): None	
6	OFF	Terminal resistance (220 $\Omega$ ) insertion to RD (RXD): None	
7	OFF	Short-circuit of SDA (TXA) and RDA (RXA): Not available	
8	OFF	Short-circuit of SDB (TXB) and RDB (RXB): Not available	
9	OFF	PS (PTS) Auto control mode: Dischlod	
10	OFF	KS (KIS) Auto control mode. Disabled	
1 When using PS-3450A PS-3451A PS3000-BA and PS3001-BD turn ON the set value			

RS-422/485 (4 wire)

DIP Switch	Setting	Description	
1	OFF	Reserved (always OFF)	
2	ON	SIO type: PS 422/485	
3	ON	510 type. K5-422/485	
4	OFF	Output mode of SD (TXD) data: Always output	
5	OFF	Terminal resistance (220 $\Omega$ ) insertion to SD (TXD): None	
6	OFF	Terminal resistance (220 $\Omega$ ) insertion to RD (RXD): None	
7	OFF	Short-circuit of SDA (TXA) and RDA (RXA): Not available	
8	OFF	Short-circuit of SDB (TXB) and RDB (RXB): Not available	
9	OFF <sup>*1</sup>	RS (RTS) Auto control mode: Disabled	
10	OFF <sup>*1</sup>	- KS (K15) Auto control mode. Disabled	

\*1 When the connection configuration are the n:1 and n:m connections (both Multilink connections), turn ON the set value.

RS-422/485 (2 wire)

DIP Switch	Setting	Description	
1	OFF	Reserved (always OFF)	
2	ON	SIQ type: RS-422/485	
3	ON	510 type. R5-422/403	
4	OFF	Output mode of SD (TXD) data: Always output	
5	OFF	Terminal resistance (220 $\Omega$ ) insertion to SD (TXD): None	
6	OFF	Terminal resistance (220Ω) insertion to RD (RXD): None	
7	ON	Short-circuit of SDA (TXA) and RDA (RXA): Available	
8	ON	Short-circuit of SDB (TXB) and RDB (RXB): Available	
9	ON	RS (RTS) Auto control mode: Enabled	
10	ON	KS (K1S) Auto control mode: Enabled	

# 2 Selection of External Device

Select the External Device to be connected to the Display.

💰 Welcome to GP-Pro EX		K	۲
67-7ro 🛃	Device/PLC Number of Devices/PLCs		
		Device/PLC 1	
	Manufacturer	Mitsubishi Electric Corporation	
	Series	FX Series Computer Link	
	Port	COM1	
		Refer to the manual of this Device/PLC	
		Recent Device/PLC	
	1	Þ	
	Use System	Area Device Information	
	Back (B	Communication Settings New Logic New Screen Cancel	

Setup Items	Setup Description
Number of Devices/ PLCs	Enter an integer from 1 to 4 to define the number of Devices/PLCs to connect to the display.
Manufacturer	Select the manufacturer of the External Device to connect. Select "Mitsubishi Electric Corporation".
Series	Select the External Device model (series) and the connection method. Select "FX Series Computer Link". In System configuration, make sure the External Device you are connecting is supported by "FX Series Computer Link".
Port	Select the Display port to connect to the External Device.
Use System Area	Check this option to synchronize the system data area of the Display and the device (memory) of the External Device. When synchronized, you can use the External Device's ladder program to switch the display or display the window on the Display. Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)" This feature can also be set in GP-Pro EX or in the Display's offline mode. Cf. GP-Pro EX Reference Manual "System Settings [Display Unit] - [System Area] Settings Guide" Cf. Maintenance/Troubleshooting Guide "Main Unit - System Area Settings"

# 3 Example of Communication Setting

Examples of communication settings of the display and the External Device, recommended by Pro-face, are shown.

When you use the FX Series, use GP-Pro EX and the ladder software to set as below.

## 3.1 Setting Example 1

#### Setting of GP-Pro EX

Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC1
Summary Change Device/PLC
Manufacturer Mitsubishi Electric Corporation Series FX Series Computer Link Port COM1
Text Data Mode 2 Change
Communication Settings
SIO Type C RS232C C RS422/485(2wire) C RS422/485(4wire)
Speed 19200
Data Length 📀 7 C 8
Parity CINONE CIEVEN CIODD
Stop Bit O 1 💌 2
Flow Control C NONE C ER(DTR/CTS) C X0N/X0FF
Timeout 3 💼 (sec)
Retry 2
Wait To Send 1 💼 (ms)
Format Format 4
RI/VCC © RI C VCC
In the case of RS232C, you can select the 9th pin to RI (Input) or VCC (5V Power Supply). If you use the Digital's RS232C Isolation Unit, please select it to VCC.
Device-Specific Settings
Allowable Number Add Device
No. Device Name Settings Add Indirect
I         PLC1         Istation No.=0         Image: PLC1         Image:

#### Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

🎒 Individual Device Settings	×	
PLC1		
Station No. 0		
Bit set in word address operation		
Other bits in this word		
◯ Do not clea	r	
Note on when selecting "Do not clear" : If the ladder program writes data to the word address during the read/write process, the resulting data may be incorrect.		
Default		
OK (O) Cancel		

## Setting of External Device

Setting of External Device includes the setting with parameter and the setting by writing data to the special data register.

Setting with parameter

Double-click [PC parameter] from [Parameter] in the tree view of the ladder software to display the [FX parameter] dialog box.

Click the [PC system settings (2)] tab for communication settings.

**IMPORTANT** • FX0N does not support the setting with parameter. Select the setting by writing data to the special data register.

Setup items and description are shown below.

Setup Items	Setup Description
CH <sup>*1</sup>	CH1 or CH2
Protocol	Protocol communication only
Data Length	7
Parity	Even
Stop Bit	2
Line Speed	Match with the speed of Display
Header	None
Terminator	None
H/W Type	Normal/RS232C
Sum Check	Added
Control method	Form 4
Timeout	1

\*1 Setting only for FX3UC, FX3U, FX3G and FX3GC.

#### Setting by writing data to the special data register

Write data to the data register of External Device. After writing, turn the power of External Device from OFF to ON.

**IMPORTANT** • When using the FX0N Series, turn ON M8120 for keeping communication settings before turning power from OFF to ON.

Write destination data register and write data are shown below.

Write Destination Data Register		
CH1 of FX3UC, FX3U, FX3G, FX3GC and FX Series except above	CH2 of FX3UC, FX3U, FX3G and FX3GC	Write data
D8120	D8420	0xE89E
D8121	D8421	0
D8129	D8429	1

# 3.2 Setting Example 2

Setting of GP-Pro EX

Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1	
Summary	Change Device/PLC
Manufacturer Mitsubishi Electric Corporation Series FX Series Computer Link	Port COM1
Text Data Mode 2 Change	
Communication Settings	
SIO Type C RS232C © RS422/485(2wire) C RS422/485(4wire)	
Speed 19200	
Data Length 📀 7 🔿 8	
Parity C NONE O EVEN C ODD	
Stop Bit C 1 💿 2	
Flow Control       O NONE       O ER(DTR/CTS)       C X0N/X0FF	
Timeout 3 📫 (sec)	
Retry 2	
Wait To Send 1 📫 (ms)	
Format Format 4	
RI/VCC © RI O VCC	
In the case of RS232C, you can select the 9th pin to RI (Input) or VCC (5V Power Supply). If you use the Digital's RS232C Isolation Unit, please select it to VCC.	
Device-Specific Settings	
Allowable Number Add Device	
or Devices/FLLs 15	Add Indirect
X 1 PLC1 Station No.=0	
	<u>#01</u>

#### Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

🎒 Individual Device S	ettings		×
PLC1			
Station No.	0	-	
Bit set in word addres	s operation		
Other bits in this w	vord	Clear	
		O Do not clear	
Note on when selecting "Do not clear" : If the ladder program writes data to the word address during the read/write process, the resulting data may be incorrect.			
		Default	]
	OK (O)	Cancel	

## Setting of External Device

Setting of External Device includes the setting with parameter and the setting by writing data to the special data register.

Setting with Parameter

Double-click [PC parameter] from [Parameter] in the tree view of the ladder software to display the [FX parameter] dialog box.

Click the [PC system settings (2)] tab for communication settings.

**IMPORTANT** • FX0N does not support the setting with parameter. Select the setting by writing data to the special data register.

Setup items and description are shown below.

Setup Items	Setup Description
CH <sup>*1</sup>	CH1 or CH2
Protocol	Protocol communication only
Data Length	7
Parity	Even
Stop Bit	2
Line Speed	Match with the speed of Display
Header	None
Terminator	None
H/W Type	RS-485/RS-422
Sum Check	Added
Control method	Form 4
Timeout	1

\*1 Setting only for FX3UC, FX3U, FX3G and FX3GC.

#### Setting by writing data to the special data register

Write data to the data register of External Device. After writing, turn the power of External Device from OFF to ON.

**IMPORTANT** • When using the FX0N Series, turn ON M8120 for keeping communication settings before turning power from OFF to ON.

Write destination data register and write data are shown below.

Write Destination Data Register		
CH1 of FX3UC, FX3U, FX3G, FX3GC and FX Series except above	CH2 of FX3UC, FX3U, FX3G and FX3GC	Write Data
D8120	D8420	0xE09E
D8121	D8421	0
D8129	D8429	1

# 3.3 Setting Example 3

Setting of GP-Pro EX

Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC1	
Summary	Change Device/PLC
Manufacturer Mitsubishi Electric Corporation Series FX Series Computer Link	Port COM1
Text Data Mode 2 Change	
Communication Settings	
SID Type O RS232C O RS422/485(2wire) O RS422/485(4wire)	
Speed 19200	
Data Length 💿 7 💿 8	
Parity CINONE CIEVEN CIDD	
Stop Bit O 1 💿 2	
Flow Control  O NONE  O ER(DTR/CTS)  O X0N/X0FF	
Timeout 3 🗮 (sec)	
Retry 2	
Wait To Send 1 👘 (ms)	
Format Format 4	
RI/VCC © RI C VCC	
In the case of RS232C, you can select the 9th pin to RI (Input) or VCC (5V Power Supply). If you use the Digital's RS232C Isolation Unit, please select it to VCC. Default	
Device-Specific Settings	
Allowable Number <u>Add Device</u>	
OF DEVICES/FLLS ID	Add Indirect
X 1 PLC1 Station No.=0	

#### Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

🎒 Individual Device Settings	×	
PLC1		
Station No. 0		
Bit set in word address operation		
Other bits in this word		
O Do not clear	r	
Note on when selecting "Do not clear" : If the ladder program writes data to the word address during the read/write process, the resulting data may be incorrect.		
Default		
OK (O) Cancel		

## Setting of External Device

Setting of External Device includes the setting with parameter and the setting by writing data to the special data register.

Setting with Parameter

Double-click [PC parameter] from [Parameter] in the tree view of the ladder software to display the [FX parameter] dialog box.

Click the [PC system settings (2)] tab for communication settings.

**IMPORTANT** • FX0N does not support the setting with parameter. Select the setting by writing data to the special data register.

Setup items and description are shown below.

Setup Items	Setup Description
CH <sup>*1</sup>	CH1 or CH2
Protocol	Protocol communication only
Data Length	7
Parity	Even
Stop Bit	2
Line Speed	Match with the speed of Display
Header	None
Terminator	None
H/W Type	RS-485/RS-422
Sum Check	Added
Control method	Form 4
Timeout	1

\*1 Setting only for FX3UC, FX3U, FX3G and FX3GC.

#### Setting by writing data to the special data register

Write data to the data register of External Device. After writing, turn the power of External Device from OFF to ON.

**IMPORTANT** • When using the FX0N Series, turn ON M8120 for keeping communication settings before turning power from OFF to ON.

Write destination data register and write data are shown below.

Write Destination Data Register			
CH1 of FX3UC, FX3U, FX3G, FX3GC and FX Series except above	CH2 of FX3UC, FX3U, FX3G and FX3GC	Write Data	
D8120	D8420	0xE09E	
D8121	D8421	0	
D8129	D8429	1	

# 4 Setup Items

Set communication settings of the Display with GP-Pro EX or in offline mode of Display. The setting of each parameter must be identical to that of External Device.

"3 Example of Communication Setting" (page 13)

# 4.1 Setup Items in GP-Pro EX

## Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1		
Summary		Change Device/PLC
Manufacturer Mitsubishi Elect	ric Corporation Series FX Series Computer Link	Port COM1
Text Data Mode 2	Change	
Communication Settings		
SIO Type 📀 R	5232C 🔿 RS422/485(2wire) 🔿 RS422/485(4wire)	
Speed 1920	0	
Data Length 📀 7	C 8	
Parity 🔿 N	DNE O EVEN O ODD	
Stop Bit 📀 1	2	
Flow Control 📀 N	DNE 💿 ER(DTR/CTS) 🔿 XON/XOFF	
Timeout 3	🗧 (sec)	
Retry 2		
Wait To Send 1		
Format Form	at 4	
RI/VCC © R	C VCC	
In the case of RS232C, yo or VCC (5V Power Supply) Isolation Unit, please selec	a can select the 9th pin to RI (Input) If you use the Digital's RS232C it to VCC. Default	
Device-Specific Settings		
Allowable Number	Add Device	
No. Device Name	Settings	Add Indirect
1 PLC1	Station No.=0	

Setup Items	Setup Description
SIO Type	Select the SIO type to communicate with the External Device.
Speed	Select speed between External Device and Display.
Data Length	Select data length.
Parity	Select how to check parity.
Stop Bit	Select stop bit length.
Flow Control	Select the communication control method to prevent overflow of transmission and reception data.
Timeout	Use an integer from 1 to 127 to enter the time (s) for which Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times Display retransmits the command.

Setup Items	Setup Description
Wait To Send	<ul> <li>Use an integer from 0 to 255 to enter standby time (ms) for Display from receiving packets to transmitting next commands.</li> <li><b>NOTE</b></li> <li>Set the value more than twice as the scanning time of External Device when connecting to FX0N, FX1S, FX1N and FX1NC Series.</li> </ul>
Format	Select the dedicated protocol format to use, from "Format 4" or "Format 1".           NOTE           • When using serial multilink, select "Format 4".
RI/VCC	You can switch RI/VCC of the 9th pin when you select RS232C for SIO type. It is necessary to change RI/5V by changeover switch of IPC when connect with IPC. Please refer to the manual of the IPC for more detail.
NOTE	<ul> <li>Refer to the GP-Pro EX Reference Manual for Indirect Device.</li> <li>Cf. GP-Pro EX Reference Manual "Changing the Device/PLC at Runtime (Indirect</li> </ul>

## Device Setting

Device)"

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

🎒 Individual Device Settings		
PLC1		
Station No. 0	<b></b>	
Bit set in word address op	eration	
Other bits in this word	<ul> <li>Clear</li> </ul>	
	◯ Do not clear	
Note on when selecting the ladder program wri address during the rea resulting data may be i	g "Do not clear" : If tes data to the word d/write process, the ncorrect.	
	Default	
ОК	(O) Cancel	

Setup Items	Setup Description
Station No.	Enter a station number of External Device, using 0 to F.
Other bits in this word	Select "Clear" or "Do not clear" for the handling of other bit data in the same word when a bit operation is performed to a bit specified word address.

# 4.2 Setup Items in Offline Mode



• Refer to the Maintenance/Troubleshooting guide for information on how to enter offline mode or about the operation.

- Cf. Maintenance/Troubleshooting Guide "Offline Mode"
- The number of the setup items to be displayed for 1 page in the offline mode depends on the Display in use. Please refer to the Reference manual for details.

#### Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings] in offline mode. Touch the External Device you want to set from the displayed list.

Comm.	Device	Option		
FX Series Compu	iter Link		[COM1]	Page 1/1
	SIO Type Speed Data Length Parity Stop Bit Flow Control Timeout(s) Retry Wait To Send(ms) Format	RS232C 19200 • 7 • NONE • 1 JER(DTR/C	8 • EVEN • 2 TS) 3 • • • • • • • • • • • • • • • • • • •	ODD
	Exit		Back	2022/12/02 16:21:57

Setup Items	Setup Description		
	Select the SIO type to communicate with the External Device.		
SIO Type	To make the communication settings correctly, confirm the serial interface specifications of Display unit for [SIO Type]. We cannot guarantee the operation if a communication type that the serial interface does not support is specified. For details concerning the serial interface specifications, refer to the manual for Display unit.		
Speed	Select speed between the External Device and the Display.		
Data Length	Select data length.		
Parity	Select how to check parity.		
Stop Bit	Select stop bit length.		
Flow Control	Select the communication control method to prevent overflow of transmission and reception data.		
Timeout (s)	Use an integer from 1 to 127 to enter the time (s) for which Display waits for the response from the External Device.		

Setup Items	Setup Description
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times Display retransmits the command.
	Use an integer from 0 to 255 to enter standby time (ms) for Display from receiving packets to transmitting next commands.
Wait To Send	NOTE
	Set the value more than twice as the scanning time of External Device when connecting to FX0N, FX1S, FX1N and FX1NC Series.
	Select the dedicated protocol format to use, from "Format 4" or "Format 1".
Format	<b>NOTE</b> When using serial multilink, select "Format 4".

## Device Setting

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Device].

Comm.	Device	Option		
FX Series Compu	iter Link		[COM1]	Page 1/1
Devic	e/PLC Name  PL	01		•
	Station No.		0 💌 🔺	
	Bit set in word	address operatio	n	
	Uther Dits	Ulear		
	Eu:+		Paole	2022/12/02
	EXIT		DACK	16:22:07

Setup Items	Setup Description
Device/PLC Name	Select the External Device for device setting. Device name is a title of External Device set with GP-Pro EX.(Initial value [PLC1])
Station No.	Enter a station number of the External Device, using 0 to F.
Bit set in word address operation	Displays "Clear" or "Do not clear" for the handling of other bit data in the same word when a bit operation is performed to a bit specified word address. (Cannot be set in offline mode.)

# Option

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Option].

Comm.	Device	Option		
FX Series Compu	liter Link		[COM1]	Page 1/1
	RI / VCC In the case the 9th pin Power Suppl RS232C Isol it to VCC.	<ul> <li>RI</li> <li>of R\$232C, you</li> <li>to RI(Input) or</li> <li>y). If you use th</li> <li>ation Unit, pleation</li> </ul>	C VCC can select · VCC(5V we Digital's use select	<ul> <li>0270</li> </ul>
	Exit		Back	2017/11/09 11:06:24

Setup Items	Setup Description
RI/VCC	You can switch RI/VCC of the 9th pin when you select RS232C for SIO type. It is necessary to change RI/5V by changeover switch of IPC when connect with IPC. Please refer to the manual of the IPC for more detail.
NOTE • G	P-4100 series, GP-4*01TM, GP-Rear Module, LT-4*01TM and LT-Rear Module do not ave the [Option] setting in the offline mode.

GP-Pro EX Device/PLC Connection Manual

The following cable diagrams may be different from cable diagrams recommended by Mitsubishi Electric Corporation. Please be assured there is no operational problem in applying the cable diagrams shown in this manual.

- Please ground the FG pin of the External Device body. Use a grounding resistance of  $100\Omega 2mm^2$  or thicker wire, or your country's applicable standard. Refer to your External Device manual for more details.
- The SG and FG are connected inside the Display. When connecting the External Device to the SG, design your system to avoid short-circuit loops.
- Connect an isolation unit if the communication is not stable due to noise or other factors.

Display (Connection Port)	Cable		Notes
GP3000 (COM1) GP4000 <sup>*1</sup> (COM1) GP6000 (COM1) SP5000 <sup>*2</sup> (COM1/2) SP-5B00 (COM1) ST3000 (COM1) ST6000 (COM1) STC6000 (COM1) ET6000 (COM1) LT3000 (COM1) IPC <sup>*3</sup> PC/AT	1A	User-created cable	The cable length must be 15 meters or less.
GP-4105 (COM1) GP-4115T (COM1) GP-4115T3 (COM1)	1B	User-created cable	The cable length must be 15 meters or less.

#### Cable Diagram 1

\*1 All GP4000 models except GP-4100 Series and GP-4203T

#### \*2 Except SP-5B00

\*3 Only the COM port which can communicate by RS-232C can be used. <sup>C</sup> ■ IPC COM Port (page 9)

1A)





Display (Connection Port)	Cable		Notes
GP3000 (COM1) GP4000 <sup>*1</sup> (COM1) GP6000 (COM1) SP5000 <sup>*2</sup> (COM1/2) SP-5B00 (COM1) ST3000 (COM1) ST6000 (COM1) STC6000 (COM1) ET6000 (COM1) LT3000 (COM1) IPC <sup>*3</sup> PC/AT	2A	User-created cable	The cable length must be 15 meters or less.
GP-4105 (COM1) GP-4115T (COM1) GP-4115T3 (COM1)	2B	User-created cable	The cable length must be 15 meters or less.

\*1 All GP4000 models except GP-4100 Series and GP-4203T

\*2 Except SP-5B00

\*3 Only the COM port which can communicate by RS-232C can be used.
 IPC COM Port (page 9)

2A)



2B)



Display (Connection Port)		Cable	Notes
GP3000 <sup>*1</sup> (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) GP-Rear Module (COM1) ST3000 <sup>*2</sup> (COM2) LT3000 (COM1) IPC <sup>*3</sup>	3A 3B	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable User-created cable	The cable length must be 500 meters or less. <sup>*4</sup>
GP3000 <sup>*5</sup> (COM2)	3C 3D	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable Online adapter by Pro-face CA4-ADPONL-01 + User-created cable	The cable length must be 500 meters or less. <sup>*4</sup>
GP-4106 (COM1) GP-4116T (COM1)	3E	User-created cable	The cable length must be 500 meters or less. <sup>*4</sup>
GP4000 <sup>*6</sup> (COM2) GP-4201T (COM1) GP6000 (COM2) SP5000 <sup>*7</sup> (COM1/2)	3F	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1 <sup>*10</sup> + User-created cable	
SP-5B00 (COM2) ST6000 <sup>*8</sup> (COM2) ST-6200 (COM1) STM6000 (COM1) STC6000 (COM1) ET6000 <sup>*9</sup> (COM2) PS6000 (Basic Box) (COM1/2)	3В	User-created cable	The cable length must be 500 meters or less. <sup>*4</sup>
PE-4000B <sup>*11</sup> PS5000 <sup>*11</sup> PS6000 (Optional Interface) <sup>*11</sup>	3G	User-created cable	The cable length must be 500 meters or less. <sup>*4</sup>

\*1 All GP3000 models except AGP-3302B

\*2 Except AST-3211A and AST-3302B

\*3 Only the COM port which can communicate by RS-422/485 (4 wire) can be used. (Except PE-4000B, PS5000, and PS6000)

■ IPC COM Port (page 9)

- \*4 When using FX1N-485-BD, FX2N-485-BD, FX3U-485-BD or FX3G-485-BD, the cable length must be 50 meters or less.
- \*5 All GP3000 models except GP-3200 series and AGP-3302B
- \*6 All GP4000 models except GP-4100 series, GP-4\*01TM, GP-Rear Module, GP-4201T and GP-4\*03T
- \*7 Except SP-5B00

- \*8 Except ST-6200
- \*9 Due to the COM port specifications, flow control is not possible. Omit wiring the control pins on the Display side of the cable diagram.
- \*10 When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 3A.
- \*11 Only the COM port which can communicate by RS-422/485 (4 wire) can be used.
   IPC COM Port (page 9)

NOTE	• The shield of cables connected to FX2N-485-BD, FX1N-485-BD, FX2NC-485ADP and FX3U	-
	485ADP must be D-class grounded.	

- Connect the shield of cable connected to FX0N-485ADP to the adapter FG terminal. In addition, always connect the FG terminal of FX0N-485ADP to the ground terminal of External Device body with D-class grounded.
- FX3U-485-BD, FX3U-485ADP and FX3G-485-BD have built-in termination resistance. Use the termination resistance switch to set termination resistance.

#### 3A)

• 1:1 connection



User-created cable

#### 3B)

• 1:1 connection



• 1:n connection



#### 3C)

• 1:1 connection



• 1:n connection



User-created cable

#### 3D)

• 1:1 connection



• 1:n connection



User-created cable

#### 3E)

• 1:1 connection



• 1:n connection



\*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.

DIP Switch No.	Set Value
1	ON
2	OFF
3	ON
4	OFF

#### 3F)

• 1:1 connection



• 1:n connection



#### 3G)

• 1:1 connection



• 1:n connection



Display (Connection Port)	Cable		Notes
GP3000 <sup>*1</sup> (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) GP-Rear Module (COM1) ST3000 <sup>*2</sup> (COM2) LT3000 (COM1)	4A	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	The cable length must be 500 meters or less. <sup>*3</sup>
	4B		
GP3000 <sup>*4</sup> (COM2)	4C	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	The cable length must be 500 meters or less. <sup>*3</sup>
	4D	Online adapter by Pro-face CA4-ADPONL-01 + User-created cable	
IPC <sup>*5</sup>	4E	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	The cable length must be 500 meters or less. <sup>*3</sup>
	4F	User-created cable	
GP-4106 (COM1) GP-4116T (COM1)	4G	User-created cable	The cable length must be 500 meters or less. <sup>*3</sup>
GP-4107 (COM1) GP-4*03T <sup>*6</sup> (COM2) GP-4203T (COM1)	4H	User-created cable	The cable length must be 500 meters or less. <sup>*3</sup>

Display (Connection Port)		Cable	Notes
$ \begin{array}{c cccc} GP4000^{*7} (COM2) \\ GP-4201T (COM1) \\ GP6000 (COM2) \\ SP5000^{*8} (COM1/2) \\ SP-5B00 (COM2) \\ ST6000^{*9} (COM2) \\ ST-6200 (COM1) \\ STC6000 (COM2) \\ FT6000^{*10} (COM2) \\ PS6000 (Basic Box) \\ (COM1/2) \\ \end{array}                                  $	4I	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1 <sup>*11</sup> + User-created cable	
	The cable length must be 500 meters or less. <sup>*3</sup>		
LT-4*01TM (COM1) LT-Rear Module (COM1)	4J	RJ45 RS-485 Cable (5m) by Pro-face PFXZLMCBRJR81	The cable length must be 200 meters or less.
PE-4000B <sup>*12</sup> PS5000 <sup>*12</sup> PS6000 (Optional Interface) <sup>*12</sup>	4K	User-created cable	The cable length must be 500 meters or less. <sup>*3</sup>

- \*1 All GP3000 models except AGP-3302B
- \*2 Except AST-3211A and AST-3302B
- \*3 When using FX1N-485-BD, FX2N-485-BD, FX3U-485-BD or FX3G-485-BD, the cable length must be 50 meters or less.
- \*4 All GP3000 models except GP-3200 series and AGP-3302B
- \*5 Only the COM port which can communicate by RS-422/485 (2 wire) can be used. (Except PE-4000B, PS5000, and PS6000)

IPC COM Port (page 9)

- \*6 Except GP-4203T
- \*7 All GP4000 models except GP-4100 series, GP-4\*01TM, GP-Rear Module, GP-4201T and GP-4\*03T
- \*8 Except SP-5B00
- \*9 Except ST-6200
- \*10 Due to the COM port specifications, flow control is not possible. Omit wiring the control pins on the Display side of the cable diagram.
- \*11 When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 4A.
- \*12 Only the COM port which can communicate by RS-422/485 (2 wire) can be used.
   IPC COM Port (page 9)
  - The shield of cables connected to FX2N-485-BD, FX1N-485-BD, FX2NC-485ADP and FX3U-485ADP must be D-class grounded.
    - Connect the shield of cable connected to FX0N-485ADP to the adapter FG terminal. In addition, always connect the FG terminal of FX0N-485ADP to the ground terminal of External Device body with D-class grounded.
    - FX3U-485-BD, FX3U-485ADP and FX3G-485-BD have built-in termination resistance. Use the termination resistance switch to set termination resistance.

#### 4A)

• 1:1 connection



• 1:n connection



User-created cable

#### 4B)

• 1:1 connection



• 1:n connection



#### 4C)

• 1:1 connection



• 1:n connection



User-created cable

### 4D)

• 1:1 connection



• 1:n connection



#### 4E)

• 1:1 connection



• 1:n connection



#### 4F)

• 1:1 connection



1:n connection



#### 4G)

• 1:1 connection







\*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.

DIP Switch No.	Set Value
1	OFF
2	OFF
3	ON
4	ON

#### 4H)

• 1:1 connection



• 1:n connection



#### IMPORTANT

The 5V output (Pin #6) on the Display is the power for the Siemens AG's PROFIBUS connector. Do not use it for other devices.

NOTE

• In COM on the GP-4107, the SG and FG terminals are isolated.

•

#### 4I)

• 1:1 connection



• 1:n connection



User-created cable

## 4J)

• 1:1 connection



• 1:n connection



Number	Name	Notes
(1)	RJ45 RS-485 Cable (5m) by Pro-face PFXZLMCBRJR81	

#### 4K)

• 1:1 connection



1:n connection



Display (Connection Port)	Cable		Notes
GP3000 <sup>*1</sup> (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) GP-Rear Module (COM1) ST3000 <sup>*2</sup> (COM2) LT3000 (COM1) IPC <sup>*3</sup>	5A	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	The cable length must be
	5B	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Multilink cable by Pro-face CA3-CBLMLT-01 + User-created cable	500 meters or less. <sup>*4</sup>
	5C	User-created cable	
	5D	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	
GP3000 <sup>*5</sup> (COM2)	5E	Online adapter by Pro-face CA4-ADPONL-01 + Multilink cable by Pro-face CA3-CBLMLT-01 + User-created cable Online adapter by Pro-face	The cable length must be 500 meters or less. <sup>*4</sup>
	5F	CA4-ADPONL-01 + User-created cable	
GP-4106 (COM1) GP-4116T (COM1)	5G	User-created cable	The cable length must be 500 meters or less. <sup>*4</sup>

Display (Connection Port)		Cable	Notes
GP4000 <sup>*6</sup> (COM2) GP-4201T (COM1) GP6000 (COM2) SP5000 <sup>*7</sup> (COM1/2) SP-5B00 (COM2) ST(C000 <sup>*8</sup> (COM2)	5H	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1 <sup>*10</sup> + User-created cable	
ST6000 ° (COM2) ST-6200 (COM1) STM6000 (COM1) STC6000 (COM1) ET6000 <sup>*9</sup> (COM2)	51	Multilink cable by Pro-face PFXZCBCBML1 <sup>*11</sup> + User-created cable	The cable length must be 500 meters or less. <sup>*4</sup>
PS6000 (Basic Box) (COM1/2)	5C	User-created cable	
PE-4000B <sup>*12</sup> PS5000 <sup>*12</sup> PS6000 (Optional Interface) <sup>*12</sup>	5J	User-created cable	The cable length must be 500 meters or less.*4

\*1 All GP3000 models except AGP-3302B

- \*2 Except AST-3211A and AST-3302B
- \*3 Only the COM port which can communicate by RS-422/485 (4 wire) can be used. (Except PE-4000B, PS5000, and PS6000)

IPC COM Port (page 9)

- \*4 When using FX1N-485-BD, FX2N-485-BD, FX3U-485-BD or FX3G-485-BD, the cable length must be 50 meters or less.
- \*5 All GP3000 models except GP-3200 series and AGP-3302B
- \*6 All GP4000 models except GP-4100 series, GP-4\*01TM, GP-Rear Module, GP-4201T and GP-4\*03T
- \*7 Except SP-5B00
- \*8 Except ST-6200
- \*9 Due to the COM port specifications, flow control is not possible. Omit wiring the control pins on the Display side of the cable diagram.
- \*10 When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 5A.
- \*11 When using a Multilink Cable (CA3-CBLMLT-01) instead of the Multilink Cable, refer to Cable Diagram 5B.
- \*12 Only the COM port which can communicate by RS-422/485 (4 wire) can be used.

<sup>C</sup> ■ IPC COM Port (page 9)

- The shield of cables connected to FX2N-485-BD, FX1N-485-BD, FX2NC-485ADP and FX3U-485ADP must be D-class grounded.
- Connect the shield of cable connected to FX0N-485ADP to the adapter FG terminal. In addition, always connect the FG terminal of FX0N-485ADP to the ground terminal of External Device body with D-class grounded.
- FX3U-485-BD, FX3U-485ADP and FX3G-485-BD have built-in termination resistance. Use the termination resistance switch to set termination resistance.









\*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.

DIP Switch No.	Set Value
1	ON
2	OFF
3	ON
4	OFF

For the Displays other than that used as the terminal, set the DIP Switch 1-4 on the rear of the Display to OFF in the n:1 connection.





# 6 Supported Device

Range of supported device address is shown in the table below. Please note that the actually supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your External Device.

E

Device	Bit Address	Word Address	32 bits	Notes
Input Relay	X000 - X377	X000 - X360		ост <b>8</b> *1 *2
Output Relay	Y000 - Y377	Y000 - Y360		ост <b>8</b> ] *1
Auxiliary Relay	M0000 - M7679	M0000 - M7664		
Special Auxiliary Relay	M8000 - M8511	M8000 - M8496		<u> </u>
State	S0000 - S4095	S0000 - S4080		
Timer (Contact)	TS000 - TS511			
Counter (Contact)	CS000 - CS255			
Timer (Current Value)		TN000 - TN511		
Counter (Current Value)		CN000 - CN199		*3
		CN200 - CN255		
Data Register		D0000 - D7999		Bit F
Special Data Register		D8000 - D8511	ŕ	*4 *5 *6
Extension Register		R00000 - R32767		<u>■ i t</u> <b>F</b> ] *6 *7

This address can be specified as system data area.

\*1 Specify word address only for the divisible value by 20oct. (Example: X0, X20, X40..., X360)

\*2 Writing cannot be made to the address, where Input Terminals are allocated on External Device, from Display.

- \*3 CN200 to CN255 are 32-bit length counter. Do not step over 32-bit counter to specify the counter address. For example, when you read or write more than 2 words from CN199, error messages such as "Out of range devices exist in write devices (Address: (Device Address))" or "Out of range devices exist in read devices (Address: (Device Address))" are displayed.
- \*4 D1000 to D2499 in FX1S Series and FX0N Series are file registers. You can specify the file capacity by the ladder software to access to the file register. When you access the address of the nonexistent file register, error response (error code: 06(0x06)) will be returned from External Device.
- \*5 Do not step over the special data register to specify the data register address. For example, when you read or write more than 2 words from D7999, error messages such as "Out of range devices exist in write devices (Address: (Device Address))" or "Out of range devices exist in read devices (Address: (Device Address))" are displayed.

\*6 The access method when specifying bits is different depending on the setting of "Other bits in this word" in "Individual Device Settings".

[Clear]	в	i	t	F	1
	_				

- [Do not clear]......When bits are written, the Display reads the corresponding word address from the External Device, sets particular bits of that word address to ON, and then returns the resulting address to the External Device. Note that the data may not be written correctly if you write to the word address using the ladder program while the Display is reading data from, and writing data to, the External Device.
- \*7 Supported only by FX3UC, FX3U, FX3G and FX3GC.

NOTE	•	Please refer to the GP-Pro EX Reference Manual for system data area.
	•	Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)" Please refer to the precautions on manual notation for icons in the table.
		"Manual Symbols and Terminology"

# 7 Device Code and Address Code

Use device code and address code when you select "Device Type & Address" for the address type in data displays.

Device	Device Name	Device Code (HEX)	Address Code
Input Relay	Х	0080	Value of word address divided by 0x10
Output Relay	Y	0081	Value of word address divided by 0x10
Auxiliary Relay	М	0082	Value of word address divided by 16
Special Auxiliary Relay	М	0083	Value of word address divided by 16
State	S	0087	Value of word address divided by 16
Timer (Current Value)	TN	0060	Word Address
Counter (Current Value) [CN000 - CN199]	CN	0061	Word Address
Counter (Current Value) [CN200 - CN255]	CN	0064	Word Address
Data Register	D	0000	Word Address
Special Data Register	D	0001	Word Address
Extension Register	R	000F	Word Address

# 8 Error Messages

Error messages are displayed on the screen of Display as follows: "No. :Device Name:Error Message(Error Occurrence Area)". Each description is shown below.

Item	Description	
No.	Error No.	
Device Name	Name of External Device where error occurs.Device name is a title of External Device set with GP-Pro EX.(Initial value [PLC1])	
Error Message Displays messages related to the error which occurs.		
	Displays IP address or device address of External Device where error occurs, or error codes received from External Device.	
Error Occurrence Area	<ul> <li>NOTE</li> <li>IP address is displayed such as "IP address(Decimal): MAC address( Hex)".</li> <li>Device address is diplayed such as "Address: Device address".</li> <li>Received error codes are displayed such as "Decimal[Hex]".</li> </ul>	

Display Examples of Error Messages

"RHAA035:PLC1:Error has been responded for device write command (Error Code:2 [02H])"

NOTE
Refer to your External Device manual for details on received error codes.
Refer to "Display-related errors" in "Maintenance/Troubleshooting Guide" for details on the error messages common to the driver.