GE Fanuc Automation

Series 90-30/70 SNP-X Driver

1	System Configuration	
2	Selection of External Device	6
3	Example of Communication Setting	7
4	Setup Items	17
5	Cable Diagram	22
6	Supported Device	
7	Device Code and Address Code	
8	Error Messages	

Introduction

This manual describes how to connect the Display and the External Device (target PLC).

In this manual, the connection procedure will be described by following the below sections:

1	System Configuration This section shows the types of External Devices which can be connected and SIO type.	"1 System Configuration" (page 3)
2	Selection of External Device Select a model (series) of the External Device to be connected and connection method.	"2 Selection of External Device" (page 6)
3	Example of Communication Settings This section shows setting examples for communicating between the Display and the External Device.	"3 Example of Communication Setting" (page 7)
4	Setup Items This section describes communication setup items on the Display. Set communication settings of the Display with GP-Pro Ex or in off-line mode.	উি "4 Setup Items" (page 17)
5	Cable Diagram This section shows cables and adapters for connecting the Display and the External Device.	ি "5 Cable Diagram" (page 22)
	Operation	

1 System Configuration

The system configuration in the case when the External Device of GE Fanuc Automation and the Display are connected is shown.

Series	s CPU Link I/F		SIO Type	Setting Example	Cable Diagram
	IC693CPU311 IC693CPU313 IC693CPU321 IC693CPU323 IC693CPU331 IC693CPU340 IC693CPU340 IC693CPU350 IC693CPU360 IC693CPU364	Connector on power supply (Built-in Serial Port)	RS485 (4 wire)	Setting Example 1 (page 7)	Cable Diagram 1 (page 24)
		IC693CMM311 ^{*1}	RS232	Setting Example 2 (page 9)	Cable Diagram 2 (page 29)
			RS485 (4 wire)	Setting Example 3 (page 11)	Cable Diagram 3 (page 30)
	IC693CPU351 IC693CPU352 IC693CPU363 IC693CPU374	Connector on power supply (Built-in Serial Port)	RS485 (4 wire)	Setting Example 1 (page 7)	Cable Diagram 1 (page 24)
		Port1 on CPU Unit	RS232C	Setting Example 4 (page 13)	Cable Diagram 4 (page 35)
Series 90-30		Port2 on CPU Unit	RS485 (4 wire)	Setting Example 5 (page 15)	Cable Diagram 1 (page 24)
		IC693CMM311 ^{*1}	RS232C	Setting Example 2 (page 9)	Cable Diagram 2 (page 29)
			RS485 (4 wire)	Setting Example 3 (page 11)	Cable Diagram 3 (page 30)
		Port on Power supply	RS485 (4 wire)	Setting Example 1 (page 7)	Cable Diagram 1 (page 24)
		IC693CMM311 ^{*1}	RS232C	Setting Example 2 (page 9)	Cable Diagram 2 (page 29)
			RS485 (4 wire)	Setting Example 3 (page 11)	Cable Diagram 3 (page 30)

Series	CPU	Link I/F	SIO Type	Setting Example	Cable Diagram
	IC697CPU731 IC697CPU732 IC697CPU771		RS232C	Setting Example 2 (page 9)	Cable Diagram 2 (page 29)
Series 90-70	IC697CPU772 IC697CPU781 IC697CPU782 IC697CPU788 IC697CPU789 IC697CPM790 IC697CPM914 IC697CPM915 IC697CPM924 IC697CPM925 IC697CPX722 IC697CPX782 IC697CPX782 IC697CPX928 IC697CPX935 IC697CGR772 IC697CGR772 IC697CGR935	IC697CMM711 ^{*2}	RS485 (4 wire)	Setting Example 3 (page 11)	Cable Diagram 3 (page 30)
VersaMax Micro	IC200UAL004/005/006 IC200UDD110/120/212 IC200UDR005/006/010 IC200UAA007 IC200UAR028	Port1 on CPU Unit	RS232C	Setting Example 4 (page 13)	Cable Diagram 5 (page 36)
		Port2 on CPU Unit	RS485 (4 wire)	Setting Example 5 (page 15)	Cable Diagram 1 (page 24)

*1 Select SNP-X protocol using the programming console, and the PLC's WYE cable is necessary. Both Port1 and Port2 can be used as RS-232C connection, and only Port2 can be used as RS-485 connection. When Port2 is used, programming console is needed to select RS-232C or RS-485 connection.

*2 Select SNP-X protocol using the programming console, and change the interface of Port1/Port2 to RS-232C or RS-485.

Connection Configuration

• 1:1 Connection



• 1:n Connection



2 Selection of External Device

Select the External Device to be connected to the Display.

ð	💰 New Project File 🛛 🔀					
	-Device/PL	C	1			
	Maker	GE Fanuc Automation				
	Driver	Series 90-30/70 SNP-X				
	🗖 Use S	ystem Area Refer to the manual of this Device/PLC				
	-Connection	Method	1			
	Port	COM1				
		Go to Device/PLU Manual				
	Back	Communication Detail Settings New Screen Cancel				

Setup Items	Setup Description	
Maker	Select the maker of the External Device to be connected. Select "GE Fanuc Automation".	
Driver	Select a model (series) of the External Device to be connected and connection method. Select "Series 90-30/70 SNP-X". Check the External Device which can be connected in "Series 90-30/70 SNP-X" in system configuration. I System Configuration" (page 3)	
Use System Area	 Check this option when you synchronize the system data area of Display and the device (memory) of External Device. When synchronized, you can use the ladder program of External Device to switch the display or display the window on the display. Cf. GP-Pro EX Reference Manual "Appendix 1.4 LS Area (only for direct access method)" This can be also set with GP-Pro EX or in off-line mode of Display. Cf. GP-Pro EX Reference Manual " 5.14.6 Setting Guide of [System Setting Window]■[Main Unit Settings] Settings Guide ♦ System Area Setting" Cf. Maintenance/Troubleshooting "2.14.1 Settings common to all Display models ♦ System Area Settings" 	
Port	Select the Display port to be connected to the External Device.	

3 Example of Communication Setting

Examples of communication settings of the Display and the External Device, recommended by Pro-face, are shown.

3.1 Setting Example 1

Settings of GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC1	
Summary Change Device/PLC	
Maker GE Fanuc Automation Driver Series 90-30/70 SNP-X Port COM1	ĺ
Text Data Mode 1 Change	
Communication Settings	
SID Type C RS232C C RS422/485(2wire) 💿 RS422/485(4wire)	
Speed 19200	
Data Length C 7 © 8	
Parity C NONE C EVEN © ODD	
Stop Bit	
Flow Control O NONE O ER(DTR/CTS) O XON/XOFF	
Timeout 3 😴 (sec)	
Retry 2	
Wait To Send 0 👘 (ms)	
RI / VCC C RI C VCC	
In the case of RS232C, you can select the 9th pin to RI (Input) or VCC (5V Power Supply). If you use the Digital's RS232C Isolation Unit, please select it to VCC.	
Device-Specific Settings	
Allowable No. of Device/PLCs 16 Unit(s)	
No. Device Name Settings Image: Settings Image: Settings	

Device Setting

To display the setting screen, click III ([Setting]) of External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

When you connect multiple External Device, click if from [Device-Specific Settings] of [Device/PLC Settings] to add another External Device.

💰 Individual Dev	ice Setti 🗙
PLC1	
SNP ID 1	
	Default
OK (<u>D)</u>	Cancel

Settings of External Device

Use the ladder software for communication settings. (Check the operation in CIMPLICITY Machine Edition V4.50)

- 1 Select "Add Target" -> "GE Fanue PLC" among "Project" of tool bar and select the series to be connected. The selected series is added as "Target" in the project.
- 2 Allocate the power supply module and the CPU module in "Hardware Configuration" -> "Main Rack" of added Target.

NOTE • The Rack number and Slot number to allocate by environment using are different. Check the environment, and allocate the Rack number and Slot number.

- **3** Double-click the CPU module, display the setting window.
- **4** Click the [Settings] tab and set the communication settings.
- 5 Forward the communication settings to the external device and spend a power supply of the external device again.

Setup Items

Setup Items	Setup Description
Data Rate [bps]	19200
Parity	Odd
Stop Bits	1
SNP ID	1

Notes

• Please refer to the manual of the ladder software for more detail on other setting description.

3.2 Setting Example 2

Settings of GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Devid	æ/PLC 1		
Sum	mary		Change Device/PLC
	Maker GE Fanuc A	utomation	Driver Series 90-30/70 SNP-X Port COM1
	Text Data Mode	1 <u>Change</u>	
Com	munication Settings		
	SIO Type	RS232C	C RS422/485(2wire) C RS422/485(4wire)
	Speed	19200	T
	Data Length	07	© 8
	Parity	C NONE	C EVEN © ODD
	Stop Bit	⊙ 1	O 2
	Flow Control	NONE	C ER(DTR/CTS) C XON/XOFF
	Timeout	3 🔅 (*	(sec)
	Retry	2 🔅	
	Wait To Send	0 🕂 ((ms)
Γ	BLAVCC	• BI	C VCC
	In the case of RS23	32C, you can selec	ct the 9th pin to RI (Input)
	or VCC (5V Power 3 Isolation Unit, pleas	Supply). If you use e select it to VCC.	e the Digital's RS232C
Dev	ice-Specific Settings Allowable No. of Devi	ice/PLCs_16.Unit(10 m#
	No. Device Nar	ne	Settings
	👗 1 PLC1		INP ID=1

Device Setting

To display the setting screen, click I ([Setting]) of External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

When you connect multiple External Device, click if from [Device-Specific Settings] of [Device/PLC Settings] to add another External Device.

💰 Individual Devi	ce Setti 🗙
PLC1	
SNP ID 1	
	Default
OK (<u>D)</u>	Cancel

Settings of External Device

Use the ladder software for communication settings. (Check the operation in CIMPLICITY Machine Edition V4.50)

- 1 Select "Add Target" -> "GE Fanuc PLC" among "Project" of tool bar and select the series to be connected. The selected series is added as "Target" in the project.
- 2 Allocate the power supply module, the CPU module and the link I/F module in "Hardware Configuration" -> "Main Rack" of added Target.

NOTE • The Rack number and Slot number to allocate by environment using are different. Check the environment, and allocate the Rack number and Slot number.

- **3** Double-click the CPU module and the link I/F module, display the setting window.
- **4** Set the communication settings.
- 5 Forward the communication settings to the external device and spend a power supply of the external device again.

♦ Setup Items

• CPU module

[Settings] tab

Setup Items	Setup Description	
SNP ID	1	

Link I/F module

[Settings] tab

Setup Items	Setup Description
Configuration Mode	SNP Only

[Port1] tab

Setup Items	Setup Description
SNP Enable	Yes
SNP Mode	Slave
Data Rate [bps]	19200
Parity	Odd
Stop Bits	1
Flow Contro	None

Notes

Please refer to the manual of the ladder software for more detail on other setting description.

3.3 Setting Example 3

Settings of GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC 1			
Summary			Change Device/PLC
Maker GE Fanue /	Automation	Driver Series 90-30/70 SNP-X	Port COM1
Text Data Mode	1 <u>Change</u>		
Communication Settings			
SIO Type	O RS232C	C RS422/485(2wire)	
Speed	19200	•	
Data Length	O 7	© 8	
Parity	O NONE	○ EVEN	
Stop Bit	I	O 2	
Flow Control	NONE	O ER(DTR/CTS) O XON/XOFF	
Timeout	3 📫	(sec)	
Retry	2 🔹		
Wait To Send	0 +	(ms)	
RI / VCC	💿 BI	O VCC	
In the case of RS: or VCC (5V Power Isolation Unit, plea	232C, you can sele r Supply). If you us ise select it to VCC	et the 9th pin to BI (Input) e the Digital's RS232C . Default]
Device-Specific Settings			
Allowable No. of De	vice/PLCs 16 Uni	t(s)	
No. Device N.	ame	SNP ID=1	

Device Setting

To display the setting screen, click I ([Setting]) of External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

When you connect multiple External Device, click if from [Device-Specific Settings] of [Device/PLC Settings] to add another External Device.

💣 Individual Devi	ice Setti 🗙
PLC1	
SNP ID 1	
	Default
OK (<u>0)</u>	Cancel

Settings of External Device

Use the ladder software for communication settings. (Check the operation in CIMPLICITY Machine Edition V4.50)

- 1 Select "Add Target" -> "GE Fanuc PLC" among "Project" of tool bar and select the series to be connected. The selected series is added as "Target" in the project.
- 2 Allocate the power supply module, the CPU module and the link I/F module in "Hardware Configuration" -> "Main Rack" of added Target.

NOTE • The Rack number and Slot number to allocate by environment using are different. Check the environment, and allocate the Rack number and Slot number.

- **3** Double-click the CPU module and the link I/F module, display the setting window.
- **4** Set the communication settings.
- 5 Forward the communication settings to the external device and spend a power supply of the external device again.

♦ Setup Items

• CPU module

[Settings] tab

Setup Items	Setup Description
SNP ID	1

• Link I/F module

[Settings] tab

Setup Items	Setup Description
Configuration Mode	SNP Only

[Port1] tab

Setup Items	Setup Description
SNP Enable	Yes
SNP Mode	Slave
Interface	RS485
Data Rate [bps]	19200
Parity	Odd
Stop Bits	1
Flow Contro	None

Notes

Please refer to the manual of the ladder software for more detail on other setting description.

3.4 Setting Example 4

- Settings of GP-Pro EX
- Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC1		
Summary Change Device/PLC		
Maker GE Fanuc Automation Driver Series 90-30/70 SNP-X Port COM1		
Text Data Mode 1 Change		
Communication Settings		
SIO Type 💿 RS232C 🔿 RS422/485(2wire) 🔿 RS422/485(4wire)		
Speed 19200		
Data Length C 7 C 8		
Parity C NONE C EVEN © ODD		
Stop Bit		
Flow Control O NONE O ER(DTR/CTS) O XON/XOFF		
Timeout 3 🚔 (sec)		
Retry 2		
Wait To Send 0 🕂 (ms)		
RI / VCC		
In the case of RS232C, you can select the 9th pin to RI (Input) or VCC (5V Power Supply) If you use the Dinital's RS232C		
Isolation Unit, please select it to VCC. Default		
Device-Specific Settings		
Allowable No. of Device/PLCs 16 Unit(s)		
No. Device Name Settings	_	

Device Setting

To display the setting screen, click I ([Setting]) of External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

When you connect multiple External Device, click if from [Device-Specific Settings] of [Device/PLC Settings] to add another External Device.

💣 Individual Devi	ce Setti 🗙
PLC1	
SNP ID 1	
	Default
OK (<u>0</u>)	Cancel

Settings of External Device

Use the ladder software for communication settings. (Check the operation in CIMPLICITY Machine Edition V4.50)

- 1 Select "Add Target" -> "GE Fanue PLC" among "Project" of tool bar and select the series to be connected. The selected series is added as "Target" in the project.
- 2 Allocate the power supply module and the CPU module in "Hardware Configuration" -> "Main Rack" of added Target.

NOTE • The Rack number and Slot number to allocate by environment using are different. Check the environment, and allocate the Rack number and Slot number.

- **3** Double-click the CPU module, display the setting window.
- **4** Set the communication settings.
- 5 Forward the communication settings to the external device and spend a power supply of the external device again.

Setup Items

[Port1 (RS-232)] tab

Setup Items	Setup Description
Port Mode	SNP
Port Type	Slave
Data Rate [bps]	19200
Parity	Odd
Stop Bits	1
SNP ID	1

Notes

Please refer to the manual of the ladder software for more detail on other setting description.

3.5 Setting Example 5

- Settings of GP-Pro EX
- Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC 1		
Summary		Change Device/PLC
Maker GE Fanuc	Automation	Driver Series 90-30/70 SNP-X Port COM1
Text Data Mode	1 <u>Change</u>	
Communication Settings		
SIO Type	C RS232C	O RS422/485(2wire)
Speed	19200	
Data Length	O 7	© 8
Parity	O NONE	O EVEN O ODD
Stop Bit	⊙ 1	© 2
Flow Control	NONE	C ER(DTR/CTS) C XON/XOFF
Timeout	3 📫	(sec)
Retry	2	
Wait To Send	0 ÷	(ms)
RI / VCC	© BI	O VCC
In the case of RS	232C, you can sele	ect the 9th pin to RI (Input)
Isolation Unit, ple	ase select it to VCC	C. Default
Device-Specific Setting:	\$	
Allowable No. of D	evice/PLCs 16 Uni	iit(s) 📊
No. Device N	lame	Settings

Device Setting

To display the setting screen, click I ([Setting]) of External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

When you connect multiple External Device, click if from [Device-Specific Settings] of [Device/PLC Settings] to add another External Device.

💣 Individual Devi	ce Setti 🗙
PLC1	
SNP ID 1	
	Default
OK (<u>0</u>)	Cancel

Settings of External Device

Use the ladder software for communication settings. (Check the operation in CIMPLICITY Machine Edition V4.50)

- 1 Select "Add Target" -> "GE Fanue PLC" among "Project" of tool bar and select the series to be connected. The selected series is added as "Target" in the project.
- 2 Allocate the power supply module and the CPU module in "Hardware Configuration" -> "Main Rack" of added Target.

NOTE • The Rack number and Slot number to allocate by environment using are different. Check the environment, and allocate the Rack number and Slot number.

- **3** Double-click the CPU module, display the setting window.
- **4** Set the communication settings.
- 5 Forward the communication settings to the external device and spend a power supply of the external device again.

Setup Items

[Port1 (RS-232)] tab

Setup Items	Setup Description
Port Mode	SNP
Port Type	Slave
Data Rate [bps]	19200
Parity	Odd
Stop Bits	1
SNP ID	1

Notes

Please refer to the manual of the ladder software for more detail on other setting description.

4 Setup Items

Set communication settings of the Display with GP-Pro EX or in off-line mode of the Display. The setting of each parameter must be identical to that of External Device.

"3 Example of Communication Setting" (page 7)

4.1 Setup Items in GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC	1		
Summary			Change Device/PLC
Make	GE Fanue A	utomation	Driver Series 90-30/70 SNP-X Port COM1
Text [)ata Mode	1 <u>Change</u>	
Communica	ation Settings		
SIO T	уре	RS232C	C RS422/485(2wire) C RS422/485(4wire)
Speed	i .	19200	T
Data I	.ength	O 7	© 8
Parity		C NONE	C EVEN © ODD
Stop F	3 it	€ 1	© 2
Flow (Control	NONE	C ER(DTR/CTS) C XON/XOFF
Timeo	ut	3 📫 ((sec)
Retry		2 🔹	
Wait 1	o Send	0 🕂 ((ms)
BL/ V	СС	• BI	© VCC
In th	e case of RS23	32C, you can selec	ect the 9th pin to RI (Input)
Isola	ition Unit, pleas	e select it to VCC.	Default
Device-Sp	ecific Settings		
Allowa	able No. of Devi	ice/PLCs_16 Unit	it(s) 💵
N N	lo. Device Nar 1 PLC1	me	SNP ID=1
			

Setup Items	Setup Description
SIO Type	Select the SIO type to communicate with the External Device.
Speed	Select speed between the External Device and the Display.
Data Length	Display data length.
Parity	Select how to check parity.
Stop Bit	Select stop bit length.
Flow Control	Select the communication control method to prevent overflow of transmission and reception data.
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.

Setup Items	Setup Description
Wait To Send	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands.
RI/VCC	You can switch RI/VCC of the 9th pin when you select RS232C for SIO type

Device Setting

To display the setting screen, click I ([Setting]) of External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

When you connect multiple External Device, click if from [Device-Specific Settings] of [Device/PLC Settings] to add another External Device.

💰 Individual Dev	vice Setti 🗙
PLC1	
SNP ID 1	
	Default
OK (<u>0)</u>	Cancel

Setup Items	Setup Description
SNP ID	Set the SNP ID of the External Device. SNP ID can contain up to 7 characters, the valid characters should be '0' - '9', 'A' - 'Z', 'a' - 'z', ' $\dot{-}$.

4.2 Setup Items in Off-Line Mode

NOTE

 Please refer to Maintenance/Troubleshooting for more information on how to enter off-line mode or about operation.
 Cf. Maintenance/Troubleshooting "2.2 Offline Mode"

Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings] in off-line mode. Touch the External Device you want to set from the displayed list.

Comm.	Device	Option	-	
Series 90-30/70	SNP-X		[COM1]	Page 1/1
	SIO Type Speed Data Length Parity Stop Bit Flow Control Timeout(s) Retry Wait To Send(ms)	RS232C 19200 8 • 1 NONE	EVEN 2 3 2 2 4	• ODD
	Exit		Back	2006/04/25 10:38:37

Setup Items	Setup Description
SIO Type	Select the SIO type to communicate with the External Device.
Speed	Select speed between the External Device and the Display.
Data Length	Display data length.
Parity	Select how to check parity.
Stop Bit	Select stop bit length.
Flow Control	Select the communication control method to prevent overflow of transmission and reception data.
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.
Wait To Send	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands.

♦ Device Setting

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Device]..

Comm.	Device	Option	-	
Series 90-30/70	SNP-X		[COM1]	Page 1/1
Devic	e/PLC Name PL	01		•
	CND ID	1		
	SWF ID		- 10 A	
	SNP ID can the valid c	contain up to 7 haracters should	characters, be Ø-9.	
	A-Z, a-z, _	(under bar).		
-	Exit		Back	2006/04/25 10:38:40

Setup Items	Setup Description
Device/PLC Name	Select the External Device for device setting. Device name is a title of External Device set with GP-Pro EX.(Initial value [PLC1])
SNP ID	Set the SNP ID of the External Device. SNP ID can contain up to 7 characters, the valid characters should be '0' - '9', 'A' - 'Z', 'a' - 'z', ''

Option

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Option].

Series 90-30/70 SNP-X [COM1] Pag RI / VCC • RI • VCC In the case of RS232C, you can select the 9th pin to RI(Input) or VCC(5V Power Supply). If you use the Digital's	َ ۱/1
Series 90-30/70 SNP-X [COM1] Pag RI / VCC • RI • VCC In the case of RS232C, you can select the 9th pin to RI(Input) or VCC(5V Power Supply). If you use the Digital's	× 1/1
RI / VCC (• RI • VCC In the case of RS232C, you can select the 9th pin to RI(Input) or VCC(5V Power Supply).If you use the Digital's	
RS232C Isolation Unit, please select it to VCC.	
Exit Back 2006/04 10:38:	(25 13

Setup Items	Setup Description
RI/VCC	You can switch RI/VCC of the 9th pin when you select RS232C for SIO type

5 Cable Diagram

The cable diagram shown below may be different from the cable diagram recommended by Schneider Electric Industries. Please be assured there is no operational problem in applying the cable diagram shown in this manual.

- The FG pin of the External Device body must be D-class grounded. Please refer to the manual of the External Device for more details.
- SG and FG are connected inside the Display. When connecting SG to the External Device, design the system not to form short-circuit loop.
- Connect the isolation unit, when communication is not stabilized under the influence of a noise etc..
- When connecting IPC with External Device by RS-232C, the COM port which can be used changes with series. Please refer to the manual of IPC for details.

Usable port

Series	Usable port
PS-2000B	COM1 ^{*1} , COM2, COM3 ^{*1} , COM4
PS-3650A, PS-3651A	COM1 ^{*1}
PS-3700A (Pentium®4-M)	COM1 ^{*1} , COM2 ^{*1} , COM3 ^{*2} , COM4

*1 The RI/5V can be switched. Please switch with the change switch of IPC.

- *2 It is necessary to set up the SIO type with the Dip switch.
- When connecting to the COM3 of PS-3700A (Pentium®4-M) with External Device, it is necessary to set up the SIO type of COM3 with a Dip switch. Please refer to the manual of PS-3700A (Pentium®4-M) for details.

Dip switch	Setting	Description
1	OFF	Reserve (always OFF)
2	OFF	SIO type of COM3: RS-232C
3	OFF	510 type of COINS. R5-252C
4	OFF	Output mode of TX data: Always output
5	OFF	Terminal resistance insertion to TX (220Ω): None
6	OFF	Terminal resistance insertion to RX (220Ω): None
7	OFF	Short-circuit of TXA and RXA: Does not Exist
8	OFF	Short-circuit of TXB and RXB: Does not Exist
9	OFF	Auto Detection: Disable
10	OFF	

Dip switch setting: RS-232C

Dip switch Setting Description Reserve (always OFF) 1 OFF 2 ON SIO type of COM3: RS-422/485 3 ON 4 OFF Output mode of TX data: Always output 5 OFF Terminal resistance insertion to TX (220 Ω): None 6 OFF Terminal resistance insertion to RX (220 Ω): None 7 OFF Short-circuit of TXA and RXA: Does not Exist 8 OFF Short-circuit of TXB and RXB: Does not Exist 9 OFF Auto Detection: Disable 10 OFF

Dip switch setting: RS-422/485 (4 wire)

Cable Diagram 1

Display (Connection Port)	Cable	Notes
GP ^{*1} (COM1) AGP-3302B (COM2) IPC ^{*2} (COM3)	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + Your own cable	
	3 Your own cable	
GP ^{*3} (COM2)	C Online adapter by Pro-face CA4-ADPONL-01 + Terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + Your own cable	The cable length must be 15m or less.
	Online adapter by Pro-face CA4-ADPONL-01 + Your own cable	

*1 All GP models except AGP-3302B

*2 Only COM3 of PS -3700A (Pentium®4-M) can be used. When use the COM3, set the SIO type of COM3 with Dip switch.

^CDip switch setting: RS-422/485 (4 wire) (page 23)

*3 All GP models except GP-3200 series and AGP-3302B

- A) When using the COM port conversion adapter (CA3-ADPCOM-01), the terminal block conversion adapter (CA3-ADPTRM-01) by Pro-face and your own cable
- 1:1 Connection



• 1:n Connection



- Your own cable
- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device.
 Please refer to the manual of the external device.
 In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Insert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

B) When using your own cable

1:1 Connection





- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device. Please refer to the manual of the external device. In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Insert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA - RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

- C) When using the online adapter (CA4-ADPONL-01), the terminal block conversion adapter (CA3-ADPTRM-01) by Pro-face and your own cable
- 1:1 Connection



• 1:n Connection



Your own cable

- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device.
 Please refer to the manual of the external device.
 In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Insert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

- D) When using the online adapter (CA4-ADPONL-01) by Pro-face and your own cable
- 1:1 Connection



• 1:n Connection



- Your own cable
- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device.
 Please refer to the manual of the external device.
 In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Insert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

Cable Diagram 2

Display (Connection Port)	Cable	Notes
GP (COM1) IPC ^{*1*2}	Your own cable	The cable length must be 15m or less.

*1 Usable ports are different by the series.

*2 When use the COM3 of PS-3700A (Pentium®4-M), set the SIO type of COM3 with Dip switch. © Dip switch setting: RS-232C (page 22)

When using your own cable

	Display D-Sub 9pin (Socket)		t)	External Device D-Sub 25pin (Plug)	
	Pin	Signal name	Shield	Pin	Signal name
	2	RD(RXD)	< <u> </u>	2	TD
Diaplay	3	SD(TXD)		3	RD
	4	ER(DTR)		4	RTS
	5	SG	L•	5	CTS
	6	DR(DSR)		7	SG
	7	RS(RTS)		8	DCD
	8	CS(CTS)	↓ ↓ ↓	20	DTR
	Shell	FG		1	Shield

Cable Diagram 3

Display (Connection Port)	Cable	Notes
GP ^{*1} (COM1) AGP-3302B (COM2) IPC ^{*2} (COM3)	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + A Terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + Your own cable	
	B Your own cable	
GP*3 (COM2)	C Online adapter by Pro-face CA4-ADPONL-01 + Terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + Your own cable Online adapter by Pro-face	The cable length must be 1000m or less.
	D CA4-ADPONL-01 + Your own cable	

*1 All GP models except AGP-3302B

*2 Only COM3 of PS -3700A (Pentium®4-M) can be used. When use the COM3, set the SIO type of COM3 with Dip switch.

^CDip switch setting: RS-422/485 (4 wire) (page 23)

*3 All GP models except GP-3200 series and AGP-3302B

- A) When using the COM port conversion adapter (CA3-ADPCOM-01), the terminal block conversion adapter (CA3-ADPTRM-01) by Pro-face and your own cable
- 1:1 Connection



Tourowirc

• 1:n Connection



- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device.
 Please refer to the manual of the external device.
 In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Iinsert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA - RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side. But termination resistance is inserted in CPU731 and CPU771 by connecting the 9th pin to the 11th pin.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

B) When using your own cable

• 1:1 Connection



1:n Connection



- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device.
 Please refer to the manual of the external device.
 In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Iinsert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA - RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side. But termination resistance is inserted in CPU731 and CPU771 by connecting the 9th pin to the 11th pin.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

- C) When using the online adapter (CA4-ADPONL-01), the terminal block conversion adapter (CA3-ADPTRM-01) by Pro-face and your own cable
- 1:1 Connection



1:n Connection



Your own cable

- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device. Please refer to the manual of the external device. In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Insert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA - RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side. But termination resistance is inserted in CPU731 and CPU771 by connecting the 9th pin to the 11th pin.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

- D) When using the online adapter (CA4-ADPONL-01) by Pro-face and your own cable
- 1:1 Connection







- *1: Notation of RD(A'), RD(B'), SD(A) and SD(B) are different by the external device.
 Please refer to the manual of the external device.
 In addition, please warn the naming of A class and B class is reversed to the display with the external device.
- *2: Iinsert the termination resistance of the external device side. The 120 Ω termination resistance is inserted between RDA - RDB by connecting the 9th pin to the 10th pin of serial interface at the external device side. But termination resistance is inserted in CPU731 and CPU771 by connecting the 9th pin to the 11th pin.
- *3: FG of the external device ground the D class grounding. In addition, FG connection to a shield line select the external device side, either display side by location environment.

Cable Diagram 4

Display (Connection Port)	Cable	Notes
GP (COM1) IPC ^{*1*2}	Your own cable	The cable length must be 15m or less.

*1 Usable ports are different by the series.

*2 When use the COM3 of PS-3700A (Pentium®4-M), set the SIO type of COM3 with Dip switch. © Dip switch setting: RS-232C (page 22)

When using your own cable



Cable Diagram 5

Display (Connection Port)	Cable	Notes
GP (COM1) IPC ^{*1*2}	Your own cable	The cable length must be 15m or less.

*1 Usable ports are different by the series.

*2 When use the COM3 of PS-3700A (Pentium®4-M), set the SIO type of COM3 with Dip switch. © Dip switch setting: RS-232C (page 22)

When using your own cable

	Display D-Sub 9pin (Socket)			External I 8pin RJ-4	Device ∙5 (Plug)
	Pin	Signal name	Shield	Pin	Signal name
	2	RD(RXD)	< <u> </u>	4	TXD
Jisplay 3 4 5 6 7 8	3	SD(TXD)		3	RXD
	4	ER(DTR)		7	+5V
	5	SG		8	GND
	6	DR(DSR)		1	RTS
	7	RS(RTS)	┝┓┊╴┊╎└╸	2	CTS
	8	CS(CTS)	┥ ┤ \/	5	DCD
Shell		FG	↓ ¥	6	DTR

This address can be specified as system data area.

6 Supported Device

Range of supported device address is shown in the table below. Please note that the actually supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your connecting equipment.

Г

Device	Bit Address	Bit Address Word Address		Notes
Discrete inputs	%I00001 - %I12288	%I00001 -% I12273		
Discrete outputs	%Q00001 - %Q12288	%Q00001 - %Q12273		
Discrete Globals	%G0001 - %G7680	%G0001 - %G7665		<u>→16+</u> 1]
Internal coils	%M00001 - %M12288	%M0001 - %M12273		
Temporary coils	%T001 - %T256	%T001 - %T241		
System status references	%S001 - %S128	%S001 - %S113		÷16+ 1 *1
	%SA001 - %SA128	%SA001 - %SA113		
	%SB001 - %SB128	%SB001 - %SB113		÷16+ 1
	%SC001 - %SC128	%SC001 - %SC113		
System register references		%R00001 - %R32640		
Analog inputs		%AI00001 - %AI32640	ľ	<u>ві t</u> 15]
Analog outputs		%AQ00001 - %AQ32640		

*1 Write disable

NOTE

• Please refer to the GP-Pro EX Reference Manual for system data area.

- Cf. GP-Pro EX Reference Manual "Appendix 1.4 LS Area (only for direct access method)"
- Please refer to the precautions on manual notation for icons in the table.

"Manual Symbols and Terminology"

7 Device Code and Address Code

Use device code and address code when you select "Device Type & Address" for the address type in data displays.

Device	Device Name	Device Code (HEX)	Address Code
Discrete inputs	%I	0080	(Word address - 1) / 16
Discrete outputs	%Q	0081	(Word address - 1) / 16
Discrete Globals	%M	0083	(Word address - 1) / 16
Internal coils	%G	0082	(Word address - 1) / 16
Temporary coils	%Т	0084	(Word address - 1) / 16
System status references	%SA	0086	(Word address - 1) / 16
	%SB	0087	(Word address - 1) / 16
	%SC	0088	(Word address - 1) / 16
	%S	0085	(Word address - 1) / 16
System register references	%R	0000	Word address - 1
Analog inputs	%AI	0001	Word address - 1
Analog outputs	%AQ	0002	Word address - 1

8 Error Messages

Error messages are displayed on the screen of Display as follows: "No. : Device Name: Error Message (Error Occurrence Area)". Each description is shown below.

Item	Description	
No.	Error No.	
Device Name	Name of External Device where error occurs. Device name is a title of External Device set with GP-Pro EX. (Initial value [PLC1])	
Error Message	Displays messages related to the error which occurs.	
	Displays IP address or device address of External Device where error occurs, or error codes received from External Device.	
Error Occurrence Area	 NOTE IP address is displayed such as "IP address (Decimal): MAC address (Hex)". Device address is displayed such as "Address: Device address". Received error codes are displayed such as "Decimal [Hex]". 	

Display Examples of Error Messages

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 2 [02H])"

NOTE
Please refer to the manual of External Device for more detail of received error codes.
Please refer to "When an error message is displayed (Error code list)" of "Maintenance/ Troubleshooting" for a common error message to the driver.

Error Code Peculiar to External Device

The error code characteristic of the external device is displayed in 2 Byte of "Major Error Status Code (1 Byte)" and "Minor Error Status Code (1 Byte)".

When received the error code from the external device, add to the below message. "Major Error Status Code" is displayed continuously "Major" and "Minor Error Status Code" is displayed continuously "Minor". For details of the error code, please refer to the manual of the external device.

Message ID	Error Message	Description
RHxx128	(Node Name): Error has been responded for initial communication command (Major:[%02Xh], Minor:[%02Xh])	Display the error message, when the error occurred by the reading demand.
RHxx129	(Node Name): Error has been responded for device read command (Major:[%02Xh], Minor:[%02Xh])	Display the error message, when the error occurred by the reading demand.
RHxx130	(Node Name): Error has been responded for device write command (Major:[%02Xh], Minor:[%02Xh])	Display the error message, when the error occurred by the write demand.
RHxx131	(Node Name): Error has been responded for device write command (Major:[%02Xh], Minor:[%02Xh] There are read only devises)	Display the error message, when write for the read only device.

The error code peculiar to the external device is as follows.