GE Fanuc Automation Inc.

# Series 90 Ethernet Driver

1	System Configuration	3
2	Selection of External Device	6
3	Example of Communication Setting	7
4	Setup Items	12
5	Supported Device	
6	Device Code and Address Code	17
7	Error Messages	

#### Introduction

This manual describes how to connect the Display and the External Device (target PLC).

In this manual, the connection procedure will be described by following the below sections:



# 1 System Configuration

The system configuration in the case when the External Device of GE Fanuc Automation and the Display are connected is shown.

Series Name	CPU	Link I/F	SIO Type	Setting Example
Series 90-30	CPU311 CPU313 CPU323 CPU331 CPU340 CPU341 CPU350 CPU351 CPU352 CPU360 CPU363 CSE311 CSE313 CSE323 CSE331 CSE340	IC693CMM321		"Setting Example 1" (page 7)
	CPU364 CPU374	Ethernet interface on CPU		"Setting Example 2" (page 9)
Series 90-70	CPU731 CPU771 CPU772 CPU780 CPU781 CPU782 CPU788 CPU789 CPM790 CPM915 CPM925 CSE784 CSE924 CSE925 CPX772 CPX782 CPX782 CPX782 CPX935 CGR772 CGR935	IC697CMM742(Type2)	Ethernet (TCP)	"Setting Example 1" (page 7)
PACSystems RX7i	CPE010 CPE020 CRE020	Ethernet interface on CPU		"Setting Example 3" (page 10)

# Connection Configuration

1:1 Connection



• 1:n Connection



• Connecting multiple Series 90-30 devices requires a V6.50 or higher CPU. Check the version of the CPU in the dialog box displayed by clicking [Online Commands]-[Show Status] from the [Target] menu of the ladder software.

n:1 Connection



n:m Connection



# 2 Selection of External Device

Select the External Device to be connected to the Display.



Setup Items	Setup Description
Maker	Select the maker of the External Device to be connected. Select "GE Fanuc Automation".
Series	Select a model (series) of the External Device to be connected and connection method. Select "Series 90 Ethernet". Check the External Device which can be connected in "Series 90 Ethernet" in system configuration.
Use System Area	<ul> <li>Check this option when you synchronize the system data area of the Display and the device (memory) of the External Device. When synchronized, you can use the ladder program of the External Device to switch the display or display the window on the Display.</li> <li>Cf. GP-Pro EXReference Manual "Appendix 1.4 LS Area (Direct Access Method)"</li> <li>This can be also set with GP-Pro EX or in off-line mode of the Display.</li> <li>Cf. GP-Pro EX Reference Manual "5.17.6 Setting Guide of [System Setting Window] Setting Guide of [Main Unit Settings]. System Area Setting"</li> </ul>
2.4	Cf. Maintenance/Troubleshooting manual "2.15.1 Common to the Display", Setting Guide of [Main Unit Settings], System Area Setting"
Port	Select the Display port to be connected to the External Device.

# 3 Example of Communication Setting

Examples of communication settings of the Display and the External Device, recommended by Digital Electronics Corp., are shown.

# 3.1 Setting Example 1

### Settings of GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings ] from [System setting window] in workspace.

Device/PLC1		
Summary		Change Device/PLC
Maker GE Fanuc Automation	Series Series 90 Ethernet	Port Ethernet (TCP)
Text Data Mode 1 <u>Change</u>		
Communication Settings		
Port No. Auto		
Timeout 3 📑 (sec)		
Retry 0		
Wait To Send 0 📑 (ms)	Default	
Device-Specific Settings		
Allowable Number of Devices/PLCs 16	WE CONTRACTOR	
Number Device Name S	Settings	
👗 1 PLC1	Series=AutoSeriesSelect,IP Address=192.168.000	).001

#### Device Setting

To display the setting screen, click I ([Setting]) of the External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

💰 Individua	I Device Settings	×
PLC1		
Series	🔽 Use AutoSelect	
	Series 90-30 🚽	
IP Address	192. 168. 0. 1	
	Default	
	OK ( <u>O)</u> Cancel	

## Settings of External Device

Use the ladder software for communication setting. (Operation confirmed using CIMPLICITY Machine Edition V4.50)

- 1. Select "GE Fanuc PLC" of "Add Target" from "Project" in the tool bar.
- 2. When the target is displayed in the project, open "Main Rack" from "Hardware Configuration" in the tree view and assign the using link I/F to the Slot.

• Rack or Slot number to be assigned varies depending on your environment. Check the environment before assignment.

- 3. Double-click the assigned link I/F to display the setting window.
- 4. Set IP Address and other items.
- 5. Download the setting in the External Device and restart the External Device.

7

#### Notes

- Check with a network administrator about IP address. Do not set the duplicate IP address.
- Set IP address on the External Device for IP address in Device-specific settings.
- You need to set IP address on the display in the off-line mode of the Display.
- Please refer to the manual of the ladder software for more detail on other setting description.

## 3.2 Setting Example 2

Settings of GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings ] from [System setting window] in workspace.

Device/PLC1		
Summary		Change Device/PLC
Maker GE Fanuc Automation	Series Series 90 Ethernet	Port Ethernet (TCP)
Text Data Mode 1 Change		
Communication Settings		
Port No. Auto		
Timeout 3 🗧 (sec)		
Retry 0 💼		
Wait To Send 🛛 🕂 (ms)	Default	
Device-Specific Settings		
Allowable Number of Devices/PLCs 16		
Number Device Name	Settings	
1 JPLC1	Series=AutoSeriesSelect,IP Address=192.168.00	0.001

#### Device Setting

To display the setting screen, click I ([Setting]) of the External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

💰 Individual	Device Settings	×
PLC1		
Series	✓ Use AutoSelect	
	Series 90-30 👻	
IP Address	192. 168. 0. 1	
	Default	
	OK (Q) Cancel	

# Settings of External Device

Use the ladder software for communication setting. (Operation confirmed using CIMPLICITY Machine Edition V4.50)

- 1. Select "GE Fanuc PLC" of "Add Target" from "Project" in the tool bar.
- 2. When the selected Series are displayed in the project, open "Main Rack" from "Hardware Configuration" in the tree view and assign the using CPU to the Slot.

**NOTE** • Rack or Slot number to be assigned varies depending on your environment. Check the environment before assignment.

- 3. Double-click the assigned CPU to display the CPU setting window.
- 4. Click the [Ethernet] tab to set IP address and other items.
- 5. Download the setting in the External Device and restart the External Device.

#### Notes

- Check with a network administrator about IP address. Do not set the duplicate IP address.
- Set IP address on the External Device for IP address in Device-specific settings.
- You need to set IP address on the display in the off-line mode of the Display.
- Please refer to the manual of the ladder software for more detail on other setting description.

## 3.3 Setting Example 3

Settings of GP-Pro EX

Communication Settings

To display the setting screen, select [Device/PLC Settings ] from [System setting window] in workspace.

Device/PLC 1		
Summary		Change Device/PLC
Maker GE Fanuc Automation	Series Series 90 Ethernet	Port Ethernet (TCP)
Text Data Mode 1 <u>Change</u>		
Communication Settings		
Port No. Auto		
Timeout 3 (sec)		
Retry 0 🛨		
Wait To Send 🛛 🕂 (ms)	Default	
Device-Specific Settings		
Allowable Number of Devices/PLCs 16	Ref.	
Number Device Name	Settings Series-AutoSeriesSelect IP Address=192,168,00	0.001
	In Jouriss-Autopenesseneet, in Autopeness-Top. Tob. of	50.001

#### Device Setting

To display the setting screen, click I ([Setting]) of the External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

💰 Individual	Device Settings	×
PLC1		
Series	☑ Use AutoSelect	
	Series 90-30 👻	
IP Address	192. 168. 0. 1	
	Default	
	OK ( <u>D)</u> Cancel	

## Settings of External Device

Use the ladder software for communication settings. (Operation confirmed using CIMPLICITY Machine Edition V4.50)

Confirm the MAC address of the External Device before setting. You can find the MAC address in [BATTERY ACCESS] on the front of the External Device.

- 1. Start the ladder software and create a new file.
- 2. Right-click [Target] in the tree view, and then select [Offline Commands]-[Set Temporary IP Address] from the menu that appears.
- 3. Enter the MAC address and IP address of the CPU in [MAC Address] and [IP Address to Set], respectively.
- 4. Click [Set IP] to write the configuration into the External Device. This completes the IP address settings. Go on to the port settings.
- 5. Select [Target] in the tree view to display the configuration list.
- 6. Select "ETHERNET" from [Physical Port].
- 7. Download the above configuration to the External Device.
- Notes
  - Check with a network administrator about IP address. Do not set the duplicate IP address.
  - Set IP address on the External Device for IP address in Device-specific settings.

- You need to set IP address on the display in the off-line mode of the Display.
- Please refer to the manual of the ladder software for details on other settings.

# 4 Setup Items

Set communication settings of the display with GP-Pro Ex or in off-line mode of the Display.

The setting of each parameter must be identical to that of External Device.

"3 Example of Communication Setting" (page 7)

**NOTE** • Set the Display's IP address in off-line mode.

Cf. Maintenance/Troubleshooting Manual "2.5 Ethernet Settings"

# 4.1 Setup Items in GP-Pro EX

## Communication Settings

To display the setting screen, select [Device/PLC Settings] from [System setting window] in workspace.

Device/PLC1		
Summary		Change Device/PLC
Maker GE Fanue Automation	Series Series 90 Ethernet	Port Ethernet (TCP)
Text Data Mode 1 <u>Change</u>		
Communication Settings		
Port No.		
Timeout 3 📑 (sec)		
Retry 0		
Wait To Send 🛛 📑 (ms)	Default	
Device-Specific Settings		
Allowable Number of Devices/PLCs 16		
Number Device Name	Settings	
1 PLC1	Series=AutoSeriesSelect,IP Address=192.168.00	0.001

Setup Items	Setup Description
Port No.	Assign the port No. of the External Device automatically.
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.
Wait To Send	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands.

# Device Setting

To display the setting screen, click I ([Setting]) of the External Device you want to set from [Device-Specific Settings] of [Device/PLC Settings].

When connecting multiple External Devices, you can click if from [Device-Specific Settings] of [Device/PLC Settings] to add the External Device which is available to set.

💰 Individual	Device Settings	×
PLC1		
Series	🔽 Use AutoSelect	
	Series 90-30 👻	
IP Address	192. 168. 0. 1	
	Default	
	OK ( <u>0)</u> Cancel	

Setup Items	Setup Description			
Series	To let the system automatically detect the series of the External Device, check [Use AutoSelect]. To set the series manually, clear [Use AutoSelect] and then select the series from the pull-down menu.			
IP Address	<ul> <li>Set IP address of the External Device.</li> <li><b>NOTE</b></li> <li>Check with a network administrator about IP address. Do not set the duplicate IP address.</li> </ul>			

# 4.2 Settings in Off-Line Mode

NOTE

• Refer to the Maintenance/Troubleshooting manual for information on how to enter off-line mode or about the operation.

Cf. Maintenance/Troubleshooting Manual "2.2 Off-line Mode"

## Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Equipment Settings] in off-line mode. Touch the External Device you want to set from the displayed list.

Comm.	Device				
Series 90 Ether	net			[TCP]	Page 1/1
	Port No.	Auto			
	Timeout(s)		_	3 🔻 🔺	<b>`</b>
	Retry		_	0 🔻 🔺	
	Wait To Send(ms)		_	0 🔻 🔺	
	Exit			Back	2006/01/17 17:20:24

Setup Items	Setup Description		
Port No.	Assign the port No. of the External Device automatically.		
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the display waits for the response from the External Device.		
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.		
Wait To Send	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands.		

# Device Setting

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Equipment Settings]. Touch the External Device you want to set from the displayed list, and touch [Device Settings].

Comm.	Device			
Series 90 Ether	net		[TCP]	Page 1/1
Devic	e/PLC Name PL	01		
	Series	AutoSerie	sSelect	
	IP Address	192 168	0 1	
	Exit		Back	2007/07/20 15:39:59

Setup Items	Setup Description
Device/PLC name	Select the External Device to set. Device name is a title of the External Device set with GP- Pro EX. (Default value [PLC1])
Series	Displays the series of the External Device. Use GP-Pro EX to set the series.
IP Address	<ul> <li>Set IP address of the External Device.</li> <li><b>NOTE</b></li> <li>Check with a network administrator about IP address. Do not set the duplicate IP address.</li> </ul>

# 5 Supported Device

Range of supported device address is shown in the table below. Please note that the actually supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your External Device.

This address can be specified as system data area.

Device	Bit Address	Word Address	32 bit	Remarks
Input Relay(%I)	%I00001-%I32768	%I00001-%I32753		÷16+ 1
Output Relay(%Q)	%Q00001-%Q32768	%Q00001-%Q32753		÷16+
Global Relay(%G)	%G00001-%G07680	%G00001-%G07665		÷16+
Internal Relay(%M)	%M00001-%M32768	%M00001-%M32753		÷16+
Temporary Relay(%T)	%T00001-%T01024	%T00001-%T01009		÷16+
System Status Relay(%S)	%S00001-%S00128	%S00001-%S00113		*1 +1B+
System Status Relay(%SA)	%SA00001-%SA00128	%SA00001-%SA00113	rL/Hj	÷16+ <b>1</b> ]
System Status Relay(%SB)	%SB00001-%SB00128	%SB00001-%SB00113		÷16+
System Status Relay(%SC)	%SC00001-%SC00128	%SC00001-%SC00113		÷16+ <b>1</b>
Register(%R)	-	%R00001-%R32640		<sub>в і 1</sub> 5
Analog Input(%AI)	-	%AI00001-%AI32640		<sub>ві</sub> <b>15</b> ]
Analog Output(%AQ)	-	%AQ00001-%AQ32640		<sub>ві</sub> <b>15</b> ]
Word(%W) <sup>*2</sup>	-	% W00000001- % W05224448		<u>ві t<b>15</b></u> ]

\*1 Write disable

\*2 Available to use only in RX7i.

NOTE

• Please refer to the GP-Pro EX Reference Manual for system data area.

Cf. GP-Pro EX Reference Manual "Appendix 1.4 LS Area (Direct Access Method)"

• Please refer to the precautions on manual notation for icons in the table.

"Manual Symbols and Terminology"

# 6 Device Code and Address Code

Use device code and address code when you select "Device Type & Address" for the address type in data displays.

Device	Device Name	Device Code (HEX)	Address Code
Input Relay	% I	0080	(Word Address - 1)/16
Output Relay	%Q	0081	(Word Address - 1)/16
Global Relay	%G	0082	(Word Address - 1)/16
Internal Relay	%M	0083	(Word Address - 1)/16
Temporary Relay	%T	0084	(Word Address - 1)/16
	% S	0085	(Word Address - 1)/16
System Status Polov	%SA	0086	(Word Address - 1)/16
System Status Relay	%SB	0087	(Word Address - 1)/16
	%SC	0088	(Word Address - 1)/16
Register	%R	0000	Word Address - 1
Analog Input	%AI	0001	Word Address - 1
Analog Output	%AQ	0002	Word Address - 1
Word <sup>*1</sup>	% W	0010	Word Address - 1

\*1 Available to use only in RX7i.

# 7 Error Messages

Error messages are displayed on the screen of the Display as follows: "No:Device Name:Error Message:Error Occurrence Area:". Each description is shown below.

Item	Description			
No.	Error No.			
Device Name	Name of the External Device where error occurs. Name of External Device is a title of External Device set with GP-Pro EX.(Initial value[PLC1])			
Error Message	Displays messages related to the error which occurred.			
	Displays IP address or device address of External Device where error occurs, or error codes received from External Device.			
Error Occurrence Area	<ul> <li>NOTE</li> <li>IP address is displayed such as "IP address(Decimal): MAC address( Hex)".</li> <li>Device address is displayed such as "Address: Device addressî.</li> <li>Received error codes are displayed such as "Decimal[Hex]".</li> </ul>			

#### Display Examples of Error Messages

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 2[02H])"

**NOTE** • Refer to your External Device manual for details on received error codes.

• Refer to "When an error is displayed (Error Code List)" in "Maintenance/Troubleshooting Manual" for details on the error messages common to the driver.

## Driver-Specific Error Messages

Driver-specific error code is displayed in 2 Bytes; "Major Error Status Code(1 Byte)" and "Minor Error Status Code(1 Byte)". When receiving the error code from the External Device, added to the following message, "Major Error Status Code" followed by "Major" and followed by "Minor" are displayed. Please refer to the manual of the External Device for more detail on error codes.

MessageID	Error Message	Description
RHxx130	(Device name): Error has been responded for device read command(Major: [Hex], Minor: [Hex])	Displayed when error occurs by device read command.
RHxx131	(Device name): Error has been responded for device write command(Major: [Hex], Minor: [Hex])	Displayed when error occurs by device write command.
RHxx145	(Device name): Unsupported devices exist in read devices	Displayed when trying to read "%W" device for PLC except RX7i.
RHxx146	(Device name): Unsupported devices exist in write devices	Displayed when trying to write "%W" device for PLC except RX7i.

Driver-specific error messages are shown below.