Pro-face



Device/PLC Connection Manuals



About the Device/PLC Connection Manuals

Prior to reading these manuals and setting up your device, be sure to read the "Important: Prior to reading the Device/PLC Connection manual" information. Also, be sure to download the "Preface for Trademark Rights, List of Units Supported, How to Read Manuals and Documentation Conventions" PDF file. Furthermore, be sure to keep all manual-related data in a safe, easy-to-find location.



7.6.1 System Structure

This section explains the system structure for the Ethernet connection between a Meidensha PLC and the GP/GLC.

■ UNISEQUE Series



*1 For the applicable GP/GLC series units, the applicability of the optional Ethernet I/F unit, and the availability of the built-in Ethernet port are listed below.

Series Name		Product Name	Optional	Built-in	
			Ethernet I/F Unit	Ethernet Port	
GP77R Series	GP-377R Series	GP-377RT	O ^{*1*2}	х	
	GP-477R Series	GP-477RE	O ^{*2}	х	
	GP-577R Series	GP-577RS	O ^{*2}	х	
		GP-577RT	O ^{*2}	х	
GP2000 Series	GP-2300 Series	GP-2300L	х	0	
		GP-2300S	х	0	
		GP-2300T	х	0	
	GP-2400 Series	GP-2400T	х	0	
	GP-2500 Series	GP-2500L	O ^{*3*4}	0	
		GP-2500S	O ^{*3*4}	0	
		GP-2500T	O ^{*3*4}	О	
	GP-2501 Series	GP-2501S	O ^{*2*3}	х	
		GP-2501T	O ^{*2*3}	х	
	GP-2600 Series	GP-2600T	O ^{*3*4}	О	
	GP-2601 Series	GP-2601T	O ^{*2*3}	х	
GLC 2000 Series	GLC-2300 Series	GLC-2300L	х	0	
		GLC-2300T	х	0	
	GLC-2400 Series	GLC-2400T	х	0	
	GLC-2600 Series	GLC-2600T	O ^{*3*4}	О	

GP-PRO/PBIII for WindowsccDeive/PLC Connection Manual

Note:

- *1 Only Multi unit can be used.
- *2 The 2-Way Driver (Pro-Server, GP-Web and others) cannot be used.
- *3 When using optional Ethernet I/F unit, a bus conversion unit (PSL-CONV00) is required.
- *4 Using the optional Ethernet I/F Unit allows you to set up separate Class and Net No.s for 2-Way Driver applications (Pro-Server, GP-Web and others) and the PLC. When doing this, data transfer with the PLC is performed through the optional Ethernet I/F Unit.

• For cable connections, refer to the user's manual for each optional unit. For the GP2000 and GLC2000 series, refer to the user's manual for that unit.

Connection Structure



< Duplex system connection>



• The IP address of the Slave PLC is that of the Master PLC plus 8. For example, when the IP address of the Master PLC is 192.168.1.1, the IP address of the Slave PLC is 192.168.1.9. The GP ignores any UDP broadcast data other than that to the specified IP address.

For further information about a duplex system, refer to the PLC's user's manual.

7.6.2 Supported Devices

The following describes the range of devices supported by the GP.

■ UNISEQUE Series

Setup System Area here.

Device	Bit Address	Word Address	Other	
Memory	00000 ~ 1FFFF	0000 ~ 1FFF		L/H

• The address range(s) available will vary depending on the CPU used. Be sure to check this information in your CPU's manual prior to creating your system.



■ GP Settings

The following describes GP settings for using Ethernet communication.

♦ SETUP OPERATION SURROUNDINGS MENU



♦ SETUP EHTERNET INFORMATION

Select "SETUP ETHERNET INFORMATION" and enter each parameter.

SETUP ETHERNET INFORMATION				SET	CANCEL
SRC IP ADDRESS	[].[].[].[]
SRC PORT NO.	[]			
DEST IP ADDRESS	[].[].[].[]
	1			1-1-1	
1 2 3 4 5		7 8	90		L↓ BS
					$\leftarrow \rightarrow$

SRC IP ADDRESS

Enter the GP's SRC IP Address. Enter a dot between every 8 bits to divide the IP Address (32 bits all together) into four gorups, and enter decimal numbers in each group.

SRC PORT NO.

Set the SRC Port No. between 1024 and 65535.

DEST IP ADDRESS

Set the PROSEC's DST IP Address.



• Regarding the IP Address and the Port No., please confirm these points with your Network supervisor. You must not duplicate the number you have already used for an IP Address setting.



• When using the built-in Ethernet port on a GP2000 or GLC2000 series unit, be sure not to set any duplicate "SRC PORT No." values.

Check the 2-Way Driver's "SRC PORT No." setting via the following menu:

GP OFFLINE mode's Main menu [INITIALIZE] -> [SETUP OPERA-TION SURROUNDINGS] -> [EXTENDED SETTINGS] -> [SETUP ETHERNET INFORMATION].

The default value is 8000. The 2-Way Driver uses this port and the following 9 ports.

♦ SETUP ETHERNET EXT. INFROMATION

SETUP ETHERNET EXT. INFORM	MATION			SET		ANCEL
SEND WAIT TIME	[] (ms)				
TIMEOUT	[] (x 29	sec)			
IP ROUTER ADDRESS	[].[].[].[]	
SUBNET MASK	[].[].[].[]	
UDP RETRY COUNT (0 to 255)	[]				
	-4	A.—A	-4 4	-44	AA	
1 2 3 4 5	6	7 8	90			↓ BS
	ĺ					»

SEND WAIT TIME

You can display the waiting time while GP's command is actually sent. This function is useful when there is a lot of traffic in your system. If not used, set it to "0".

TIMEOUT

You can set the time for waiting for a reply from the destination. If any reply is not made by the destination within the time you set, a communication timeout will occur. "0" setting is the default value as 15 second-setting for timeout.

IP ROUTER ADDRESS

Set Router's IP Address. (There is only one setting for Router.) If not used, set all values to "0".

SUBNET MASK

Set the Subnet Mask . If not used, set all values to "0".

UDP RETRY COUNT (0 to 255)

This setting cannot be used, and the setting value is disabled.



 If you initialize GP/GLC memory from the OFFLINE mode, some values may revert to the factory settings. Please confirm all values after initialization.

■ PLC Unit Setup

• UNISEQUE Series

GP S	Setup	PLC Setup		
IP address of user's station	IP address of GP			
Port No. of user's station	IP address of GP			
IP address of destination	IP address of PLC	IP address	IP address of PLC	
		Port No. TCP	20010 (fix ed)	
		Port No. UDP	20050 (fix ed)	
		Broadcast	Available/unavailable	

*1 For the setting values, check with the network administrator.

*2 If the built-in Ethernet port is used on the GP2000 or GLC2000 series, check that the "Port No. of user's station" is not duplicated with the port No. for the 2-Way Driver.

The port No. for the 2-Way Driver can be checked by selecting [INITIALIZE] -> [SETUP OPERATION SURROUNDINGS] -> [EXTENDED SETTINGS] -> [SETUP ETHERNET INFORMATION]. The default value is 8000. The 2-Way Driver uses 10 continuous ports (8000 to 8009) starting with the default setting.

*3 If a duplex system connection is used, specify the IP address of the Master PLC.

The GP automatically recognizes the IP address of the Slave PLC. Therefore, specify the IP address of the Slave PLC by adding 8 to the IP address of the Master PLC.

Example:

IP address of Master PLC: 192.168.0.1

IP address of Slave PLC: 192.168.0.9



Reference For error codes specific to the GP Ethernet, refer to the "Protocol Stack Error Codes".

■ PLC SPECIFIC ERROR CODES

An error code specific to the PLC is displayed in the lower left corner of the GP/GLC screen like "Host communication error (02:**)" (** stands for the error code specific to the PLC).

♦ UNISEQUE Series

Error Code	Description	Status	
05	Illegal access	Addressing is illegal.	
08	Error mode	The CPU is disabled for transmission (e.g., because the PLC's ladder program stops).	





Protocol Stack Error Codes

The error codes related to the protocol stack are displayed on the GP screen as follows: PLC COM. ERROR (02:FE:**)

"**" represents any of the error codes 00 to F0 shown in the above table.

Error code	Description	Other
00	There is a setup error related to the IP address of your station at initialization.	
05	Initialization has failed.	
06	Abortion of communications has failed.	
07	An attempt was made to establish a connection before initialization was successfully completed.	
08	The port number of your station is abnormal.	
09	The port number of the destination station is abnormal.	
0A	The IP address of the other station is abnormal.	
0B	The same port number is already being used by the UDP for establishing the connection.	
0C	The same port number is already being used by the TCP for establishing the connection.	
0D	The protocol stack has refused connection establishment.	
0E	The protocol stack has returned the unsuccessful establishment of a connection.	
0F	The connection has been shut down.	
10	All the connections are busy. No connection is available.	
13	Your station is aborted by the other station	
30	There is no reply from the protocol stack	
32	There is no reply from the other station	*1
40	The designated Node Addresses do not exist in Network Information.	*1
41	I/O Memory Type for Randam Read Out response data is wrong.	*1
42	Network Information does not exist.	
F0	Undefined error.	

*1 When using an Omron CS1 Series unit, the error code display is as shown below. The Network Addresses and Node Addresses also are displayed.

Host Communication Error (02:FE:**:###:###)"



