

# Device/PLC Connection Manuals

---



## About the Device/PLC Connection Manuals

Prior to reading these manuals and setting up your device, be sure to read the "Important: Prior to reading the Device/PLC Connection manual" information. Also, be sure to download the "Preface for Trademark Rights, List of Units Supported, How to Read Manuals and Documentation Conventions" PDF file. Furthermore, be sure to keep all manual-related data in a safe, easy-to-find location.

# Matsushita Electric Works Connectable Devices

The following tables list the devices that can be connected and used with the GP.

## ■ PLCs

### ◆ 1:1 Connection

Series Name	CPU	Link Unit	Comments	Device type in Screen Editor	GP Series GLC 2000 Series	GLC 100 Series GLC 300 Series
MEWNET	FP3	AFP3462		MATSUSHITA MEWNET-FP series	○	x
	FP5	AFP5462				
	FP10(S)	COM. Port on CPU unit				
		AFP3462				
	FP1	RS-232C Port on CPU unit	Tested using C24C and C40C.			
		CPU Direct Connection				
	FP-M	Serial port connector on Board				
		CPU Direct Connection				
	FP10SH	COM.Port on CPU unit				
	FP2	COM.Port on CPU unit				
		CPU Direct Connection				
	FP0	RS-232C Port on CPU unit	CPU unit built-in RS- 232C is required.			
		CPU Direct connection				
FPS	Tool Port on control unit					
	FPG-COM1 FPG-COM2					

◆ **n:1 (Multi-link) Connection**

Series Name	CPU	Link I/F	Device type in Screen Editor	GP Series GLC2000 Series	GLC100 Series GLC300 Series
MEWNET	FP10S *1 FP10SH	Link I/F on CPU unit	MATSUSHITA MEWNET-FP series	○	X

*\*1 Use Version 1.8 or higher.*