Pro-face



Device/PLC Connection Manuals



About the Device/PLC Connection Manuals

Prior to reading these manuals and setting up your device, be sure to read the "Important: Prior to reading the Device/PLC Connection manual" information. Also, be sure to download the "Preface for Trademark Rights, List of Units Supported, How to Read Manuals and Documentation Conventions" PDF file. Furthermore, be sure to keep all manual-related data in a safe, easy-to-find location.

CHINO Corporation Controllers 12.10

System Structure 12.10.1

The following describes the system configuration used when connecting the GP/ GLC/LT to a CHINO Controller.



GP/GLC/LT's System Area (LS0 to LS19) Settings

The GP/GLC/LT's system area (20 words) cannot be allocated to the Controller's own data area. When you are entering the system area settings via the screen editor software or via the GP/ GLC/LT's OFFLINE screen, be careful that you do not use the Controller's own data area.

■ LT230 Series



*1 The model data " \square " will vary depending on the type of option. For detailed controller information, refer to that unit's catalog. Serial data transfer option types use a "2" for RS-485 and "3" for RS-485+2 External Input.

Controller *1	Cable Diagram		GP/GLC/LT
0000			
LT30000R00-000	RS-232C (Cable Diagram 1)	Chino's RS-232C Cable RZ-CRS2ロロ ^{*2}	
LT30000A00-000	RS-422 4-wire (Cable Diagram 2) RS-422 4-wire 1:n Connection (Cable Diagram 3)	Digital's GP230-IS11-O	GP/GLC Series LT Type C
LT30000\$00-000	RS-422 2-wire (Cable Diagram 4) RS-422 2-wire 1:n Connection (Cable Diagram 5)		

LT300 Series

- *1 The model data "□" will vary depending on the type of option. For detailed controller information, refer to that unit's catalog. Serial data transfer option types use a "R" for RS-232C, "A" for RS-422A and "S" for RS-485.
- *2 The Cable cannot be connected directly to a GP-377/GP-377R/GP2300 Series unit because of the connectors cover size.

■ LT400 Series

Controller *1	Cable Diagram		GP/GLC/LT
LT4000R00-000	RS-232C (Cable Diagram 1)	Chino's RS-232C Cable RZ-CRS2ロロ ^{*1}	
	RS-422 4-wire (Cable Diagram 2)	Digital's GP230-IS11-O	
	RS-422 4-wire 1:n Connection (Cable Diagram 3)		GP/GLC Series LT Type C
LT40000\$00-000	RS-422 2-wire (Cable Diagram 4) RS-422 2-wire	-	
	1:n Connection (Cable Diagram 5)		

- *1 The model data "□" will vary depending on the type of option. For detailed controller information, refer to that unit's catalog. Serial data transfer option types use a "R" for RS-232C, "A" for RS-422A and "S" for RS-485.With LT-400 Series units, be sure to use units with a Serial Number of LT4037**** or later. When using LT 400 Series units with a Serial Number of LT4036**** or earlier, an error "PLC NOT RESPONDING (02:FE:**)" will appear on GP/GLC/LT display.
- *2 The Cable cannot be connected directly to a GP-377/GP-377R/GP2300

JU Series



*1 JU Series Thyristors models vary, depending on each unit's communication specifications. The two groups are identified by model numbers with a "5" (Unit space Master with temperature controller feature), and a "6" (Unit space Slave - without temperature controller feature). For details, refer to the Thyristor catalog. thyristors with no temperature controller feature (JUDDDDDD613) cannot be connected directly to the GP. The unit must first be connected to a "5" series unit (JUDDDD513), and communication is performed via the "5" series unit's Master-Slave communication. For inter-unit communication methods, refer to your Thyristor unit's Installation Guide.

Connections

•1:1 connection (RS-232C or RS-422)



•1:n connection (RS-422)



•1:n connection (JU Series inter-unit communication) (RS-422)



12.10.2 Cable Diagrams

The cable diagrams shown below and the cable diagrams recommended by CHINO Corporation may differ, however, using these cables for your Controller's operations will not cause any problems.



- Connect the FG line of the Shield cable to the GP/GLC/LT side.
- If a communications cable is used, be sure to connect its SG (signal ground) terminal.
- RS-232C cables should be 15 meters or less.
- RS-422 cables should be 600 meters or less.

Cable Diagram 1 RS-232C

<When making your own cable connections>



<When using Chino's RS-232C Cable RZ-CRS2

 $(\Box\Box$ indicates the Cable length. 15m max.)





Chino's RS-232C Cable RZ-CRS2DD cannot be connected to GP-377/GP-377RS/GP2300 Series unit because of the connector size.

Cable Diagram 2 RS-422 4-Wire

<When using Digital's RS-422 connector terminal adapter GP070-CN10-0>



<When using Digital's RS-422 Cable GP230-IS11-0>



<When making your own cable>





When connecting the #9 and #10 pins in the GP Serial I/F, a termination resistance of 100Ω is added between RDA and RDB.

Cable Diagram 3 (1:n) RS-422 4-Wire

<When using Digital's RS-422 connector terminal adapter GP070-CN10-0>



<When using Digital's RS-422 Cable GP230-IS11-0>



<When making your own cable>





When connecting the #9 and #10 pins in the GP Serial I/F, a termination resistance of 100Ω is added between RDA and RDB.

Cable Diagram 4 RS-422 2-Wire



The controller terminal number will differ depending on the type of controller used. The controller pin assignment diagrams are shown below. When using JU series, SA and SB will be called SA1 and SB1. JU Series unit has no SG.

Signal		Termina	l number	
name	LT230	LT 300	LT400	JU+ (Master)
SA	6	11	11	14
SB	7	12	12	15
SG	8	15	15	

<When using Digital's RS-422 connector terminal adapter GP070-CN10-0>



<When using Digital's RS-422 Cable GP230-IS11-0>



When connecting the #9 and #10 pins in the GP Serial I/F, a termination resistance of 100Ω is added between RDA and RDB.

GP-PRO/PBIII for Windows Device/PLC Connection Manual

Cable Diagram 5 (1:n) RS-422 2-Wire



The controller terminal number will differ depending on the type of controller used. The controller pin assignment diagrams are shown below. When using JU series, SA and SB will be called SA1 and SB1. JU Series unit has no SG.

Signal	Terminal number				
name	LT230	LT300	LT400	JU+ (Master)	
SA	6	11	11	14	
SB	7	12	12	15	
SG	8	15	15		

<When using Digital's RS-422 connector terminal adapter GP070-CN10-0>



<When using Digital's RS-422 Cable GP230-IS11-0>







When connecting the #9 and #10 pins in the GP Serial I/F, a termination resistance of 100Ω is added between RDA and RDB. GP-PRO/PBIII for Windows Device/PLC Connection Manual

Cable Diagram 6 (1:n) RS-422 2-Wire (JU Series inter-unit communication)



Cable length used between the temperature controller master and the slave should be less than 10 meters.



<When using Digital's RS-422 Cable GP230-IS11-0>



<When making your own cable>



Note:When connecting the #9 and #10 pins in the GP Serial I/F, a termination
resistance of 100Ω is added between RDA and RDB.GP-PRO/PBIII for Windows Device/PLC Connection Manual12-10-11

12.10.3 Supported Devices

The following list shows the range of devices supported by the GP/GLC/LT.

■ LT230 Series

Device	Bit Address	Word Address	Comments
Digital Setting Value	00101		*1
Digital Input Data	10004~10120		*2
Analog Input Data		30101~30142	<u>B i t</u> 15 *2 H/L
Analog Setting Value		40008~40251	15 1 *1
Analog Octing Value		49501~49512	Bit

*1 When writing data, be sure to set the Controller's Key Lock to [Lock 4]. When Writing with Key Lock [Lock 4], a Host communication error (02:12:**) will appear.
✓ Reference 12.10.5 Error Codes

*2 Only data read-out is possible. Data write is not possible. If data write is attempted, a Host communication error (02:01:**) will appear. **Reference** 12.10.5 Error Codes

■ LT300 Series

Device	Bit Address	Word Address	Comments
Digital Setting Value	00101		*1
Digital Input Data	10004~10122		*2
Analog Input Data		30101~30142	B i t 15 *2 H/L
Analog Setting Value		40008~40251	—1 Б ъ ^{*1}
Analog Coung Value		49501~49512	Bit

*1 When writing data, be sure to set the Controller's Key Lock to [Lock 4]. When Writing with Key Lock [Lock 4], a Host communication error (02:12:**) will appear.
Reference 12.10.5 Error Codes

*2 Only data read-out is possible. Data write is not possible. If data write is attempted, a Host communication error (02:01:**) will appear. **References** 12.10.5 Error Codes

■ LT400 Series

Device	Bit Address	Word Address	Comments
Digital Setting Value	00101		*1
Digital Input Data	10004~10124		*2
Analog Input Data		30101~30142	<u>B i t</u> 15 *2 H/L
Analog Setting Value		40001~40388	15 1 *1
Analog ocung value		49501~49512	Bitl

^{*1} When writing data, be sure to set the Controller's Key Lock to [Lock 4]. When Writing with Key Lock [Lock 4], a Host communication error (02:12:**) will appear. **Reference** 12.10.5 Error Codes

*2 Only data read-out is possible. Data write is not possible. If data write is attempted, a Host communication error (02:01:**) will appear. **Reference** 12.10.5 Error Codes

JU Series

Device	Bit Address	Word Address	Comments
Digital Satting Value	00101~00106		*1
Digilal Sewing value	01102~01612		
Digital Input Data	10002~10122		*2
	11109~11614		
		30101~30142	<u>віt</u> 15]
Analog Input Data		31101~31612	* ² H/L
		39001~39080	
		40001~40384	<u>віt</u> 15]
Analog Setting Value		41102~41627	*1
		48111~48618	
		49501~49525	

- *1 When writing data, be sure to set the Thyristor's Key Lock to [Lock 4]. When Writing with Key Lock [Lock 4], a Host communication error (02:12:**) will appear. **Reference** 12.10.5 Error Codes
- *2 Only data read-out is possible. Data write is not possible. If data write is attempted, a Host communication error (02:01:**) will appear. Reference 📐 12.10.5 Error Codes



Indicating Controller Slave Address settings can be entered in your screen editor software. If a unit number is not indicated, the previously entered station number is automatically used. (The default value is 1.)

E.g. When entering Device Address 40001

Enter the Device Name "4", and the Word Address "0001".







• GP/GLC/LT's System Area (LS0 to LS19) Settings

The GP/GLC/LT's system area (20 words) cannot be allocated to the Controller's own data area. When you are entering the system area settings via the screen editor software or via the GP/ GLC/LT's OFFLINE screen, be careful that you do not use the Controller's own data area.

• With system versions later than the following, even if the system area is allocated, the GP/GLC/LT will not send the system area data to a Controller. To check the system version, refer to the GP/GLC/LT's User Manual.

GP/GLC/LT Series	GP77R	GP377	GP2000	GLC300	GLC2000	LT Type C
System Version	Ver.2.60	Ver.2.60	Ver.2.60	Ver.2.45	Ver.3.10	Ver.1.00



Decimal point data is included in temperature controller data. The GP/ GLC/LT unit handles decimal point data as follows:

<When reading out data>

Data read out from a temperature controller will be converted to a nondecimal integer.

EX.) Temperature controller's value is 100.0 Temperature controller value 100.0 Value on the GP/GLC/LT unit (set for no value after decimal)1000

When displaying decimal values on a GP/GLC/LT(via an N-tag, etc.) the data will be displayed according to the [Display Data Format]'s [Decimal Places] setting. For example, if the temperature controller's setting is for one digit after the decimal place, enter "1" for the [Decimal Places].

EX.) Temperature controller's value is 100.0 Temperature controller value 100.0 Value on the GP/GLC/LT unit (set for no value after decimal) 1000 Value on the GP/GLC/LT unit (set for one digit after decimal point) 100.0

<When writing data>

Writing data from a temperature controller to the GP/GLC/LT will always be set for no value after the decimal point.

For detailed information about data setting ranges and decimal values, refer to Chino Corporation's Communication Interface Installation guide for each type of temperature controller.

Environment Setup 12.10.4

The following table lists Pro-face's recommended CHINO Corporation Controller and GP/GLC/LT communication settings.

■ LT230/LT300Series

GP/GLC/L	GP/GLC/LT Settings		Settings
Baud Rate	9600bps	Communication Rate	9600bps
Data Length	8 bits	Data Length	8 bits
Stop Bit	1 bit	Stop Bit	1 bit
Parity Bit	Non	Parity Bit	Non
Communication Format	RS-232C		
When using RS-232C	10-2020		
Communication Format			
When using RS-422	4-000		
Communication Format	2 wiro		
When using RS-485	2-Wite		
Unit No.	1	Slave Address *1	1
		Protocol	MODBUS RT U
		Communication Feature	Host Communication

*1 Even though slave addresses can be set from 1 to 99, be sure to set them only from 1 to 32 when connecting to a GP.

■ LT400 Series

GP/GLC/L	Γ Settings	Controller	Settings
Baud Rate	9600bps	Communication Rate	9600bps
Data Length	8 bits	Data Length	8 bits
Stop Bit	1 bit	Stop Bit	1 bit
Parity Bit	Non	Parity Bit	Non
Communication Format	RS-232C		
When using RS-232C	10-2020		
Communication Format	1-wire		
When using RS-422	+-WIIC		
Communication Format	2 wire		
When using RS-485	2-WIIC		
Unit No.	1	Slave Address *1	1
		Protocol	MODBUS RT U
		Communication Feature	Host Communication
Send Wait	30ms		

*1 Even though slave addresses can be set from 1 to 99, be sure to set them only from 1 to 32 when connecting to a GP.

JU Series

GP/GLC/L ⁻	GP/GLC/LT Settings		Settings
Baud Rate	9600bps	Communication Rate	9600bps
Data Length	8 bits	Data Length	8 bits
Stop Bit	1 bit	Stop Bit	1 bit
Parity Bit	Non	Parity Bit	Non
Communication Format	RS-232C		
When using RS-232C	10-2020		
Communication Format	1-wire		
When using RS-485	4-000		
Unit No.	1	Slave Address *1	1
		Communication Code	RTU
Send Wait	30ms		

*1 Even though the GP unit's Station number can be set from 1 to 32, be sure to use only 1 to 31, which is the range allowed for temperature controller slave addresses.



Controller Error Codes

♦ LT/JU Series

Error messages (Ex. Host communication error (02:**:##)) are displayed in the lower left corner of the GP/GLC/LT screen (** stands for an error code specific to the Controller).

Host Communication Error (02:**:##)

 Slave Address of Controller that has caused the error
 Controller Error Code

Error Code	Description
01	Incorrect function code
02	Incorrect indirect number (reference number)
03	Incorrect amount of data
09 *1	Either a data transfer error occurred between units, or the initial resistance value could not be set.
11	Outside of value setting range

*1 Error Code "09" is only for JU Series.

Refer to the Controller's manual for error code details.