

Device/PLC Connection Manuals



About the Device/PLC Connection Manuals

Prior to reading these manuals and setting up your device, be sure to read the "Important: Prior to reading the Device/PLC Connection manual" information. Also, be sure to download the "Preface for Trademark Rights, List of Units Supported, How to Read Manuals and Documentation Conventions" PDF file. Furthermore, be sure to keep all manual-related data in a safe, easy-to-find location.

Modicon Connectable Devices

The following tables list the devices that can be connected and used with the GP.

■ PLCs

◆ 1:1 Connection

| Series Name | CPU | Link Unit | Device Type in Screen Editor | GP Series GLC 2000 Series | GLC 100 Series GLC 300 Series |
|-------------|-----------------|--------------------|-------------------------------|---------------------------------|--|
| 884/984 | 884, 984A, 984B | Modbus Port on CPU | MODICON Modbus (Master) | ○ | x |

◆ Modbus Plus Communication, Modbus Slave Communication

| Series Name | CPU | Link I/F | Device Type in Screen Editor |
|---------------|---------------------|----------------------------|------------------------------|
| Modbus Master | | | Modicon Modbus (SLAVE) |
| 884/984 | 884 984A 984B | Modbus Plus Port on CPU | Modicon Modbus Plus |