Pro-face



Device/PLC Connection Manuals



About the Device/PLC Connection Manuals

Prior to reading these manuals and setting up your device, be sure to read the "Important: Prior to reading the Device/PLC Connection manual" information. Also, be sure to download the "Preface for Trademark Rights, List of Units Supported, How to Read Manuals and Documentation Conventions" PDF file. Furthermore, be sure to keep all manual-related data in a safe, easy-to-find location.

Ubon Corporation Connectable Devices

The following tables list the devices that can be connected and used with the GP.

■ PLC

♦ 1:1 Connection

Series Name	CPU	Link Unit	Comments	Device Type in Screen Editor	GP Series GLC 2000 Series	
UPZ	UPZ3-16ND1-16TD1 UPZ3-T UPZ2-M	Link I/F unit on CPU		Ubon UPZ Series	0	х