25 Transferring

25.1   Setting Guide

This step transfers a network project file to a specified entry node, making ACTION and data transfer available.

| NOTE	• Please make sure to save the network project file before transferring.

☞ "24Saving"

Setting item	Setting content
Transfer to Another Node	Transfers a network project file to a specified node. When the file transfer is executed, the "Transfer Network Project" screen appears to show the results of network project compilation, transfer status to each node and completion message. **NOTE** • The GP turns to offline mode when a network project file is transferred, and restarts after the transfer is completed. • When transferred to multiple nodes, a network project file is transferred to each node in order. If error occurs during the transfer to one of the nodes, the transfer process is cancelled without transferring to the rest of the nodes. Click [Transfer to other nodes] to continue the file transfer.
Delete Network Project	Deletes the network project of the node specified. The "Delete Network Project" screen will appear. Click [Yes] or [No].
Confirm Online Node	Obtains "Project version" and "Current version" from a specified node to update the node list.
Currently Edited Network Project File	Displays File Name, User Management Number, and Build Number of the network project file being edited.

Setting item		Setting content
ALL		Checks all the nodes displayed.
PASV		Transfers in passive mode. This is effective only for transferring a network project file to GP3000 Series node. **NOTE** • Transfer in passive mode is useful for the file transfer under the circumstance where the network filters FTP commands with the firewall setting.
Node List	Node Name	Displays registered node names. Check the check box to specify a node.
	IP Address	Displays IP addresses of nodes.
	Actual Device	Displays the information of the network project file transferred to the GP or CF card when executing [Confirm Online Node]. GP3000 Series: The file name is displayed, if transferred. GP Series: You can confirm the file existence.
	No.	Displays user management numbers. Available only for GP3000 Series.
	Build No.	Displays build numbers. Available only for GP3000 Series.
	Last Transfer Date/Time	Displays the last date and time when a network project file was transferred. Available only for GP3000 Series.