

# Backlight Replacement Guide

Thank you for purchasing the CA5-BLU12XGA-01 replacement backlight.

Be sure to read the following Backlight Replacement Warnings prior to replacing your unit's backlight.

This replacement backlight package contains the following:

If this backlight is not appropriate for your unit or does not function correctly, please contact your nearest Pro-face office.

## WARNINGS

- Be sure the unit's power cord has been disconnected before changing the backlight. When the unit's power cord is connected and the power supply is ON, high voltage runs through the wires in the backlight area.
- After the unit's power cord is disconnected, the backlight area will remain hot for a short period. Be sure to wear gloves to prevent burns.
- Do not touch the backlight unit's glass tube directly or try to remove its power cord. If the glass tube breaks you may be injured.
- When this backlight is disposed of, it should be done so according to your country's regulations for similar types of industrial waste.



- *Do not allow water, oil or fingerprints to remain on the tube, since they can all reduce the backlight's life.*
- *Change the entire backlight unit, i.e. both the tube and holder.*

### ◆ Package Contents

- One (1) replacement backlight (Model:CA5-BLU12XGA-01)

### ◆ Items Required When Changing The unit's Backlight

- Phillips screwdriver (no. 2).
- One pair of clean (preferably new) cotton gloves.

Also, Pro-face recommends you prepare a small container for keeping all screws removed during the replacement process.