17 Graph Display

This chapter explains how to use the GP-Pro EX Graph feature.

Please start by reading "17.1 Settings Menu" (page 17-2) and then turn to the page with the relevant explanation.

17.1	Settings Menu	17-2
17.2	Displaying the Current Value in a Bar/Circle/Tank Graph	17-4
17.3	Displaying Alarms in a Bar/Circle/Tank Graph	17-7
17.4	Using Line Charts	17-11
17.5	Using a Line Chart to View Historic Data	17-15
17.6	Displaying Multiple Addresses Concurrently (Block Display)	17-19
17.7	Settings Guide	17-24
17.8	Restrictions	17-71

17.1 Settings Menu





17.2 Displaying the Current Value in a Bar/Circle/Tank Graph

17.2.1 Introduction

The current value is converted as defined in the range values and displayed on the Graph.





17.2.2 Setup Procedure

	• Please refer to the settings guide for details.
NOTE	🎯 "17.7.1 Graph Part Settings Guide" (page 17-24)
	 For details about placing parts or setting addresses, shapes, or colors, please refer to the "Part Editing Procedure". ⁽²⁾ "0.04 Editing Parts" (ages 0.20)
	9.6.1 Editing Parts" (page 9-38)

Displays word address (D100) data on a Bar Graph.



- 1 From the [Parts (P)] menu, select [Graph (G)] or click 🛍 . Place the Graph on the screen.
- **2** Double-click the new Graph. The following dialog box appears.

💰 Graph		X
Comment Select Shape No Shape	Basic Color Scale Graph Type Image: Statistical Graph Image: Statistical Graph Monitor Word Address [PLC1]D00000 Image: Statistical Graph Data Type 16 Bit Bin Bit Length Image: Statistical Graph Data Type 16 Bit Bin Bit Length Image: Statistical Graph Specify Input Rance Image: Statistical Graph Display Rance Input Specification Image: Statistical Graph Image: Statistical Graph Min. Image: Statistical Graph Image: Statistical Graph Min. Image: Statistical Graph Image: Statistical Graph Min. Image: Statistical Graph Image: Statistical Graph Graph Shape Image: Statistical Graph Image: Statistical Graph Graph Shape Bar Graph Image: Statistical Graph Hole Image: Statistical Graph Image: Statistical Graph Hole Image: Statistical Graph Image: Statistical Graph Graph Shape Image: Statistical Graph Image: Statistical Graph Hole Image: Statistical Graph Image: Statistical Graph Hole Image: Statistical Graph Image: Statistical	
Help (<u>H</u>)	OK (Q) Cancel	

3 In [Monitor Word Address], set the address you want to display. Then set the [Data Type] and [Bit Length].

Monitor Word Addre	ss [PLC1]D00100		_
Data Type	16 Bit Bin 💌	Bit Length	16 🚊 🏢

4 In the [Input Specification] drop-down list, select [Constant]. In the [Min] and [Max] fields, set the range of data stored in that address. If you are storing negative values, set the [Input Sign] to [2's Complement] or [MSB Sign].

-Specify Inpu	ut Range		
Input Specie	fication	Constant	-
Input Sign		None	-
Min	p	÷ #	
Max.	500	=	

5 In the [Graph Shape] drop-down list, select [Bar Graph].

[Graph Shape						
	Graph Shape	Bar Graph	•	Display D	irecti	on Top	-
	🗖 Hole	20	 ◄	Show Fill	Г	Show Start F	oint

• You can also select [Circle Graph], [Semicircle Graph], and [Tank Graph].

6 In [Select Shape], select the Graph shape.

NOTE

7 On the [Color] tab, set the [Display Color].Set the Graph's other colors (pattern color, border color) if necessary.

Basic Color Scale			
Display Color	Blink None		
Pattern			
None	-		
			1
Border Color	Blink		
7 <u>▼</u>	None 💌		
Background Color	Blink		
	None 💌	-	
🗖 Alarm Settings			

8 On the [Scale] tab, set the scale's display settings, designate the scale colors, and click [OK].

Basi	c Color	Scale					
	Show the	Major So	ale				
	Scale Div	isions	2	-	3		
	Show	Minor Sc.	ale				
	Scale Div	isions	Б	-	3		
	Scale Colo	r		Blink			
	1		•	None	-		
			_				

17.3 Displaying Alarms in a Bar/Circle/Tank Graph

17.3.1 Introduction

When the data range is 0-500:



You can set the normal and abnormal values. When an abnormal value occurs, the Graph color changes.

This is useful for users to quickly see abnormal values.

17.3.2 Setup Procedure

	• Please refer to the settings guide for details.
NOTE	"17.7.1 Graph Part Settings Guide" (page 17-24)
	• For details about placing parts or setting addresses, shapes, or colors, please
	refer to the "Part Editing Procedure".
	🐨 "9.6.1 Editing Parts" (page 9-38)

Set the Graph color so that it changes when the word address (D100) data goes below 20% or above 80% of the Input Range.



1 From the [Parts (P)] menu, select [Graph (G)] or click 🛍 . Place the Graph on the screen.

2 Double-click the new Graph. The following dialog box appears.

💰 Graph		×
Parts ID GR_0000 🚔 Comment Select Shape No Shape	Basic Color Scale Graph Type Monitor Word Address [PLC1]D00000 Data Type 16 Bit Bin Bit Length 16 Specify Input Range Input Specification Constant Input Sign None Min. Max. 100 Graph Shape Graph Shape Graph Shape Bar Graph Hole Color Scale Max Show Fill Show Start Point	
Help (<u>H</u>)	OK (Q) Cancel	

3 In [Monitor Word Address], set the address you want to display. Then set the [Data Type] and [Bit Length].



4 In the [Input Specification] drop-down list, select [Constant]. In the [Min] and [Max] fields, set the range of data stored in that address.

-Specify Inp	ut Range		
Input Speci	fication	Constant	-
Input Sign		None	-
Min	p	- H	
Max.	500	Ħ	

5 In the [Graph Shape] drop-down list, select [Bar Graph].

Graph Shape	Bar Graph	-	Display Di	rection Top
🗖 Hole	20 :		Show Fill	🗖 Show Start Po

• You can also select [Circle Graph], [Semicircle Graph], and [Tank Graph].

6 In [Select Shape], select the Graph shape.

NOTE

7 On the [Color] tab, set the [Display Color].Set the Graph's other colors (pattern color, border color) if necessary.

Basic Color Scale	
Display Color Blink 4 None Pattern	
None	
	1
Border Color Blink	
7 Vone V	
Background Color Blink	
None 💌	
Alarm Settings	

8 Select the [Alarm] check box, and specify the alarm range (percentage). (For example, Lower Limit 20, Upper Limit 80).

9 In [Display Color], set the Alarm Display color.

Alarm Settings		
Alarm Action Constant	-	
Alarm Range	Alarm Color	
Lower Limit	Display Color	Blink
20 芸 🏢	1 💌	None
Upper Limit	Pattern Color	Blink
β0 <u>Ξ</u>	7 -	None

10 On the [Scale] tab, set to show the scales and the color and blink. Click [OK].

Basic Color Scale	
Show the Major Scale	
Scale Divisions	
Scale Color Blink	

17.4 Using Line Charts

17.4.1 Introduction



You can collect and display data in regular or random intervals in a Line Chart.

You can use this to identify significant changes in data or to view the relationship between different data.

Up to 20 lines can be displayed on a single Line Chart.

IMPORTANT	• Use the Sampling function to get data. To display a historical trend graph, you first need to set connection device/PLC data to be collected in the GP using the Sampling.
	"24.3 Sampling Data at Constant Intervals" (page 24-5)
	"24.4 Sampling Data at Specific Periods" (page 24-10)

17.4.2 Setup Procedure

NOTE	• Please refer to the settings guide for details.
NOTE	"17.7.2 Historical Trend Graph Settings Guide" (page 17-40)
	• For details about placing parts or setting addresses, shapes, or colors, please
	refer to the "Part Editing Procedure".
	"9.6.1 Editing Parts" (page 9-38)

Each time a Word Address data point is sampled, that data point is displayed on a Line Chart.



- 1 From the [Parts (P)] menu, select [Historical Trend Graph (H)] or click 🔛 . Place the Graph on the screen.
- **2** Double-click the new Graph. The following dialog box appears.

💰 Historical Trend G	raph	×
Parts ID HT_0000 === Comment	Graph Display Area Color Limit Colors Display Historical Data Graph Type Image Pen Recorder	
Select Shape	Group Number Number of Channels 1	
	Data Type 16 Bit Bin Input Range Input Sign None Min. Max. 15535 Max.	
Help (<u>H</u>)	OK (Q) Cancel	

- **3** In [Select Shape], select the Graph shape.
- 4 In [Sampling Group], select the number of the sampling group you want to display.

5 Click [Channel Settings]. The following dialog box appears.

In [Number of Channels], set the number of data lines to display on the graph. In [Channel1], select the graph display address.

💰 Channel Data Settings	_ 🗆 🗙
Number of Channels 1	
Line Chart Display Buffer List	
Channel Number 1 :[PLC1]D00100	-
OK (<u>O</u>) Car	ncel

6 Set the data type and input range for the graph data.

-Input/Display	Settings			
Data Type	16 Bit Bin	-		
-Input Range			-Display Range	·
Input Sign	None	-	🗖 Display Si	ign +/-
Min.	p	= =	Min.	0
Max.	100		Max.	100

7 On the [Color] tab, set the color and type of the line to be displayed and the color of the Graph Display Area.

Graph Display Area Color Limit Colors Display Historical Data	
Channel Number 1	
Channel Color	
Line Type -Solid Line 💽 Line Thickness 1 🚍 🧾	
Display Color Blink	
7 None T	
Border Color Blink Scale Color Blink	
7 💌 None 💌 🗖 5 💌 None 💌	
Graph Area Color Blink	
□ 1	

8 Click the [Display Area] tab. Set the [Display Direction] and the [Data Samples]. The initial value of the [Samples to Scroll] is the same as [Data Samples].



9 Adjust the scale settings as necessary, and click [OK].

17.5 Using a Line Chart to View Historic Data

17.5.1 Introduction



You can display a Line Chart's past data.

You can view historic data that has been cleared from the Line Chart. This function is useful looking at changes in data over a period of time.

17.5.2 Setup Procedure

NOTE	• Please refer to the settings guide for details.
NOTE	"17.7.2 Historical Trend Graph Settings Guide" (page 17-40)
	• For details of the part placement method and the address, shape, color, and
	label setting method, refer to the "Part Editing Procedure".
	"9.6.1 Editing Parts" (page 9-38)

Use these settings when you want to check a Word Address' historic data.



1 From the [Parts (P)] menu, select [Historical Trend Graph (H)] or click 🔝 . Place the Graph on the screen.

2 Double-click the new Graph. The settings dialog box appears.
 Set the sampling group and address (D100), then adjust the settings needed for display such as the line color, number of display data, etc.
 ^{CP} "17.4.2 Setup Procedure" (page 17-12)

3 Open the [Display Historical Data] tab. Select the [Display Historical Data] check box.



• Only one Historical Trend Graph part with a Display Historical Data function can be placed per screen.

4 Set the switches which will display historical data.

Set the number that the switch will scroll when pressed once.

-Switch Layout	_	
Visplay Historical Dat	a	
Scroll for Old Data	Samples to Scroll	1 🗄
Scroll for New Data	Samples to Scroll	1 🗄

• When you use [Historical Trend Graph Switch] from [Special Switch] in the switch lamp part without setting the switch layout on the Historical Trend Graph, you can set a shape, color to an individual switch.

- 5 In [Select Shape], select the Switch shape.
- 6 Select the Switch Label [Font Type] and [Display Language]. Set the [Text Color].

Standard Font	•
Japanese	•
7	•
	Standard Font Japanese

7 In [Select Switch], choose the switch and enter the text in [Label]. Type a label for each of the switches.

Display Historical Data	Scroll for Old Data	Scroll for New Data
Display Hi storical	Back	Next

8 Select the switch color and click [OK]. (Some colors cannot be set depending on the selected switch shape.)

The switches are placed on the top right of the Historical Trend Graph.



9 Select the Graph display part and an individual switch independently and move it anywhere within the screen.



17.6 Displaying Multiple Addresses Concurrently (Block Display)

17.6.1 Introduction





You can display multiple values from consecutive word addresses on a single Line Chart. You can compare the values and state of multiple data points.

17.6.2 Setup Procedure

NOTE	• Please refer to the settings guide for details.
NOTE	"17.7.3 Data Block Display Graph Settings Guide" (page 17-55)
	• For details about placing parts or setting addresses, shapes, or colors, please
	refer to the "Part Editing Procedure".
	"9.6.1 Editing Parts" (page 9-38)

When bit 0 of a word address (D100) is turned on, and a Graph is created, displaying the Line Chart of data from 4 consecutive words in block display.



- 1 From the [Parts (P)] menu, select [Data Block Display Graph (L)] or click [. Place the Graph on the screen.
- 2 Click the new Graph. The following dialog box appears.

💰 Data Block Display	/ Graph		×
Parts ID	Graph Display Area Color Lin	nit Colors	
Comment	Number of Channels 1		>>Extended
	Channel Number 1	•	
	Control Word Address	[PLC1]D00000	-
	Number of Channels Address	[PLC1]D00001	
	Data Storage Start Address	[PLC1]D00002	
Select Shape	Input/Display Settings		
🔲 No Shape	Data Type 16 Bit Bin	 Offset 	
	Input Range	Display Range	
	Input Sign None	Display Sign +,	/
	Min. P =	<u>비패</u> Min. [^ ㅋㅋ	
	Max. 65535 <u>+</u>	<u>∃</u> Max. 100	
		OK (0)	
Heip (H)		UKW	Cancel

3 In [Select Shape], select the Graph shape.

4 In [Control Word Address], set the address (D100) to control the graph display. The address (D101) used to store the number of data displayed on the graph "4" is displayed in [Number of Channel Data Storage Address].

Control Word Address	[PLC1]D00100
Number of Channels Address	[PLC1]D00101
Data Storage Start Address	[PLC1]D00102

5 In the [Min] and [Max] fields, set the range of data stored in that address. If you are storing negative values, set the [Input Sign] to [2's Complement] or [MSB Sign].

—Input/Display Data Type	Settings 16 Bit Bin	•
-Input Range		
Input Sign	None	-
Min.	ρ	#
Max.	100	- H

6 On the [Display Area] tab, set [Display Direction]. Set the [Data Samples] to 4.

Display Direction Data Samples
Data Samples
Saala Divisiona
Vertical Description Vertical Minor - E
Major Scale P 🔤 Scale
Horizontal P 📰 🗰 Horizontal 🔽 🎼 🧱

7 On the [Color] tab, set the color and type of the line to be displayed, and the color of the Graph Display Area. Next click [OK].

Graph Display Area Color Limit Colors
Channel Number 1
🔽 Line Type 🛛 — Solid Line 🗨 Line Thickness 1 🚍 🧱
Display Color Blink
□ 7 Vone V
Dot Type Gircle
7 Blink None
Border Color Blink Scale Color Blink
7 🔽 None 💌 🗖 5 💌 None 💌
Graph Area Color Blink
None 💌

17.6.3 Displaying/Clearing a Data Block Display Graph

♦ Disp.

Store the number of data that will display on the graph in [Number of Channel Data Storage Address] and set the data channels after [Data Storage Start Address]. Then write "1" to the [Control Word Address] (turn ON bit 0).



Clear

Write "2" to the [Control Word Address] (turn ON bit 1). The displayed graph is cleared.



Clear and Display

Write "3" to the [Control Word Address] (turn ON bit 0 and bit 1). After the displayed graph is cleared, the graph is redisplayed with the currently stored data.



17.7 Settings Guide

17.7.1 Graph Part Settings Guide

💰 Graph		×
Parts ID GR_0000 # Comment Select Shape No Shape	Basic Color Scale Graph Type Image: Color Scale Image: Color Scale Normal Graph Statistical Graph Image: Color Scale Normal Graph Statistical Graph Image: Color Scale Monitor Word Address [PLC1]D00000 Image: Color Scale Data Type 16 Bit Bin Bit Length 16 Data Type 16 Bit Bin Bit Length 16 Specify Input Range Ipplay Range Ipplay Sign +/- Input Sign None Image: Color Scale Min: Image: Color Scale Image: Color Scale Graph Shape Graph Shape Ear Graph Display Direction Graph Shape Image: Color Scale Image: Color Scale Input Scale Image: Color Scale Image: Color Scale Graph Shape Barght Display Direction Top Image: Color Scale Input Scale Image: Color Scale Show Fill Show Scale	

Setting	Description
Part ID	Placed parts are automatically assigned an ID number. Graph ID: GR_**** (4 digits) The letter portion is fixed. The number portion can be modified from 0000 to 9,999.
Comment	The comment for each Part can be up to 20 characters long.
Part Shape	Displays the shape that you chose for the part with [Select Shape].
Select Shape	Open the Select Shape dialog box to choose the Part shape.
No Shape	Select whether or not the part will be transparent with no shape. This can only be set when the [Graph Type] set to [Normal Graph] or [Statistical Graph].
Graph Type	 Select the Graph type. Normal Graph Displays a specified address' current value in the graph. "17.7.1 Graph Part Settings Guide INormal Graph" (page 17-25) Statistical Graph Statistics are taken from data stored in multiple consecutive addresses starting from a set address and displayed on the graph. "17.7.1 Graph Part Settings Guide I Statistical Graph" (page 17-34) Meter Graph Displays a specified address' current value with a moving needle. "17.7.1 Graph Part Settings Guide I Meter Graph" (page 17-36)

Normal Graph

♦ Basic Settings

Basic Color Scale
Graph Type
Normal Graph Statistical Graph Meter Graph
Monitor Word Address [PLC1]D00000
Data Type 🛛 16 Bit Bin 💌 Bit Length 🛛 16 📰 🏢
Specify Input Range Display Range
Input Specification Constant 🔽 🗖 Display Sign +/-
Input Sign None Min.
Min. 0 🗮 🗰 Max. 100
Max. 100 📰 🏢
Graph Shape
Graph Shape Bar Graph 💌 Display Direction Top 💌
E Hole 20 📰 🗰 🔽 Show Fill E Show Start Point
OK (<u>O</u>) Cancel

Setting		Description	
Monitor W	ord Address	The data stored in this Word Address is displayed in the graph.	
Data Type		Select the graph display data type from [16 Bit Bin], [16 Bit BCD], [32 Bit Bin], [32 Bit BCD], or [32 Bit Float].	
Bit Length		If [Data Type] is [16 Bit Bin], set the data's enabled bit length from 1 to 16.	
Specify Input Range	Input Specificatio n	Choose how the input range's max and min values is specified. Constant Designate a set constant as the Min/Max. Address Designate the address where the Min/Max values are stored. Specify Input Range Input Specification Address Input Sign None Input Sign Input S	

Continued

Setting		Description					
	Input Sign	 Set whether graph display data can handle negative numeric data. This can only be set when the [Data Type] is [16 Bit Bin] or [32 Bit Bin]. None Only positive numeric data will be handled. 2's Complement Negative numbers are handled with 2's complement. MSB Sign Negative numbers are handled with MSB sign. 					
		Select the input ra [Constant], set a m Word Address who Each [Data Type]	nge for graph d nin value/max v ere the min valu and [Input Sign	isplay data. If [Input Specification] is value. If [Address] is set, specify the ue/max value are stored. I] has a different size range.	is		
Specify		Data Type	Input Sign	Range			
Input			None	0 to 65535			
Range		16 Bit Bin	2's Complement	-32,768 to 32,767			
			MSB Sign	-32767 to 32767			
	Min. Value/		None	0 to 4294967295			
	Max. Value	32 Bit Bin	2's Complement	-2147483648 to 2147483647			
			MSB Sign	-214748364 7 to 2147483647			
		16 Bit BCD	-	0 to 9999			
		32 Bit BCD	-	0 to 99999999			
		32 Bit Float	-	-9.9e ¹⁶ to 9.9e ¹⁶			
		• Word address da displayed on the	ta is convert to graph as a valu	correspond to the input range, and is the between 1 and 1,000.	.S		
Display Range		specify whether or not negative numbers can be displayed. This can be set when the [Data Type] is [Bin] or [Float]. e.g.: For a Bar Graph					
	Display Sign +/-	Display Sign +/- Displa					
	Min. Value/ Max. Value	Shows the display range's Min and Max. If [Display Sign +/-] is set, the Min is displayed as "-100". If it is not set, the Min is displayed as "0". The Max is fixed as "100".					

Continued

Setting		Description			
Graph Type	Graph Shape	Choose the graph shape from [Bar Graph], [Circle Graph], [Semicircle Graph], and [Tank Graph].			
	Display Direction	Set a direction for the graph display. If the [Graph Shape] is [Bar Graph] or [Tank Graph], choose from [Top], [Bottom], [Left], or [Right]. For [Circle Graph] and [Semicircle Graph], the starting point is fixed at the top and rotates clockwise.			
	Hollow Circle	 When the [Graph Shape] is [Circle Graph] or [Semicircle Graph], set the radius of the inner circle. NOTE If you set the radius of the inner circle to less than 20 dots, the graph may not be properly displayed. 			
	Show Fill	Set whether or not to display a fill in the graph. If you do not want to display a fill, the graph is set to a Meter Graph.			
	Show Start Point	If the [Graph Shape] is [Circle Graph] or [Semicircle Graph] and [Show Fill] is not set, select whether or not to display the start point.			

♦ Color/Basic

Basic Color Scale	
	<u>>>Extended</u>
Display Color Blink	_
□ 1 None	
Pattern	
None	
1	
Border Color Blink	
None 💌	
Background Color Blink	
None 💌	_
Alarm Settings	

Setting	Description
	Select the display color for the graph.
Display Color	If [Show Fill] is not selected and a Meter Graph is used, the color set
	becomes the needle color.
Pattern	Select the graph pattern.
Pattern Color	Select the pattern color.
	Select a color for the graph border.
Border Color	NOTE
	• Some settings cannot be set depending on the part shape.
	Select the background color for the graph.
Background Color	NOTE
	• Some settings cannot be set depending on the part shape.
	Select whether or not the Part blinks and the blink speed. You can choose
	different blink settings for the [Display Color], [Pattern Color], [Border
	Color], and [Background Color].
Blink	NOTE
	• There are cases where you can and cannot set Blink depending on the
	Main Unit and System Settings' [Color].
	[™] "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34)
Graph Display Sample	Displays a sample of how the graph appears with the [Display Color].
	Continued

Setting		Description			
Alarm		Set the graph's color changes when the value goes outside of the set range.			
		✓ Alarm Settings Alarm Action Constant ✓ Alarm Range Alarm Range Alarm Color Lower Limit Display Color Blink 0 ● ● Upper Limit Pattern Color Blink 100 ● ● ✓ ▼ None			
		 NOTE This cannot be set when the detail settings' [Ranges] is 2 or more. This cannot be set when detail settings' [Color Specification] is set to [Address]. 			
	Alarm Action	Choose how the alarm range's upper and lower limit value are specified • Constant Designate a set constant as the Min/Max value. • Address Designate the address where the Upper/Lower Limit values are stored. V Alarm Settings Alarm Action Address V Alarm Range Alarm Lower Limit Display [PLC1]D00001 V 7 Upper Limit Patterr [PLC1]D00002 V 7 7			
	Upper Limit/ Lower Limit	Set the upper and lower limits for the Alarm Range from 0 to 100 (with [Display Sign +/-] selected, from -100 to 100). If [Alarm Action] is [Constant], enter an upper/lower limit value. If [Address] is set, specify the Word Address where the upper/lower limit value are stored.			
	Display Color	Select the graph display color for when the alarm is displayed.			
	Pattern Color	Select the pattern color for when the alarm is displayed.			
	Blink	 Select whether or not the Part blinks and the blink speed. You can choose different blink settings for the alarm display's [Display Color] and [Pattern Color]. NOTE There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. "9.5.1 Setting Colors = List of Available Colors" (page 9-34) 			

Color/Extended

You can set the data range and have the Graph's color change according to that range.

≫Basic
Demons D Reserve Demons O to the Demons
Ranges p 🔄 🧾 opecity Range Constant 💌
Range Settings
Range Number 0<=Range1<33
Min.
Max. 33 🗄 🏛 s
Color Specification
Constant 🔄 🗖 Color Stack
Display Color Blink 2
Pattern
Border Color Blink Background Color Blink
7 V None V None V
Alarm Settings

Setting		Description
Ranges		Set the number of ranges the graph display is divided into, from 1 to 16.
Specify Range		 Select the method to designate the Min. and Max. of each range if [Ranges] is more than 2. If [Ranges] is 1, this value is automatically set to [Constant]. Constant Designate a set constant as the Min/Max. Address Designate the address where the Min/Max values are stored.
Range Number		Select the set range for Min. and Max and color within the range specified in [Ranges]. You can select by clicking the range you want to specify on the graph display sample. Display as "(Min.) <= Range No. <= (Max.)".
	Min. Value/ Max. Value	Set the Min. and Max. value range selected in [Range Number] between 0 to 100 percentage value. (If the [Display Sign +/-] is specified, between - 100 to 100.) If [Specify Range] is specified as [Constant Input], input the Min. value and Max. value. If [Specify Range] is specified as [Address], specify the word address storing the Min. value and Max. value. Default sets the Min. and Max. values to equalize each range.

Continued

Setting		Description				
Range Settings	Color Specificatio n	Select the designation method of the display color and pattern for the range selected with [Range Number]. If the [Ranges] is 2 or greater or [Color Stack] is set, this will be fixed as [Direct]. Constant Individually designate the display color and pattern. Address Set the address which will store the color code and pattern code. Color Specification Address Display Color [PLC1]D00001 Pattern [PLC1]D00				
	Color Stack	Specify whether or not each range is color-coded when displayed. This can only be set if the [Ranges] is "2" or more. Ranges = 2 Color Stack Range 2 Range 1 Range 1 and Range 2 are displayed with a unique color. Both Range 1 and Range 2 are displayed with Range 2's color.				

Changing the Graph Color from a Device/PLC

In the address set in [Display Color], the lower 16 bits store the color code, and the upper 16 bits store the pattern color.

In the next address after the [Display Color], the lower 16 bits store the pattern code.

	15	87	0
Designated Display Color Address	Pattern Color	Display Color	
+1	(0 Fixed)	Pattern	

Color Code

The color code is the number displayed on the color palette. ⁽²⁾ "9.5.1 Setting Colors ■ Defining Colors" (page 9-35)

Pattern Code

Stored Value	0	1	2	3	4	5	6	7	8
Pattern									8

For example, Display Color: D100



Scale

Basic Color Scale	
Show the Major Scale	
Show Minor Scale	
Scale Divisions 5	
Scale Color Blink	
5 None	

Setting		Description			
Show the Major Scale		Shows the Major Scale.			
	Scale Divisions	Set the number of scale divisions to be displayed from 1 to 100.			
Show Minor Scale		Designate whether or not to display a small scale to further divides the large scale.			
	Scale Divisions	Set the number of scale divisions to be displayed from 2 to 100.			
Scale Cold	or	Select the display color for the scales.			
Blink		 Select whether or not the [Scale Color] blinks and the blink speed. NOTE There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. "9.5.1 Setting Colors List of Available Colors" (page 9-34) 			

Statistical Graph

Basic Settings

Basic Color Scale
Graph Type
Normal Graph Statistical Graph Meter Graph
Monitor Word Address [PLC1]D00000
Data Type 16 Bit Bin 💌
Graph Shape Graph Shape Bar Graph I Display Direction Top I Hole 20

Setting	Description		
Monitor Word	Select the top Word Address from where the statistical data is taken. Addresses from this address to the portion designated in the [Color] tab's		
Address	[Data Divisions] are automatically allotted and that address range is displayed.		
	Select the graph display data type from [16 Bit Bin], [16 Bit BCD], [32 Bit Bin], [32 Bit BCD], or [32 Bit Float].		
Data Type	NOTE		
	• Different data formats can not be used within the same Statistical Graph.		
Graph Shape	Choose the Graph shape from [Bar Graph] or [Circle Graph].		
	Set a direction for the graph display. If the [Graph Shape] is [Bar Graph], you can choose from [Top], [Bottom], [Left], or [Right].		
Display Direction	NOTE		
	• For [Circle Graph], the starting point is fixed at the top and rotates		
	clockwise. If you want to change the starting point, rotate the part.		
	When the [Graph Shape] is [Circle Graph], set the radius of the inner		
Hollow Circle	NOTE		
	• If you set the radius of the inner circle to less than 20 dots, the graph may not be properly displayed.		

♦ Color

Basic Color Scale	
Data Divisions 🛛 🗧 🧮	4
Division Settings Division Number2 Disclar: Calar Division	3
Pattern	2
None	
Border Color Blink	Background Color Blink
☐7 ▼ None ▼	■1 Vone V

Setting		Description		
Data Divisions		Set the number of sections for displaying your data on the graph from 1 to 16. Statistics are taken from consecutive address data starting from the address set in [Monitor Address] for the set number of sections.		
	Division Number	Displays the division number selected in the Graph Display Sample. The Division Number depends on the Display Direction, and is assigned automatically in order from the top address.		
Division Settings	Display Color	Set a color for each division by clicking each numbered section in the graph displayed on the right side.		
	Pattern	Select the pattern for each division from among 9 types.		
	Pattern Color	Select a pattern color for each division.		
Border Color		Select a color for the graph border. NOTE • Some settings cannot be set depending on the part shape		
Background Color		Select the background color for the graph. This color will be displayed when all data is 0. NOTE • Some settings cannot be set depending on the part shape.		
Blink		 Select whether or not the Lamp blinks and the blink speed. You can choose different blink settings for the [Display Color], [Pattern Color], [Border Color], and [Background Color]. NOTE There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. * "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34) 		
Graph Dis	play Sample	Displays a sample of how the graph appears with the [Display Color].		

- Meter Graph
- ♦ Basic Settings

Basic Color Scale					
Graph Type					
Monitor Word	Address [PLC1]D00000				
Data Type	16 Bit Bin 💌 Bi	t Length 16 🚊 🏢			
-Specify Inpu	ut Range — D	isplay Range			
Input Sign	None 🔽	Display Sign +/-			
Min.		Min.			
Max.	100	Max. 100			
Display Dire	ection Rotate Right 💌				

Setting		Description
Monitor Word Address		The data stored in this Word Address appears in the Meter Graph.
Data Type		Select the graph display data type from [16 Bit Bin], [16 Bit BCD], [32 Bit Bin], [32 Bit BCD], or [32 Bit Float].
Bit Length		If [Data Type] is [16 Bit Bin], set the data's enabled bit length from 1 to 16.
Specify Input Range	Input Sign	 Set whether graph display data can handle negative numeric data. This can only be set when the [Data Type] is [16 Bit Bin] or [32 Bit Bin]. None Only positive numeric data will be handled. 2's Complement Negative numbers are handled with 2's complement. MSB Sign Negative numbers are handled with MSB sign.

Continued
Setting		Description				
		Select the input range for graph display data. Each [Data Type] and [Input Sign] has a different size range.				
		Data	Туре	Input Sign	Range	
				None	0 to 65535	
		16 Bit	t Bin	2's Complemen t	-32,768 to 32,767	
				MSB Sign	-32767 to 32767	
.				None	0 to 4294967295	
Specify Input Range	Min. Value/ Max. Value	32 Bit	t Bin	2's Complemen t	-2147483648 to 2147483647	
				MSB Sign	-2147483647 to 2147483647	
		16 Bit	t BCD	_	0 to 9999	
		32 Bit	t BCD	_	0 to 99999999	
		32 Bit	t Float	-	$-9.9e^{16}$ to $9.9e^{16}$	
		 • Word address data is convert to correspond to the input range, and is displayed on the graph as a value between 1 and 1,000. 				
	Display Sign +/-	Set if the graph should display positive or negative numeric data. This can only be set when the [Data Type] is [16 Bit Bin], [32 Bit Bin], or [32 Bit Float].				
		Display Sign +/-				
Display Range		Negative numbers				
		displayed displayed				
	Min. Value/ Max. Value	Shows the display range's Min and Max. If [Display Sign +/-] is set, the Min is displayed as "-100". If it is not set, the Min is displayed as "0". The Max is fixed as "100".				ıe
	Display Direction	Select the graph display direction from [Rotate Right] or [Rotate Left].				

♦ Color

Display Color Blink 4 None Border Color Blink 7 None Background Color Blink 7 None None To None Background Color Blink	Basic Color Scale	
Alarm Settings	Display Color 4 Border Color 7 Background Color 7 Alarm Settings	Blink None Blink None Blink None

Setting		Description		
Display Color		Select the color for the needle.		
Border Color		Select a color for the graph border.		
Backgrou	nd Color	Select the background color for the graph.		
Blink		 Select whether or not the Part blinks and the blink speed. You can choose different blink settings for the [Display Color], [Border Color], and [Background Color]. NOTE There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. * "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34) 		
Alarm		Set whether or not the needle color changes when the value moves from one range to another range.		
Alarm Range	Alarm Action	Choose how the alarm range's upper and lower limit value are specified. Constant Designate a set constant as the Min/Max value. Address Designate the address where the Upper/Lower Limit values are stored. Image: Image: Ima		

Setting		Description		
	Upper Limit/ Lower Limit	Set the upper and lower limits for the Alarm Range from 0 to 100 (wi [Display Sign +/-] selected, from -100 to 100). If [Alarm Action] is [Constant], enter an upper/lower limit value. If [Address] is set, specify the Word Address where the upper/lower lim value is stored.		
Alarm	Display Color	Select the needle color displaying the alarm.		
Range	Blink	 Select whether or not the [Display Color] blinks when the alarm appears and the blink speed. NOTE There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. "9 5 1 Setting Colors. List of Available Colors" (page 9-34) 		

17.7.2 Historical Trend Graph Settings Guide

Sampled data taken at regular or random intervals can be displayed on a Line Chart. "24.8.1 Common [Sampling] Settings Guide" (page 24-37)

💰 Historical Trend G	raph	X
Parts ID HT_0000 == Comment	Graph Display Area Color Limit Colors Display Historical Data Graph Type I Mormal Pen Recorder	
Select Shape	Group Number Number of Channels Channel Settings 1 Channel Settings 1 Channel Number of Channels	
	Input/Display Settings	
	Input Range Input Sign None Display Range Min. Display Sign +/- Min. Max. 55535 Max. 100	
Help (<u>H</u>)	Cancel	

Setting	Description
Part ID	Parts in the window are automatically assigned an ID number.Historical Graph ID: HT_**** (4 digits) The letter portion is fixed. The number portion can be modified from 0000 to 9,999.
Comment	The comment for each Part can be up to 20 characters long.
Part Shape	Displays the shape that you chose for the part with [Select Shape].
Select Shape	Open the Select Shape dialog box to choose the Part shape.
No Shape	Select whether or not the part will be transparent with no shape.

Setting	Description
	 Select the line shape from [Normal] or [Pen Recorder]. Normal The specified word address data changes are displayed over time in a Line Chart. Data at the start time is "0". As each sampling period elapses, the latest data is added in the specified [Display Direction]. When the graph line reaches the limit of the Display Area, the graph is shifted in the display direction for the number of units set in [Samples to Scroll].
	e.g.: Display Direction: Bottom Left→Rotate Right, Data Samples: 4, Samples to Scroll: 4
	Screen scrolls at this point.
Graph Type	$ \begin{array}{c} \hline \\ \hline $
	Start 30 25 60 40 20
	 Pen Recorder The specified word address data changes are displayed over time in a Line Chart. Data at the start time is "0". The latest data always appears at the edge of the Display Area. Each time sampling occurs, the whole graph scrolls 1 spot in the set [Display Direction]. e.g.: Display Direction: Bottom Left→Rotate Right. Data Samples: 4
	e.g.: Display Direction. Bottom Lent \rightarrow Kotate Kight, Data Samples. 4 $ \begin{array}{c} $

Normal/Pen Recorder

♦ Graph/Basic

Graph Display Area Color Limit Colors Display Historical Data
Graph Type
Normal Pen Recorder
Group Number Number of Channels >>Extended
Channel Number 1
Input/Display Settings
Data Type 16 Bit Bin 💌
Input Sign None Display Sign +/-
Min. 🛛 🖂 🏢 Min.
Max. 65535 📰 Max. 100
OK (<u>O</u>) Cancel

Setting	Description		
Sampling Group	The sampling group number from 1 to 64 of the graph to display.		
Channel Settings	Open the [Channel Data Settings] dialog box appears. From among the designated sampling group, set the address and number of addresses (Number of Channels) of the line you want to display. The Number of Channels can be from 0 to 20.		
Number of Channels	The set Number of Channels appears in the [Channel Data Settings] dialog box. The number of channels is displayed as lines on the Graph Display Area.		
	Continued		

GP-Pro EX Reference Manual

Setting	Description			
Channel	Select the Channel to process Input/Display.			
Data Type	Select the graph display data type from [16 Bit Bin], [16 Bit BCD], [32 Bit Bin], [32 Bit BCD], or [32 Bit Float].			Bit
Input Sign	 Set whether graph display data can handle negative numeric data. This can only be set when the [Data Type] is [16 Bit Bin] or [32 Bit Bin]. None Only positive numeric data will be handled. 2's Complement Negative numbers are handled with 2's complement. MSB Sign Negative numbers are handled with MSB sign. 			
	Select the input range	for Line Char	t display data.	
	Each [Data Type] and	[Input Sign] h	as a different size range.	
	Data Type	Input Sign	Range	
	16 Bit Bin	2's Complemen t	-32,768 to 32,767	
		MSB Sign	-32767 to 32767	
		None	0 to 4294967295	
Min. Value/Max. Value	32 Bit Bin	2's Complemen t	-2147483648 to 2147483647	
		MSB Sign	-2147483647 to 2147483647	
	16 Bit BCD	-	0 to 9999	
	32 Bit BCD	-	0 to 99999999	
	32 Bit Float	-	$-9.9e^{16}$ to $9.9e^{16}$	
	 NOTE Data collected from the sampling function corresponds to the input range and is displayed on the graph as a value between 1 and 1,000. 			
	Specify whether or not set when the [Data Typ When the [Data Type] [Display Sign +/-] is set	t negative num pe] is [Bin]. is [BCD], [D et.	nbers are displayed. This can only be isplay Sign +/-] is not set. For [Float	e t],
Display Sign +/-	Display Sign	+/-	Display Sign +/- 100 50 0 Negative numbers not	
	Negative numbers Negative numbers not displayed displayed			

Setting	Description
Min. Value/Max. Value	Shows the Min and Max for data displayed on the Trend Graph. If [Display Sign +/-] is set, the Min value is "-100". If it is not set, the Min is "0". The Max. Value is "100".

Graph/Extended

You can set Input/Display for each channel.

Graph Display Area Color Limit C	olors Display Historical Data
Graph Type	
-wh	
Normal Pen Recorder	
Group Number	Number of Channels Seasid
Channel Number 1	•
Input/Display Settings	
💿 Block 🛛 🔿 Individual	
Data Type 🛛 16 Bit Bin 💌	Bit Length 👖 📑 🏢
-Input Range	Display Range
Input Sign None 💌	🗖 Display Sign +/-
Min. 🛛 🔁	Min.
Max. 65535	Max. 100
	OK (Q) Cancel

Setting	Description
Block/Individual	Define the [Input/Display] for all the channels as a whole or separately.
Bit Length	If [Data Type] is [16 Bit Bin], set the data's enabled bit length from 1 to 16.

Display Area

Graph Display A	Area Color Limit (Colors Display Histo	orical Data
Display Directio	n 🖂 Bottom Left	Corner -> Rightward	•
Data Samples	10 🗄 🏢	Samples to Scroll	비 문 역
-Scale Divisions	;		
Vertical Major Scale	2 🗄 🏢	Vertical Minor Scale	ē 😑 🏯
Horizontal Major Scale	2 🗄 🏢	Horizontal 🗖 🗖	5 <u>;</u>

Setting	Description		
	Select the graph display direction.		
Display Direction	<u>ane</u> Na		
	Set the number of data samples to depends on the set model's Displa	be displayed on a single li ay Number of Dots.	ne. The range
	Display Number of Dots	Data Samples	
	320 x 240 dots (QVGA)	0 to 319	
	640 x 480 dots (VGA)	0 to 639	
	800 x 600 dots (SVGA)	0 to 799	
Data Samples	1024 x 768 dots (XGA)	0 to 799	
	 NOTE You can verify the Display Number of Dots with [System Settings] - [Display]. When [Fill Below Line] is set, the maximum number of [Data Samples] is 97. 		
Samples to Scroll	Select the number of data to remove when the graph fills the Display Area. This can only be set when the Graph Type is [Normal]. Set this within the range designated by [Data Samples].		
Vertical Major Scale/ Minor Scale	Set whether or not to display the major and minor scale on the Line Chart's Y-axis. If so, choose the number of divisions. The number of divisions can be set from 1 to 638 for Major Scale, and from 2 to 638 for Minor Scale.		
Horizontal Major Scale/Minor Scale	Set whether or not to display the major and minor scale on the Line Chart's X-axis. If so, choose the number of divisions. The number of divisions can be set from 1 to 638 for Major Scale, and from 2 to 638 for Minor Scale.		

♦ Color/Basic

Graph Display Area Color Limit Colors Display Historical Da	ta
Channel Number 1 SExtended	<u>1</u>
Channel Color	
Line Type -Solid Line 💽 Line Thickness 1	<u>=</u>
Display Color Blink	
Border Color Blink Scale Color Blink	
7 Vone 5 Vone	-
Graph Area Color Blink	
None 💌	

Setting	Description
Channel	Select the Channel to configure.
	Select the type of line from among 5 kinds: Solid Line, Dashed Line, Dash Line, Chain Line, and Two-Dot Chain Line.
Line Type	NOTE
	• When the data display spacing is less than 16 dots, line types other than the solid line may not display correctly.
Line Thickness	Set the line thickness from 1 to 2.
Display Color	Set the line color.
Background Color	Set the line's background color.
	Set the border color of the Historical Trend Graph.
Border Color	NOTE
	• Some settings cannot be set depending on the part shape.
	Select the graph's scale color.
Scale Color	NOTE
	• Some settings cannot be set depending on the part shape.
Graph Area Color	Select a color for the Graph Display Area.
	Select whether the Part blinks and the blink speed. You can choose different blink settings for [Display Color], [Background Color], [Border Color], [Scale Color], and [Graph Area Color].
Blink	
	• There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]
	[™] "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34)

♦ Color/Extended

Graph Display Area Color Limit Colo	rs Display Historical Data
Channel Number 1	<u>≫Basic</u>
Channel Color	
Line Type 🛛 — Solid Line 🔄	🛚 Line Thickness 👖 🚞 🧱
Display Color Blink	
□ 7 💌 None 💌	
Border Color Blink Sc	ale Color Blink
7 🔽 None 🔽	5 🔽 None 🔽
Graph Area Color Blink	
– 🗹 Fill Below Line – – – – – – – – – – – – – – – – – – –	
Pattern	•
Pattern Color 1 Blink Pa	attern Color 2 Blink
7 _ None _ ■	0 Vone

Setting	Description
	Select whether or not to fill in the area under the Line Chart. This can only
	be set when [Number of Channels] is 1.
Fill Below Line	NOTE
	• This can not be set when alarms are being used.
Pattern	Select a pattern for filling the area below the graph line.
Pattern Color 1	Select the pattern color.
Pattern Color 2	Set the pattern's background color.
	Select whether or not the Part blinks and the blink speed. You can choose
	different blink settings for [Pattern Color 1] and [Pattern Color 2].
Blink	NOTE
	• There are cases where you can and cannot set Blink depending on the
	Main Unit and System Settings' [Color].
	^I "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34)

♦ Alarm

Graph Display Area Color Limit Colors Display Historical Data	
Channel Number 1	
Alarm Settings	
Alarm Range Lower Limit Designed Upper Limit Designed	
Alarm Color	
Display Color 📃 7 👻 Blink None 💌	
Background Color 🔲 Blink None 💌	

Setting	Description		
Channel	Select the Channel to configure.		
Alarm	If set, the displayed color changes when the value moves outside of a designated range.		
Upper Limit/Lower Limit	Set the Alarm Display range from 0 to 100 (with [Display Sign +/-] selected, from -100 to 100).		
Display Color	Select the Alarm Display color. The Alarm Display color appears as follows. For example, Upper Limit = 80, Lower Limit = 30 Sampling Data 1st Sample 2nd Sample 2th Sample 50 50 50 50 50 50 50 50 50 50		
Background Color	Select the background color for displaying the alarm.		
Blink	 Select whether or not the Part blinks and the blink speed. You can choose different blink settings for the alarm colors [Display Color] and [Background Color]. NOTE There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. "9.5.1 Setting Colors I List of Available Colors" (page 9-34) 		
Color Range Display Bar	Displays a sample of how the color in each range appears. Any alarm ranges specified in [Alarm] are also displayed.		

Display Historical Data

Configure settings for displaying Historical Data.

Graph Display Area Color I	Limit Colors Display	Historical Data
🔽 Display Historical Data		
-Switch Layout		
🔽 Display Historical Data		
🔽 Scroll for Old Data	Samples to Scroll	
Scroll for New Data	Samples to Scroll	

Setting			Description
Display Historical Data		ical Data	Set whether or not to display historical data.
	Display Historical Data		Set whether or not to place a switch on the screen to display historical data. Pressing the switch displays the Display Historical Data mode. You can scroll back to previous data on the display. Pressing the switch again cancels Display Historical Data mode and the current values are displayed. Only one switch of this kind can be placed on a Graph using Display Historical Data.
Switch Layout	Scroll for Old Data Samples to Scroll		Set whether or not to place a switch to scroll backward from current to historical data. Multiple switches of this kind can be placed on a Graph.
	Samples to Scroll		Set the no. of samples to scroll. The value can be from 1 to 65535.
	Scroll for New Data		Set whether or not to place a switch to scroll forward from historical data to the most current data. Multiple switches of this kind can be placed on a Graph.
		Samples to Scroll	Set the no. of samples to scroll. The value can be from 1 to 65535.

If a switch for Display Historical Data is created, you can set the color and labels for these switches.

💰 Historical Trend G	raph 🛛
Parts ID HT_0000 💮 Comment Select Shape No Shape ABC Select Shape	Graph Display Area Color Limit Colors Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Historical Data Image: Display Display Display Display Color Image: Display Display Color Image: Display Display Color Image: Display Color Image: Display Display Color Image: Display Display Color Image: Display Display Color Image: Display Color Image: Display Color Image: Display Display Color Image: Display Display Color Image: Display Color Image: Display Display Color Image: Display Display Color Image: Display Display Color Image: Display Color Image: Display Color Image: Display Color Image: Display Color Image: Display Color Image: Display Color Image: Display Color Image: Display Color Image: Display Color
Help (<u>H</u>)	OK (Q) Cancel

Setting		Description	
Switch Label	Font Type	Set the font type for the switch label from [Standard Font] or [Stroke Font].	
	Display Language	Select the language that to display on the switch label. Choose from [ASCII], [Japanese], [Chinese (Traditional)], [Chinese (Simplified)], [Korean], [Cyrillic], or [Thai].	
	Select Switch	Select the Switch whose label you want to set.	
	Label	Enter the text to display on the switch.	
	Text Color	Set a color for the label text.	
	Blink	Select whether or not the [Text Color] blinks and the blink speed.	
Switch Color	Border Color	Set the border color for the switch.	
	Display Color	Set the color for the switch.	
	Pattern	Set the pattern for the switch.	
	Pattern Color	Set the pattern color for the switch.	
	Blink	Select whether or not the Part blinks and the blink speed. You can choose different blink settings for the [Border Color], [Display Color], and [Pattern Color].	
		 There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. ^{CP} "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34) 	
Select Sha	pe	Open the Select Shape dialog box to choose the switch shape.	
Status Display		Displays the shape and status of the switch.	

Display Historical Data

To execute historical data display on the GP display, you need the historical data operation switch. You can specify the location of the switch on the historical trend graph or use the switch lamp parts [Special Switch].

When using a Historical Trend Graph featuring the Display Historical Data function, the excluded dotted-line portion is displayed on the GP screen. By touching the Display Historical Data Switch, past data stored in the GP can be viewed on the graph display.

For example, Number of Samples Taken: 14, Data Samples (shown): 6



Data Samples

Data samples consist of data numbers and data values. Data Numbers are assigned to data values, with the most recent data value designated as Data Number 0. The data values are stored by data number and are in reverse chronological order, starting with the most recent numbered as "0", followed by "1", "2", "3", etc.

When a Historical Trend Graph with the Display Historical Data function is displayed on the GP, the historical data samples (picture portion A) and the historical data samples (picture portion B) are automatically stored in the Special Relay Area (LS9000~) in the GP Internal Device. Data numbers are stored in the LS area as binary numbers in the range of 0 to 65,237. The data type is Bin.

To understand the data sampling in the drawing above, the data numbers and data values of portion A and B are displayed below.

The data samples and data values are stored even if a graph is not in Display Historical Data mode.



 When a screen change occurs, all data samples stored in the Special Area (LS9000+) of the GP internal device are cleared to 0. Each inputted data is converted to the display value and saved as a ratio of 1000 (from 0 to 1000). When [Display Sign +/-] is selected, the display value range is -1000 to 1000. To display the data value "200" as "20.0" in a Data Display, set the [Decimal Places] to "1".

Display Historical Data Examples



Touching the "Back" switch scrolls the data backward by the predetermined scroll number and displays previous data records.

Touching the "Back" switch while the historical data samples are being retrieved from backup SRAM causes the buzzer to sound three times. The data cannot be scrolled further until the data samples are retrieved.



Touching the "Fwd" switch scrolls the data forwards the recent data samples by the predetermined scroll number.

When you scroll to the most recent data samples after changing to Display Historical Data mode, the graph will appear blank. Touching the [FWD] switch again causes the buzzer to sound three times, indicating data cannot be scrolled further.



Data samples are still taken in Display Historical Mode.



17.7.3 Data Block Display Graph Settings Guide

Displays the current values of multiple addresses on a single graph.

💣 Data Block Displa	y Graph X
Parts ID LG_0000	Graph Display Area Color Limit Colors Number of Channels
Select Shape	Input/Display Settings Data Type 16 Bit Bin Input Range Input Sign None Min. Max.
Help (<u>H</u>)	OK (<u>O</u>) Cancel

Setting	Description
Part ID	Placed parts are automatically assigned an ID number. Data Block Display ID: LG_**** (4 digits) The letter portion is fixed. The number portion can be modified from 0000 to 9,999.
Comment	The comment for each Part can be up to 20 characters long.
Part Shape	Displays the shape that you chose for the part with [Select Shape].
Select Shape	Open the Select Shape dialog box to choose the Part shape.
No Shape	Select whether or not the part will be transparent with no shape.

■ Graph/Basic

Graph Display Area Color 1	Limit Colors]	
Number of Channels 1	· #	<u>>>Extended</u>
Channel Number 1	•	
Control Word Address	[PLC1]D00100	
Number of Channels Address	[PLG1]D00101	
Data Storage Start Address	[PLC1]D00102	
Input/Display Settings Data Type 16 Bit Bin	Contract Contract	
Input Range	Display Rane	ge
Input Sign None	🔽 📃 🗖 Display S	ign +/-
Min. P	🗄 🏢 🛛 Min. 🛛	0
Max. 65535	🗄 🧾 Max. 🛛	100

Setting	Description	
Number of Channels	Select the number of channels to display on the graph. The value can be from 1 to 20.	
Channel	Choose the channel (data line) to configure. Change to the numbers of the channels set in [Number of Channels] and set input/display settings.	
	Set the address that controls the displaying/clearing of the graph. This address' bit 0 and bit 1 control when the graph is displayed and cleared.	
	• When "1" is stored in the address (bit 0 is ON), the graph will be displayed.	
	Control 15 03 02 01 00	
	• When "2" is stored in the address (bit 1 is ON), the displayed graph will be cleared.	
Control Word Address	Control 15 03 02 01 00	
	• When "3" is stored in the address (bit 0 and bit 1 are ON), the displayed graph will temporarily be cleared and then displayed again.	
	Control 15 03 02 01 00	
	This can be set to either a device/PLC address or GP internal device address.	
	Continued	

Setting		Description	
Number of Channel Data Storage Address		Displays the address at [Control Word Address] + 1. This address stores the number of data lines displayed on the graph. On the graph, this will become the number of data samples.	
		For example, Number of data entries: 7	
		Data 1 1 1 1 1 1 1 1 1 1 1 1 1	
Data Storage Start Address/Offset Value Storage Address		Displays the address at [Control Word Address] +2. This address is the start address that stores the data displayed on the graph. When an [Offset] is set, this changes to the [Offset Value Storage Address].	
	Data Type	 Select the graph display data type from [16 Bit Bin], [16 Bit BCD], [32 Bit Bin], [32 Bit BCD], or [32 Bit Float]. NOTE If [Individual] is selected in the Detail Settings, individual channels settings can be modified. If [Show Scale] is selected in the Detail Settings, only [16 Bit Bin] or [32 Bit Bin] can be set. 	
Input/ Basic Settings	Offset	Select whether or not to display an offset on the graph. ☞ " ◆ Data Block Display Graph Mechanism" (page 17-59)	
	Input Sign	 Set whether graph display data can handle negative numeric data. This can only be set when the [Data Type] is [16 Bit Bin] or [32 Bit Bin]. None Only positive numeric data will be handled. 2's Complement Negative numbers are handled with 2's complement. MSB Sign Negative numbers are handled with MSB sign. 	

Setting		Description			
		Select the input range for graph display data. Each [Data Type] and [Input Sign] has a different size range.			
		Data Type	Input Sign	Range	
			None	0 to 65535	
		16 Bit Bin	2's Complemen t	-32,768 to 32,767	
			MSB Sign	-32767 to 32767	
			None	0 to 4294967295	
	Min. Value/ Max. Value	32 Bit Bin	2's Complemen t	-2147483648 to 2147483647	
			MSB Sign	-2147483647 to 2147483647	
		16 Bit BCD	-	0 to 9999	
		32 Bit BCD	_	0 to 99999999	
		32 Bit Float	-	$-9.9e^{16}$ to $9.9e^{16}$	
Input Display		 NOTE Each word address' data corresponds to the input range and is displayed on the graph as a value between 1 and 1,000. 			
	Display Sign +/-	Set to display neg Type] is [Bin].Wh set. For [Float], [I	ative numbers. The len the [Data Type] Display Sign +/-] is	is can only be set when the []] is [BCD], [Display Sign +/-] s set.	Data is not
		🔽 Displa	y Sign +/-	Display Sign +/-	
			\sim	100 - 50 -	\
		-100	nbers	0 Negative numbers not displayed	-
	Min. Value/ Max. Value	Set the range's Mi +/-] is set, the Min "100".	in/Max to be displant is "-100". If it is	ayed on the graph. If [Display not set, the Min is "0". The M	y Sign Iax is

Data Block Display Graph Mechanism

When using the Data Block Display feature, you need to reserve the areas for the number of addresses specified below, beginning from the specified Control Word Address. The Control Word Address can be set to either a device/PLC address or GP internal device address. Configure offset settings and you can set the graph display data in an address shifted down from the address storing the [Data Items].



When you want to control the graph display from a device/PLC, the graph's display speed will differ depending on if you set the [Control Word Address] to a device address or use the GP Internal Read Area.

When setting a device/PLC address

After the "control" display bit (bit 0) turns ON, the time to read data from the device/PLC to GP and displaying on the graph is longer than the time when the GP Internal Device. However, when the graph is not displayed, the time to display the whole screen is less than with the GP Internal Device.

GP Internal Device When Using the Read Area

The Read Area constantly reads data from the device/PLC to the GP, regardless of screen display status. After the "control" display bit (bit 0) turns ON, the time to display the graph is shorter than when using a device/PLC address. However, when the Read Area size is large, the time to display the entire screen is slower than when using a device/PLC address.

NOTE	• To use the GP Internal Device's Read Area, you need to set the [Read Area Size]. From the [System Settings], click [Main Unit] then check the [System
	Areal. A maximum of 256 words are allowed.

• When setting a device/PLC address and displaying multiple data lines (channel) with Block Display, enable offset settings to improve the graph display speed. By setting all the data in continuous addresses as in the following, data can be easily read in one communication round.



Graph/Extended

Configure input/display settings for each channel's Data Type, Input Sign, etc.

Graph Display Area Color Limit Col	ors
Number of Channels 1	<u>⇒</u> <u>∰</u> >>Basic
Channel Number 1	•
Control Word Address	[PLC1]D00100
Number of Channels Address	[PLC1]D00101
Data Storage Start Address	[PLC1]D00102
Block C Individual Incut/Display Settings	
Display Method Specify Range	▼ Data Type 16 Bit Bin ▼
Bit Length 👖 🗄 🧮	C Offset
Input Range	Display Range
Input Sign None 💌	🗖 Display Sign +/-
Min. 🛛 🗄 🧮	Min.
Max. 65535 🗮 🏢	Max. 100

Setting	Description
Block/Individual	For the Data Type, Input Sign, etc., to change the input/display settings for all channels as a whole or separately. When the [Display Method] is selected as [Show Scale], this setting is fixed as [Block].
Display Method	Set to display a specified range of the graph. When [Show Scale] is set, Alarm and the [Color] tab's [Fill Below Line] option cannot be set. ^(G) " ◆ Show Scale" (page 17-62)
Bit Length	If [Data Type] is [16 Bit Bin], set the data's enabled bit length from 1 to 16.

Show Scale

Displays only the specified range of the graph. When data is concentrated in a fixed range, this is useful for verifying details.



Setting	Description
Data Type	Choose the graph data type from [16 Bit Bin] or [32 Bit Bin].
Offset	Select whether or not to display an offset on the graph. ^(GP) " ◆ Data Block Display Graph Mechanism" (page 17-59)
Display Sign +/-	Set to display negative numbers.

Setting	Desc	ription			
Upper Limit/Lower	Select the method for setting the scale's upper and lower value from [Constant] or [Address], and set the Upper and Lower Limit.Constant				
	 Address Designate the address where the Upper/Lower Limit values are stored. 				
		Data Type	Display Sign +/-	Range	
		16 Bit Bin	Unchecked	0 to 65535	
			Checked	-32,768 to 32,767	
		32 Bit Bin	Unchecked	0 to 4294967295	
			Checked	-2147483648 to 2147483647	
	• If [E Display Sign +/-] nplement system.	is set, negativ	ve numbers are handled with the 2's	

Display Area

Graph Display Area	Color Auxiliary Line
Display Direction	🛃 Bottom Left Corner -> Rightward
Data Samples	
Scale Divisions Vertical Major Scale Horizontal Major Scale	Uertical Minor IZ IS Scale Horizontal Minor Scale IZ IS Minor Scale

Setting	Description		
	Select the graph display direction.		
Display Direction	<u>A</u> NK <u>A</u>		
	Set the number of data samples that t	o display on a single line. The range	
	depends on the set model's Display N	lumber of Dots.	
	Display Number of Dots	Data Samples	
	320 x 240 dots (QVGA)	0 to 319	
	640 x 480 dots (VGA)	0 to 639	
Data Camalaa	800 x 600 dots (SVGA)	0 to 799	
Data Samples	1024 x 768 dots (XGA)	0 to 799	
	 NOTE You can verify the Display Number of Dots with [System Settings] - [Display]. When [Fill Below Line] is set, the maximum number of [Data Samples] is 97. 		
Vertical Major Scale/ Minor Scale	Set whether or not to display the major and minor scale on the Line Chart's Y-axis. If so, choose the number of divisions. The number of divisions can be set from 1 to 638 for Major Scale, and from 2 to 638 for Minor Scale.		
Horizontal Major Scale/Minor Scale	Set whether or not to display the major and minor scale on the Line Chart's X-axis. If so, choose the number of divisions. The number of divisions can be set from 1 to 638 for Major Scale, and from 2 to 638 for Minor Scale.		

■ Color/Basic

Graph Display Area Color Auxiliary Line
Channel Number 1
Line Type → Solid Line ↓ Line Thickness ↓ → →
Dot Type Circle
7 Blink None
Border Color Blink Scale Color Blink
1 None

Setting		Description	
Channel		Select the Channel to configure color settings.	
Channel Color Color Color Color Display Color Backgrou Color Pixel Size	Line Type	Select to display the lines on the Graph. Choose a line type from among 5 kinds: Solid Line, Dashed Line, Dash Line, Chain Line, and Two-Dot Chain Line.	
		• When the data display spacing is less than 16 dots, line types other than the solid line may not display correctly.	
	Line Thickness	Set the line thickness from 1 to 2.	
	Display Color	Select the data line color.	
	Background Color	Select the data line background color.	
	Pixel Size	Select to display dots on the Graph. Choose a dot type from among the 7 patterns: filled circle, filled triangle, filled square, circle, triangle, square, and X. The dot size is fixed at 5 pixels. MPORTANT • This cannot be used at the same time as the Detail Settings' [Fill	
	Display Color	Set the dot color. The dot color does change during Alarm Display.	
Border Co	lor	Select the border color of the Data Block Display Graph.	
Scale Cold	or	Select the graph's scale color.	
Graph Are	a Color	Select the color of the Graph Display Area.	

Setting	Description
Blink	Select the Part blinks and blink speed. You can choose different blink settings for the line's [Display Color] and [Background Color], the dots [Display Color], and the Graph's [Border Color], [Scale Color], and [Graph Area Color].
	 There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. "9.5.1 Setting Colors List of Available Colors" (page 9-34)

Color/Extended

Graph Display Area Color Limit Colors	
Channel Number 1 >>Basic	
Channel Color	
🔽 Line Type 🛛 — Solid Line 💽 Line Thickness 🕅 拱 🏢	
Display Color Blink	
None 💌	
Dot Type Oircle	
7 V Blink None V	
Border Color Blink Scale Color Blink	
7 🔽 None 💌 🗖 5 💌 None 💌	
Graph Area Color Blink	
None None	
Fill Below Line	
Pattern None 🗨	
Pattern Color 1 Blink	
□7 ▼ None ▼	

Setting	Description	
Fill Below Line	Select to fill in the area under the Line Chart. This can only be set when	
	[Number of Channels] is 1.	
	NOTE	
	• This can not be set when alarms are being used.	
	• Can not be used with [Show Scale].	
Pattern	Select a pattern for filling the area below the graph line.	
Pattern Color 1	Select the pattern color.	
Pattern Color 2	Select the pattern background color.	
Blink	Select whether or not the Part blinks and the blink speed. You can choose	
	different blink settings for [Pattern Color 1] and [Pattern Color 2].	
	NOTE	
	• There are cases where you can and cannot set Blink depending on the	
	Main Unit and System Settings' [Color].	
	^C "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34)	

Alarm

Configure settings to change the line color when values move outside of a set range.

• When [Show Scale] is set, Alarm cannot be used.

Graph Display Area Color Limit Colors
Channel Number 1
Alarm Settings
-Alarm Range
Lower Limit
Upper Limit 100 🚍 🧱
Alarm Color
Display Color 4 Blink None
Background 7 Blink None

Setting	Description		
Channel	Select the Channel to configure Alarm.		
Alarm	 Select to change the color when the value moves outside of a set range. NOTE This cannot be set if the [Fill Below Line] option is set in the Detail Settings on the Color tab. 		
Upper Limit/Lower Limit	Set the Alarm Display range from 0 to 100 (with [Display Sign +/-] selected, from -100 to 100).		
Display Color	Select the data line color for the alarm.		
Background Color	Select the data line background color for the alarm.		
Blink	 Select whether or not the Part blinks and the blink speed. You can choose different blink settings for the alarm colors [Display Color] and [Background Color]. NOTE There are cases where you can and cannot set Blink depending on the Main Unit and System Settings' [Color]. 		
	[™] "9.5.1 Setting Colors ■ List of Available Colors" (page 9-34)		
Color Range Display Bar	Displays a sample for the alarm colors.		

Auxiliary Line

To use Auxiliary Lines, the [Display Method] must be set to [Show Scale]. This option is located in [Detailed Settings] under the [Graph] tab.

By using auxiliary lines to show the standard value or a range, you can quickly verify which data have moved away from the standard value.

400		Upper Limit Standard Lower Limit
Graph Display Area C	Solor Auxiliary Line	
Upper Limit Standard Lower Limit	Lower Limit Standard	d Upper Limit
Draw Line —		
Specify Display Co Position	nstant 💌 Display Posit	ion 🛛 🚊
Line Type 🛛 🗕 So	olid Line 🚽 Line Thicknes	s 1 🗄 🔳
Display Color	Blink None	

Setting	Description	
Upper Limit/ Standard/Lower Limit	Select the auxiliary line to set.	
Draw Line	Defines whether or not to draw the [Upper Limit], [Standard], and [Lower Limit] auxiliary lines in the selected positions.	
Specify Display Position	 Select the designation method of the auxiliary lines' display position from [Constant] or [Address]. Constant Designate a set constant as the Display Position. Address Designate the address where the Display Position is stored. 	

Setting	Description		
	Set the auxiliary line's Display Position.		
Display Position	The setting range for each auxiliary line on the Y-axis is as follows.		
	Data Type	Display Sign +/ -	Setting Range
	16 Bit Bin1016 Bit Bin032 Bit Bin032 Bit Bin032 Bit Bin0	Unchecked Checked Unchecked Checked	0 to 65535 -32,768 to 32,767 0 to 4294967295 -2147483648 to 2147483647
	Set each horizontal auxiliary line from 0 to 1,000 (out of 1000%). 500 is the middle position, 1000 is the largest position.		
Line Type	Select the auxiliary line type:		
	Solid Line		
	Dashed Line		
	Dash Line		
	Chain Line		
	Two-Dot		
	Chain Line.		
	NOTE		
	• If the Graph screen is 16 pixels or less, any pattern other than a solid line may not properly display.		
Line Thickness	Set the auxiliary line thickness from 1 to 2.		
Display Color	Set the auxiliary line color.		
Background Color	If you selected a line type other than the solid line, set the auxiliary line's background color.		
Blink	Select the Part blinks and blink speed. You can choose different blink		
	settings for the [Display Color], and [Background Color].		
	NOTE		
	• There are cases where you can and cannot set Blink depending on the		
	Wain Unit and System Settings [Color]. [©] "9.5.1 Setting Colors. ■ List of Available Colors" (page 9-34)		
	"9.5.1 Setting Colors ■ List of Available Colors" (page 9-34)		

17.8 Restrictions

17.8.1 Restrictions for Graphs

- When a value outside of the set input range is collected, the Graph Display only shows values up to the maximum and down to the minimum.
 - For example, When the input range Min = 0, Max = 100



• When corrupt BCD data is collected, it can not be displayed properly. When a value is invalid, the previous state is displayed. If the value is corrupt and no previous value exists, a value is then only displayed once a valid value is collected.

17.8.2 Restrictions for Historical Trend Graphs

- A total of eight Historical Trend Graph parts can be displayed at the same time on a single screen. When you are using a window screen, the eight Historical Trend Graph parts can be displayed on the base screen and window screen together eight. When Data Block Displays are also placed on the same screen, you can have up to eight data black and historical trend graphs.
- The maximum number of channels (number of lines) that can be displayed on a single Historical Trend Graph is 20.
- A maximum of 40 channels can be displayed on a single screen. On a window screen, a maximum of 40 channels can be displayed on the base screen and window screen. The subsequent channels do not appear.
- To draw lines within the display area on the historical trends graph, place the graph on a base screen numbered 9000-9999. If you draw scale lines within the graph display area on a base screen numbered 1-8999, the scale lines will not be displayed on the GP. To display a graph with scale lines on a base screen numbered 1-8999, call up a screen with a number above 9000.
- When the sampling period is designated as 1 second or less, depending on the size of the graph display area used, scroll processing can take almost one second, and communication and tag processing can be affected. In this case, setting the sampling period to two or more seconds should correct the problem.

• If an error occurs when reading the data samples, the line on that portion of the graph is not displayed. If the error continues, that period does not appear on the graph. The following data samples appear on the Historical Trend Graph as follows:



• When the [Data Type] of the historical trend graph part is specified as [BCD], and the sampled data including A to Fh except BCD (except 0 to 9) is stored and the graph containing the previous sampled data is displayed.

When the next sampled data is displayed on the historical trend graph, it is displayed as follows.



The fourth sample, 95(5Fh) is ignored, and the third sample, 50(32h), is shown in its place on the Graph.

• Set the [Data Type] on the Historical Trend Graph to match the data sample bit length. If the [Bit Length] is set to [16 Bit] and the [Data Type] is 32 bit, two Words' data are combined and handled as 32 bit.


Restrictions for Displaying Historical Data

- Only one Historical Trend Graph part with a Display Historical Data function enabled can be placed on a Base screen.
- You cannot use Display Historical Data Settings on a window screen. The Display Historical Data function does not work.
- When you erase data samples stored in the GP, Historical Data cannot be displayed.
- The Number of Data (current data + historical data) that can be displayed in one channel with Display Historical Data is the amount in [Cycles] designated in the sampling settings. For the Historical Trend Graph [Data Samples], set a number less than [Cycles] in the sampling settings.
- The number of sampled data that can be saved on the GP depends on the capacity of the backup SRAM ^{*1} and the intended use, as well as the sampling settings.

"24.9.1 Summary Backup SRAM" (page 24-100)

The table below shows the maximum number of samples when the backup SRAM is used only for backing up the sampling groups used in a line chart.

Backup SRAM Size	1	10	20	30	40
	Channe	Channe	Channe	Channe	Channe
	1	ls	1	ls	ls
320KB	65535	16265	8132	5421	4065
128KB	32180	6435	3217	2144	1608

The maximum number of samples per Number of Channels

Setting Contents: Number of Sampling Groups: 1, Blocks: 1, Data Type: 16 Bit,

Overwrite old data after finishing the specified no. of times, No Date Data, No Data Enabled/Disabled Flags

- Switches placed on a Historical Trend Graph are automatically grouped. You can change an individual Switch's size or attributes, but if you delete the Switch, the Graph is also deleted.
- Do not use two different types of switches for the same Historical Trend Graph. One type of switch is the Switch/Lamp: on the [Parts] menu, point to [Switch/Lamp], [Special] and then click [Historical Trend Graph Switch]. The other type of switch is configured directly in the Historical Trend Graph.
- When using a Switch Lamp [Special Switch] [Historical Trend Graph Switch] for Display Historical Data, place the Special Switch and the trend graph with the Display Historical Data function on the same Base screen. If the Historical Trend Graph is placed on the Base Screen and the Special Switch on the Window Screen, they will not function.
- While in Display Historical Data mode, new samples will not be displayed even if they occur. The display will update when Display Historical Data mode is released. Even while in Display Historical Data mode, data sampling continues.
- Changing screen while in Display Historical Data mode cancels the mode.
- *1 The capacity differs depending on the model. Confirm the capacity: from the [Project (F)] menu, point to [Information] and select [Project Information]. Then select [SRAMInformation].

17.8.3 Data Block Display Graph Restrictions

- A total of 8 Data Block Display Graph parts can be displayed at the same time on a single screen. When you are using a window screen, the total number of Data Block Display Graph parts that can be displayed on the base screen and window screen together is 8. When Historical Trend Graphs are also placed on the same screen, the maximum allowed for the two kinds of parts is 8.
- The maximum number of channels (number of lines) that can be displayed on a single Data Block Display Graph is 20.
- The maximum number of channels (number of lines) that can be displayed on a single screen is 40. When you are using a window screen, the total number of channels that can be displayed on the base screen and window screen together is 40. When more than 40 trend graph lines are set up, the 41st and subsequent lines will not function.
- When displaying variables on the data block display graph, specify the Array Size.

Restrictions for Show Scale

• Data which is out of the scale's display range will not be shown.



- Show Scale's update timing (the timing of value reading) is the instant when the graph display is cleared or the screen is switched.
- When Show Scale is set, [Alarm] cannot be used.
- When Show Scale is set, [Fill Below Line] cannot be used.
- When auxiliary lines are set, any changes to Show Scale will also affect the horizontal auxiliary lines.



- If a set auxiliary line's value exceeds the graph display range, that auxiliary line is not displayed.
- When auxiliary lines are designated with [Address], the update timing (the timing of value reading) is the instant when the graph display is cleared or the screen is switched.