

FP2650-T41 User Manual



Preface

Thank you for purchasing Digital's TFT type color display panel, the FP2650-T41 unit (hereafter referred to as the *FP unit*).

Please read this manual completely to ensure the correct use and complete understanding of the FP unit's functions.

<Note>
1) It is forbidden to copy the contents of this manual, in whole or in part, except for the user's personal use, without the express permission of Digital Electronics Corporation of Japan.
2) The information provided in this manual is subject to change without notice.
3) This manual has been written with care and attention to detail; however, should you find any errors or omissions, please contact Digital Electronics and inform them of yourfindings.
4) Regardless of the above clause, Digital Electronics Corporation shall not be held responsible for any damage or third-party claims for damage or losses resulting from the use of this product.

All Company/Manufacturer names used in this manual are the registered trademarks of their respective companies.

© 2005, Digital Electronics Corporation

Essential Safety Precautions

This manual describes safety instructions for correct use of the FP unit. Please keep this manual close at hand and refer to it when necessary.

The following symbols are used throughout this manual to ensure the safe use of the FP unit. Please be sure to follow all instructions given since they explain important safety points.



Indicates situations where sever bodily injury, death or major equipment damage will occur.

Caution

Indicates situations where bodily injury or machine damage can occur.

- Prior to connecting the FP2650-T41 (hereafter referred to as the "FP" or FP unit) unit's power cord terminals to the Terminal Block, be sure to check that the FP unit's power supply is completely turned OFF, via a breaker, or similar unit.
- Do not use voltage levels that exceed the FP unit's specified voltage range. Doing so may cause a fire or an electric shock.
- Since the FP unit contains high voltage parts, an electric shock can occur when opening the unit. Therefore, be sure to unplug the power cord before opening it.
- Do not modify or remodel the FP unit. Doing so may lead to a fire or electric shock.
- Do not use FP unit touch panel switches in human-safetyrelated or important disaster prevention situations. For safety-related switches, such as an emergency stop switch, be sure to use a separately installed mechanical switch.
- Do not use the FP unit as a warning device for critical alarms that can cause serious operator injury, machine damage or production stoppage. Critical alarm indicators and their control/activator units must be designed using stand-alone hardware and/or mechanical interlocks.

After the FP unit's backlight burns out, unlike the FP unit's "Standby Mode", the touch panel is still active. If the operator fails to notice that the backlight is burned out and touches the panel, a potentially dangerous machine operation error can occur. Therefore, do not use FP touch switches for the control of any equipment safety mechanisms, such as Emergency Stop switches, etc. that protect humans and equipment from injury and damage. If your FP unit's backlight suddenly turns OFF, use the following steps to determine if the backlight is actually burned out. 1) If your current FP application is not set to turn the backlight OFF, and the screen has gone blank, your backlight is burned out. 2) If your current FP application is set to turn the backlight OFF, and if touching the screen does not cause the display to reappear, your backlight is burned out. · If substantial amounts of metallic dust, water or liquids enter the FP unit, turn OFF the power supply immediately, unplug the power cord, and contact your local FP distributor. • When installing the FP unit, be sure to follow the instructions given in "Chapter 3 Installation and Wiring". • Do not use the FP in an environment where flammable gases are present, since operating the FP may cause an explosion. • Do not use the FP with aircraft control devices, aerospace equipment, central trunk data transmission (communication) devices, nuclear power control devices, or medical life support equipment, due to these devices' inherent requirements of extremely high levels of safety and reliability. • When using the FP with transportation vehicles (trains, cars and ships), disaster and crime prevention devices, various types of safety equipment, non-life support related medical devices and others, be sure to use redundant and/or failsafe system designs to ensure the appropriate degree of system reliability and safety. • To prevent operator injury or machine damage, be sure to design your machine operation system so that the machine will not malfunction due to a communication fault between the FP unit and its PC host controller.

- Do not strike the FP unit's touch panel with a hard or heavy object, or press on the touch panel with too much force, since it may damage the display.
- When the surface of the display screen becomes dirty or smudged, clean the display with a cloth soaked in a neutral detergent. Do not use paint thinner or organic solvent.
- Do not press on the touch panel's face with sharp objects, such as a mechanical pencil or screwdriver, since it might damage the LCD panel.
- Do not use or store the FP in direct sunlight, excessively dusty or dirty environments, or where chemicals or their vapors are present in the air.
- Do not restrict the FP unit's natural ventilation, or store or use the FP in an environment that will increase the FP's internal temperature.
- Do not use the FP in areas where sudden, large changes in temperature may occur. These changes can cause condensation to form inside the unit, possibly leading to a malfunction.

Notes on the FP unit's Liquid Crystal Display (LCD)

- The FP unit's LCD contains a strong irritant. If the panel is damaged and the LCD unit's liquid contacts your skin, be sure to wash it with running water for at least 15 minutes. If any of this liquid should enter your eye, be sure to flush the eye with running water for more than 15 minutes, and see a doctor immediately.
- The brightness of the LCD screen will depend on the screen's current display and the LCD unit's contrast adjustment. Any brightness variations that result are normal for LCD displays.
- There are minute grid-points on the LCD surface. These points are not defects.
- The displayed color will look different when viewed from an angle outside the specified view angle. This is also normal.

- Displaying a single screen image for long periods of time can cause an afterimage to remain. To correct this, turn the unit OFF for 5 or 10 minutes, then turn it ON again. This phenomenon is a common attribute of the LCD unit's and not a defect. To prevent this effect, you can:
 - use the Display OFF feature, if the same image is to be displayed for a long period of time.
 - change the screen display periodically to prevent the displaying of a single image for a long period of time.

Documentation Conventions

The list below describes the documentation conventions used in this manual.

Symbol	Meaning	
Indicates important information or procedures that must be follow correct and risk-free software/device operation.		
Reference	Refers to useful or important supplemental information.	
Note: Provides useful or important supplemental information.		
*1	Indicates useful or important supplemental information.	
1), 2)Indicates steps in a procedure. Be sure to perform these steps order given.		

FP2650-T41 Features

High Quality TFT Color LCD Display

The FP-2650-T41 unit is equipped with a 12.1 inch TFT type color LCD. This unit has superb brightness and wide viewing angles and its speed of response is fast, not found in ordinary laptop-type TFT LCDs.

The FP-2650-T41 unit is 1024(H) X 768(V) pixels. It can display 260,000 colors.

Easy Installation In User Cabinets and Panels

The FP unit's slim and compact design makes installation a snap. These panels are designed specifically for IA (Industrial Automation) or OA (Office Automation) monitor. The flat front panel provides protection equivalent to IP65f. Even without its optional protective cover the front panel is highly resistant to both water and dust.

Panel can be used as a Display

Since the FP is equipped with an analog RGB interface and a DVI-D Interface, it can be connected to a PC and other similar devices easily. (The PC's dot clock frequency, however, must be within the standard range.)

Easy-to-use Built-In Touch Panel

The FP unit's built-in touch panel is standard equipment, allowing touch panel data to be output to a host PC via input/output commands and an RS-232C or USB cable. This is ideal for systems requiring both touch panel operation and data monitoring.

Connecting the FP to a PC

The FP-2650-T41 unit is designed as a standard XGA display.

Be aware that some types of VGA equipment may not be within the ranges specified in this document, and, therefore, cannot be connected to the FP.

Also, if you change your PC's VGA/SVGA board, there is the possiblity that the new board may not be able to be connected to the FP.

Reference 2.3 Interface Specifications



• When a signal timing value not compatible with the FP unit is entered, or if the entered timing value is larger than can be displayed by the dot clock, an "OUT OF RANGE" message is displayed. If this occurs, consult your computer's manual and enter a value that is compatible with this device.

 If no signal (synchronized signal) is entered, a "NO SIGNAL" message is displayed.

What is IP65f?

This code indicates the degree of ingress protection provided from the front face of the FP, and assumes that the FP is securely mounted into a metal panel.

This unit's protection rating of IP65f is actually a composite code, consisting of the internationally recognized British "Ingress Protection" standard (BS EN 60529:1992) - "IP65", and the standard developed by the Japanese Electronics Manufacturer's Association (JEM) - "f". This code is used in this manual to identify this product's degree of structural resistance to a variety of environmental elements and thus, prevent problems or accidents related to the inappropriate product use.

The individual meaning of each character of this code is explained below.

IP 6 5 f

- (1) (2) (3) (4)
- (1) Designates the type of protection provided.
- (2) Indicates the degree of protection provided to the human body by the unit, and the degree of protection provided by the unit's front face from particles/dust intrusion into the interior of the unit. Here, "6" indicates that the unit is completely protected from dust intrusion.

(3) Indicates the degree of protection provided by the unit's front face from water intrusion into the interior of the unit.

Here, "5" indicates that the unit is protected from water intrusion from a direct water jet.

(4) Indicates the degree of protection provided by the unit's front face from oil particle intrusion into the interior of the unit.

Here, "f" indicates that the unit is completely protected from oil intrusion via either oil particles or oil splashes from any direction (to the front panel).

Package Contents

The FP unit's packing box contains the items listed below. Please check to be sure each item is included and is not damaged.



These items have all been carefully packed with special attention to product quality. However, should you find anything damaged or missing, please contact your local FP distributor immediately for prompt service.

UL/c-UL(CSA) Application Notes

FP2650-T41 unit is UL/c-UL(CSA) qualified product (UL File No. E171486).

FP2650-T41 (UL Registration Model No.:3384101-01)

The FP-2650-T41 conforms to the following standards:

■<u>UL60950-1</u> First Edition

Information Technology Equipment - Safety - Part 1: General Requirements

■<u>CAN/CSA-C22.2 No.60950-1-03</u> (c-UL Qualification)

Information Technology Equipment - Safety - Part 1: General Requirements

<Cautions>

- The FP must be used as a built-in component of an end-use product.
- The FP unit must be used indoors only.
- This unit should be installed in the front face of a metal panel.
- If the FP unit is installed so as to cool itself naturally, be sure to mount it in a vertical panel. Be sure that the FP unit is installed at least 100 mm away from any adjacent structures or machine parts. If these conditions are not met, the heat generated by the FP unit's internal components may cause the unit to fail to meet UL standards.
- When using the FP in an end-use product, be sure to install the FP unit's power cut-off switch where the operator can easily reach it. Use the switch that is appropriate for the current and voltage used.
- The unit, the FP is built into, shoud be used with a UL60950-1 compatible structure.

CE Marking Notes

FP2650-T41 unit is CE marked, EMC Directive and Low Voltage Directive compliant product.

<Complies with the following Standards>

• Safety

EN60950-1

• EMI

EN55011 (Group 1, Class A)

• EMS <EN61000-6-2>

EN61000-4-2, EN61000-4-3, EN61000-4-4, EN61000-4-5, EN61000-4-6, EN61000-4-11

If the following requirements are not met, the FP may fail to meet EN60950-1 standard requirements.

- The FP must be used as a built-in component of an end-use product.
- The FP unit must be used indoors only.

CD-ROM Data

- When using the FP in an end-use product, be sure to install the FP unit's power cut-off switch where the operator can easily reach it. Use the switch that is appropriate for the current and voltage used.
- The unit, the FP is built into, shoud be used with a UL60950-1 compatible structure.

CD-ROM Data

The following data and programs are contained in the FP-2650-T41 unit's CD-ROM.



Table of Contents

Preface	1
Essential Safety Precautions	2
Documentation Conventions	5
FP2650-T41 Features	6
Connecting the FP to a PC	7
What is IP65f?	7
Package Contents	8
UL/c-UL(CSA) Application Notes	9
CE Marking Notes	9
CD-ROM Data	.10

Chapter 1 Introduction

1.1	System Design	1-1	L
1.2	Optional Equipment	1-2	

Chapter 2 Specifications

2.1	General Specifications	
	2.1.1 Electrical	2-1
	2.1.2 Environmental	2-2
	2.1.3 Structural	2-2
2.2	Functional Specifications	
	2.2.1 Performance	2-3
	2.2.2 Display	2-3
2.3	Interface Specifications	
	2.3.1 Analog RGB Interface	2-4
	2.3.2 DVI-D Interface	2-6
	2.3.3 RS-232C Interface	2-8
	2.3.4 USB Interface	2-9

Table of Contents

2.4	Cable Diagrams	2-10
	2.4.1 Analog RGB Interface Pin Connections (Optional cable)	2-10
	2.4.2 DVI-D Interface Pin Connections (Optional cable)	
	2.4.3 RS-232C Interface Pin Connections (Optional cable)	2-12
	2.4.4 USB Interface Cable Pin Connections (Option cable)	2-12
2.5	Names and Functions of FP Parts	2-13
2.6	FP Dimensions	2-14
2.6	FP Dimensions	
2.6		2-14
2.6	2.6.1 External Dimensions	2-14 2-14

Chapter 3 Installation and Wiring

3.1 Installation

	3.1.1 Installation Procedures	3-1
3.2	Wiring Cautions	
	3.2.1 Connecting the Power Cord	
	3.2.2 Connecting the USB Cable Strap Attachment	
	3.2.3 Connecting the Power Supply	
	3.2.4 Precautions: Grounding	
	3.2.5 Precautions: Input/Output Signal Lines	

Chapter 4 Setting up and Adjusting the FP unit

4.1	Operation Mode Setup	
	4.1.1 Dip Switch Preset Settings and Adjustments	4-1
	4.1.2 Status of Front LED in Operation Modes	
4.2	Screen Display Adjustment	
	4.2.1 Calibration of OSD Display Position	4-2
	4.2.2 OSD Setting Icons	
	4.2.3 OSD Setting Item Details	4-4

Chapter 5 Touch Panel Data	
5.1 Touch Interface Data	5-1
Chapter 6 Troubleshooting	
6.1 Troubleshooting	6-1
6.1.1 Possible Device Problems	6-1
6.1.2 No Display	
6.1.3 Touch Panel Does Not Respond	6-4
6.2 Error Message	
6.2.1 Error Message List	
Chapter 7 Maintenance	

7.1	Regular Cleaning	. 7-1
	7.1.1 Cleaning the Display	7-1
	7.1.2 Installation Gasket Replacement	7-2
7.2	Periodic Check Points	. 7-3
7.3	Backlight Replacement	. 7-4

Memo

1. System Design

2. Optional Equipment

Chapter 1 Introduction

1.1 System Design

The FP can be connected to Pro-face's PS-2000B or to a Windows® compatible PC.





The FP unit's dip switches set the type of communication method used for sending touch data and commands (USB or RS-232C), and also for outputing image signals (DVI-D or Analog RGB).

Reference 4.1.1 Dip switch setting

* Only when FP-DV01-100 is connected to PS-2000B, you can use it.

1.2 **Optional Equipment**

All optional items listed below are Digital Electronics Corporation products.

■ Cables

Item	Model Number	Description	
		Serial interface cable used for touch panel data	
RS-232C Cable	FP61V-IS00-O (5m)	transmission between the host and the FP or	
NO-2020 Cable	FP61V-IS00-0 (5III)	command transmission to the FP. This is a	
		straight Dsub 9-pin female cable.	
		Analog RGB interface cable used when image	
Analog RGB Cable	FP-CV02-45 (4.5m)	signals are output to the FP from the host.	
		(Dsub 15-pin male).	
		USB interface cable used for touch panel data	
USB Cable	le FP-US00 (5m)	transfer between the host and the FP or	
		command transmission to the FP. A-B type	
		cable.	
	FP-DV01-50 (5m)	Digital Visual Interface cable used to send the	
DVI-D Cable	FP-DV01-100 (10m) ^{*2}	image signal from the host to the FP. XGA	
		specification DVI-D 24-pin male.	

optional devices

ltem	Model Number	Description
Adapter for hanging on walls		Adapter installed, with the FP hung on the
Adapter for hanging on waits	CAT-WIMALRG-01	wall.
Desktop Stand	CA1-STDLRG-01	Stand installed, with the FP set up on the
Desktop Stand		plane such as a desk etc
		Cover fixed on the rear of the FP.
Rear Cover	CA1-RCVLRG-01	Use it combining with Desktop stand or
		Adapter for hanging on walls or the Arm
		available on the market.

■ Maintenance Parts

ltem	Model Number	Description
Installation Fasteners	GP070-AT01	Metal installation fasteners.
		Replacement rubber gasket, used when
Rubber Gasket	GP570-WP10-MS	installing the FP. Same as the FP unit's
		original gasket.
		Disposable, dirt resistant
Screen Protection	PSL-DF00	sheet for the FP unit's screen. The FP unit's
Sheet	PSL-DF00	touch panel can be used with this cover
		sheet attached. (5 sheets/set)
Backlight	CA5-BLU12XGA-01	Replacement backlight for FP2650-T41 unit.

Available Software

Item Model Number		Description	
Mouse Emulator V2 ^{*1}	PL-TD000	Mouse emulation software for the FP.	

*1 OS can be Windows[®]95, WindowsNT[®]4.0, Windows[®]98, Windows[®]2000 or Windows[®]XP. Windows[®]95 needs OSR2 or more. Windows[®]98 needs 2nd Edition or more. WindowsNT[®]4.0 needs SP6a or more.

*2 Only when FP-DV01-100 is connected to PS-2000B, you can use it. When you use FP-DV01-100, turn on the inner dip switch of the PS2000B. (when you use FP-DV01-50, turn it off.)



- **1. General Specifications**
- 2. Functional Specifications
- 3. Interface Specifications
- 4. Cable Diagrams
- 5. Names and Functions of FP Parts
- 6. FP Dimensions

2.1 General Specifications

2.1.1 Electrical

■ FP2650-T41

Rated Voltage		AC 100V to AC 240V	
Rated Voltage Range		AC 85V to AC 264V	
Rated Frequency		50/60 Hz	
Rate	Rated Frequency Range 47 Hz to 63 Hz		
Allo	wable Voltage Drop	20ms or less	
Po	ower Consumption	50VA (ACIN 100V)/85VA (ACIN 240V)	
Between charging and		Voltage Resistance AC1500V for one minute	
Insulation	FG/SG terminals	insulating resistance $10M_{\Omega}$ or higher (DC500V)	
Between SG terminals and FG terminals		Non-insulation	
Earth Connection		Ground FG terminal by D type ground (for both protective earth and functiona earth)	

2.1 General Specifications

	FP-2650-T41	
Ambient Operating	0°C to +50°C ^{*1}	
Temperature	(the panel face should not incline more than 30°C)	
Storage Temperature	-10°C to +60°C	
Ambient Humidity	10%RH to 90%RH	
Ambient Humidity	(Non condensing, wet bulb temperature: 39°C or less)	
Air Purity (Dust)	Free of dust	
Pollution Degree	Pollution Degree 2	
Air Pressure Resistance	Range Altitude 800~1114hPa(2000m or less)	
Corrosive Gasses	Free of corrosive gasses	
Vibration Resistance	10Hz to 25Hz 19.6m/s ²	
Vibration Resistance	X, Y, Z directions (30min.)	
	Noise Voltage: 1,500Vp-p	
Noise Immunity	Pulse Duration: 1ms, 500ns, 50ns	
(via noise emulator)	Rise Time: 1ns	
	Normal mode1kV,Common mode2kV	
Surge Resistance	(IEC61000-4-5 level3)	
Electrostatic Discharge Immunity	4kV (complies with EN 61000-4-2)	

2.1.2 Environmental

2.1.3 Structural

*1 (For front panel of installed unit)	Equivalent to IP65f (JEM 1030)
External Dimensions	W317mm [12.48 in] x H243mm [9.57 in] x D58mm [2.28 in]
Weight	3.5kg (7.7lb) or less
Cooling Method	Natural air circulation

*1 The front face of the FP unit, installed in a solid panel, has been tested using conditions equivalent to the standard shown in the specification. Even though the FP unit's level of resistance is equivalent to the standard, oils that should have no effect on the FP can possibly harm the unit. This can occur in areas where either vaporized oils are present, or where low viscosity cutting oils are allowed to adhere to the unit for long periods of time. If the FP's front face protection sheet peels off, these conditions can lead to the ingress of oil into the FP and separate protection measures are suggested. Also, if non-approved oils are present, it may cause deformation or corrosion of the front panel's plastic cover. Therefore, prior to installing the FP be sure to confirm the type of conditions that will be present in the FP's operating environment.

If the installation gasket is used for a long period of time, or if the unit and its gasket are removed from the panel, the original level of the protection cannot be guaranteed. To maintain the original protection level, be sure to replace the installation gasket regularly.

2.2 Functional Specifications

2.2.1 Performance

		FP-2650-T41
Graphics		XGA(1024 X768)
Display Unit		12.1 inch TFT XGA
	Туре	Resistive Film (Analog)
Touch Panel I/F	Resolution	1024 X 1024
	Interface	Serial Interface (RS-232C)
		USB Interface
Video I/F		Analog RGB Interface
		DVI-D Interface

2.2.2 Display

	FP-2650-T41		
Туре	TFT Active Matrix Color LCD		
Resolution	1024 (H) X 768(V) pixels		
Display colors	260,000 colors (R/G/B six bits each)		
Brightness Control ^{*1}	Available		
	Available (Analog RGB only)		
Contrast Control ^{*1}	(when using analog RGB connection)		
	640X400, 640X480,		
Display Modes ^{*2}	720X400,800X600,		
	1024X768		
Backlight	CCFL (Replaceable)		
De aldials (Life times	Backlight can be replaced by the user.		
Backlight Lifetime	50,000 hours at an ambient temperature of $25^{\circ}C^{*3}$		

*1 Setting up OSD. For details, refer to 4.2 Screen Display Ajustment

- *2 For details, refer to 2.3 Interface Specifications
- *3 50% decreased brightness indicates the backlight needs to be replaced. This value is only for reference and not a guaranteed value.

2.3 Interface Specifications

2.3.1 Analog RGB Interface

Input signal type	Analog RGB
Input signal characteristic	Image signal: analog RGB
	Synchronous signal: TTL level, negative true or positive true
	Scanning type: non-interlaced
Setting via OSD	CONTRAST
(On Screen Display)	BRIGHTNESS
	H-POS
	V-POS
	H-SIZE
	PHASE
	BACKLIGHT
	DEFAULT (ALL CLEAR)

The number of dots (pixels) displayed are as follows:

FP2650-T41

Resolution	H Sync. (kHz)	V Sync (Hz)	Dot Clock (MHz)	Screen Resolution Expansion (H : Horizontal) (V : Vertical)	Display Resolution
640×400	24.827	56.000	21.053	×1.6(H)	1024×768
640×400	31.469	70.000	25.175	×1.92(V)	1024×768
640×480	31.469	59.992	25.175		1024×768
640×480	37.500	75.000	31.500	× 1.6	
640×480	35.000	66.667	30.240		
720×400 ^{*1}	31.469	70.000	28.320	× 1.42(H) × 1.92(V)	1023×768
800×600	37.879	60.317	40.000		1024×768
800×600	46.875	75.000	49.500	× 1.28	1024~700
1024×768	48.363	60.004	65.000		
1024×768	56.476	70.069	75.000	× 1.0	1024×768
1024×768	60.023	75.029	78.750		

*1 When chenging from horizontal 720 dots to horizontal 640 dots, select "720 x 400 Display Resolution 720 x 400 DSP" in the OSD (On Screen Display) "System Setting" screen.

Analog RGB Interface

Pin No.	Signal Name	Condition	P	in Location
1	Analog R	R signal input		
2	Analog G	G signal input		
3	Analog B	B signal input	1	\bigcirc
4	Reserved	NC (spare for input)	1	
5	Digital grounding	Digital signal GND	1 (
6	Return R	R signal GND	15	
7	Return G	G signal GND		
8	Return B	B signal GND	1	
9	Reserved	NC (spare for input)	1	
10	Digital grounding	Digital signal GND	11	0 0 1
11	Reserved	NC (spare for input)	1	
12	Reserved	NC (spare for input)	1 (
13	H. SYNC	Horizontal synchronous		\bigcirc
13	H. STNC	signal input		
14	V. SYNC	Vertical synchronous signal	1	
14	V. STNC	input		
15	Reserved	NC (spare for input)	1	

Pin Assignments and Signal Names

Connector: Mini Dsub 15 pin male

Connector set screw: Inch type (4-40)

Analog RGB Cable: FP-CV02-45<4.5m>manufactured by Digital Electronics Corporation of Japan



If a cable other than the specified RGB cable is used, FP unit operation cannot be guaranteed due to the possibility of noise interference.

2.3 Interface Specifications

2.3.2 DVI-D Interface

Input signal type	DVI-D
Setting by OSD	H-POS
(On Screen Display)	V-POS
	BACKLIGHT
	DEFAULT (ALL CLEAR)

The number of dots (pixels) displayed are as follows:

◆FP2650-T41	

Resolution	H Sync. (kHz)	V Sync (Hz)	Dot Clock (MHz)	Screen Resolution Expansion (H : Horizontal) (V : Vertical)	Display Resolution
640×400	24.827	56.000	21.053	×1.6(H)	1024×768
640×400	31.469	70.000	25.175	×1.92(V)	1024×768
640×480	31.469	59.992	25.175		1024×768
640×480	37.500	75.000	31.500	× 1.6	
640×480	35.000	66.667	30.240		
720×400 ^{*1}	31.469	70.000	28.320	× 1.42(H) × 1.92(V)	1023×768
800×600	37.879	60.317	40.000		1024×768
800×600	46.875	75.000	49.500	× 1.28	1024~700
1024×768	48.363	60.004	65.000		
1024×768	56.476	70.069	75.000	× 1.0	1024×768
1024×768	60.023	75.029	78.750		

*1When chenging from horizontal 720 dots to horizontal 640 dots, select "720 x 400 Display Resolution 720 x 400 DSP" in the OSD (On Screen Display) "System Setting" screen.

DVI-D Interface

Pin No.	Signal Name	Pin No.	Signal Name	Pin Location
1	TMDS DAT A2-	13	NC	
2	TMDS DATA2+	14	NC	
3	TMDS DATA2 SHIELD	15	GND	
4	NC	16	Hot Plug Detect	
5	NC	17	TMDS DATA0-	
6	DDC Clock	18	TMDSDATA0+	
7	DDC Data	19	TMDS DAT A0 SHIELD	
8	NC	20	NC	
9	TMDS DATA1-	21	NC	
10	TMDS DATA1+	22	TMDS CLOCK SHIELD	\bigcirc
11	TMDS DATA1 SHIELD	23	TMDS CLOCK+	
12	NC	24	TMDS CLOCK-	

Pin Assignments and Signal Names

Connector:

DVI-D 24-pin male

Connector set screw: Inch type (4-40)

DVI-D Cable:

FP-DV01-50<5m> FP-DV01-100<10m> manufactured by Digital Electronics Corporation



If a cable other than the specified DVI-D cable is used, FP unit operation cannot be guaranteed due to the possibility of noise interference.

2.3.3 RS-232C Interface

	Baud rate: 9600 bps
	Data length: 8 bits
RS-232C Interface	Parity: none
	Stop bit: 1

RS-232C Interface

Pin Assignments and Signal Names

Pin No.	Signal Name	Condition	Pin Location
1	CD	Carrier Detect *1	
2	RD	Receive Data (FP->Host)	\bigcirc
3	SD	Send Data (FP<-Host)	
4	DTR	Data Terminal Ready ^{*1}	6 0
5	GND	Ground	9 0 0
6	DSR	Data Set Ready ^{*1}	5
7	RS	Request to Send (FP<-Host)	$\overline{\bigcirc}$
8	CS	Clear to Send (FP->Host)	
9	NC	(Used internally)	

Connector: Dsub 9 pin female

Connector set screw: Inch type (4-40)

RS-232C Cable: FP61V-IS00-O <5m> manufactured by Digital Electronics Corporation of Japan

*1 CD, DTR, and DSR are connected together inside the FP.



Signal Names

Signal names used for the RS-232C Interface are designed to match the pin order used on most PC RS-232C interfaces, which allows a straight cable to be used to connect the two. <u>Therefore, connect each pin's signal to the same signal name on the PC side.</u>

For example, the FP unit connector's pin #2 'RD' should be connected to the PC connector's 'RD' terminal. For detailed signal direction information,

Reference 2.4 Cable Diagrams



If a cable other than the specified RS-232C cable is used, FP unit operation cannot be guaranteed due to the possibility of noise interference.

2.3.4 USB Interface

USB Interface

Pin Assignments and Signal Names

Pin NO.	Signal Name	Condition	Pin Location
1	USB1-5V	+5VIN	2 1
2	USBD1(-)	USB data(-)	
3	USBD1(+)	USB data(+)	
4	GND	Ground	3 4

Low speed Device Communication:

Connector: B type connector

FP-US00 <5m> manufactured by Digital Electronics Corporation USB Cable :



If a cable other than the specified USB cable is used, FP unit operation *Important* cannot be guaranteed due to the possibility of noise interference.

2.4 Cable Diagrams

2.4.1 Analog RGB Interface Pin Connections (Optional cable)

log G Inp log B Inp erved ground ırn R	nput nput nput 	1 2 3 4 5	RED IN GRN IN BLU IN NC		RED VIDEO GRN VIDEO BLU VIDEO	1 2	Output Output		1
log B Inp erved ground ırn R	nput 	3 4	BLU IN NC				Output	GRN VIDEO	1
ground urn R		4	NC		BLU VIDEO				2
ground urn R						3	Output	BLU VIDEO	3
irn R		5			NC	4		NC	4
			GND		GROUND	5		GROUND	5
		6	RED GND		GROUND RED	6		GROUND RED	6
ırn G		7	GRN GND		GROUND GRN	7		GROUND GRN	7
ırn B		8	BLU GND		GROUND BLU	8		GROUND BLU	8
erved		9	NC		NC	9		NC	9
ground		10	GND		GROUND	10		GROUND	10
erved		11	NC		MONITOR	11		MONITOR	11
					SENSE(COLOR)			SENSE(COLOR)	
erved		12	NC		MONITOR	12		MONITOR	12
					SENSE(MONO)			SENSE(MONO)	
YNC Inp	nput	13	HSYN		HSYN	13	Output	HSYN	13
YNC Inp	nput	14	VSYN		VSYN	14	Output	VSYN	14
		15	NC		NC	15		NC	15
		FG FG -							
÷	rved YNC I YNC I	rved YNC Input YNC Input rved	rved 12 rNC Input 13 rNC Input 14 rved 15	rved 12 NC YNC Input 13 HSYN YNC Input 14 VSYN rved 15 NC	rved 12 NC YNC Input 13 HSYN YNC Input 14 VSYN rved 15 NC	erved 12 NC SENSE(COLOR) MONITOR SENSE(MONO) YNC Input 13 HSYN HSYN YNC Input 14 VSYN VSYN erved 15 NC NC	Arved12NCSENSE(COLOR)Arved12NCMONITOR12YNCInput13HSYNHSYN13YNCInput14VSYNVSYN14Arved15NCNC15	inved 12 NC SENSE(COLOR) inved 12 NC MONITOR 12 inved 13 HSYN HSYN 13 Output inved 14 VSYN VSYN 14 Output	arved 12 NC SENSE(COLOR) SENSE(COLOR) arved 12 NC MONITOR 12 MONITOR arved 13 HSYN HSYN 13 Output HSYN 13 arved 15 NC NC 15 NC

Signals and signal names used with the FP and the Analog RGB cable (optional cable) are the same as those used for PCs. Also, the same pin is used on both sides of the optional cable so that you can connect the cable regardless of the cable direction.

Inch is used for the pitch of the connector screw on the PC. For this reason, inch (4-40) is also used for the pitch of the connector screw for the cable and the FP.



2.4.2 DVI-D Interface Pin Connections (Optional cable)

Signals and signal names used with the FP and the DVI-D cable (optional cable) are the same as those used for the PC. Also, the same pin is used on both sides of the optional cable so that you can use the cable without worrying about the cable's direction.

Inch is used for the pitch of the connector screw on the PC. For this reason, inch (4-40) is also used for the pitch of the connector screw for the cable and the FP.

FP						SIO cable		PC				
1	CD	Output		1	CD		CD	1		Input	CD	1
2	RD	Output		2	RD		RD	2		Input	RD	2
3	SD	Input		3	SD		SD	3		Output	SD	3
4	DTR	Input		4	DTR		DTR	4		Output	DTR	4
5	GND	_		5	GND		GND	5		—	GND	5
6	DSR	Output		6	DSR		DSR	6		Input	DSR	6
7	RS	Input		7	RS		RS	7		Output	RS	7
8	CS	Output		8	CS		CS	8		Input	CS	8
9	NC	—		9	NC		RI	9		Input	RI	9
FG	FG	—		FG	FG		FG	FG				
-									-			

2.4.3 RS-232C Interface Pin Connections (Optional cable)

Signals and signal names used with the FP and the RS-232C cable (optional cable) are the same as those used for PCs. Also, the same pin is used on both sides of the optional cable so that you can connect the cable regardless of the cable direction.

Inch is used for the pitch of the connector screw on the PC. For this reason, inch (4-40) is also used for the pitch of the connector screw for the cable and the FP.

2.4.4 USB Interface Cable Pin Connections (Option cable)

FP	
----	--

USB	cable

PC

1	+5VIN	Input	[1 +5VIN	Input	 Output	+5VIN	1]	Output	+5VIN	1
2	USB-	Input/Output		2 USB-	Input/Output	Input/Output	USB-	2		Input/Output	USB-	2
3	USB+	Input/Output		3 USB+	Input/Output	 Input/Output	USB+	3		Input/Output	USB+	3
4	GND	Input/Output		4 GND	Input/Output	Input/Output	GND	4		Input/Output	GND	4

2.5 Names and Functions of FP Parts



FP-2650-T41 Front



Bottom

- A : TFT Color LCD Displays host data.
- B : Touch Panel Switches screens or writes/sends data to the host.
- C : Front LED

Used to indicate status of power supply, backlight or image signal input.

Reference 3.3.2 Status of Front LED in Operation Modes

- D : Power Input Terminal Block Provides power to the FP unit via the input and ground terminals
- E : Dip Switches

Switches for setting up the FP unit's Operation Mode.

- G : Analog RGB Connector Connector for analog RGB cable.
- H : DVI-D Interface Connector Connector for DVI-D calbe.
- I: RS-232C Connector

Connector for RS-232C (serial) interface. Used sending touch panel data to the host, and receiving commands from the host.

J: USB Connector

Connector for USB cable. Used for sending touch panel data to the host, and receiving commands from the host.

2.6 **FP** Dimensions

2.6.1 External Dimensions



2.6.2 External Dimensions (with Installation Fasteners)





2.6.3 Installation Fasteners

Unit : mm [in.]



2.6.4 FP Panel Cut Dimensions





- Panel thickness should be between 1.6mm [0.06in.] and 10.0mm [0.4in.]. Panel's thickness should be based on the level of panel strength required.
 - Check that the installation panel or cabinet's surface is flat, in good condition and has no jagged edges.
 - If desired, metal reinforcing strips can be attached to the inside of the panel, near the Panel Cut, to increase the panel's strength.

Reference 3.1.1 Installation Procedure

• Be sure to create the correct sized panel cut required to install the FP, using the installation dimensions given.

Memo

Chapter 3

- 1. Installation
- 2. Wiring
- 3. Operation Mode Setup and Display Positioning

Installation and Wiring

3.1 Installation

3.1.1 Installation Procedures

Follow the steps given below when installing the FP.

Check the Installation Gasket's Seating

It is strongly recommended that you use the installation gasket, since it absorbs vibration in addition to repelling water.

Place the FP on a level surface with the display panel facing downward. Check that the FP unit's installation gasket is seated securely into the gasket's groove, which runs around the perimeter of the panel's frame.

For details about installing the gasket, refer to

Reference 6.1.2 Installation Gasket Check/Replacement



- Before installing the FP into a cabinet or panel, check that the installation gasket is securely attached to the unit.
- A gasket which has been used for a long period of time may have scratches or dirt on it, and can lose much of its dust and drip resistance. Be sure to change the gasket periodically (or when scratches or dirt become visible).
- Be sure to use gasket model GP570-WP10-MS.
- Be sure the gasket's seam is not inserted into any of the unit's corners, only in the straight sections of the groove. Inserting it into a corner may lead to its eventually tearing.
- To ensure the installation gasket's maximum level of moisture resistance, be sure the gasket's seam is inserted as shown into the panel's bottom face.



3.1 Installation

Creating a Panel Cut

Create the correct sized opening required to install the FP, using the installation dimensions given.

Reference 2.6.4 FP Installation Dimensions

The installation gasket, installation fasteners and attachment screws are all required when installing the FP.





- Check that the installation panel or cabinet's surface is flat, in good condition and has no jagged edges. Also, if desired, metal reinforcing strips can be attached to the inside of the panel, near the Panel Cut, to increase the panel's strength.
- Panel thickness should be from 1.6mm [0.06in.] to 10.0mm [0.4in.]. Decide the panel's thickness based on the level of panel strength required.





For easier maintenance, operation, and improved ventilation, be sure to install the FP at least 100 mm [3.94 in.] away from adjacent structures and other equipment.

Unit: mm [in.]





Be sure that the ambient temperature(0°C to 50°C) and the ambient humidity(10%RH to 90%RH) are within their designated ranges. (When installing the FP in a cabinet or enclosure, the term "ambient temperature" indicates the cabinet or enclosure's internal temperature.)



- Be sure that heat from surrounding equipment does not cause the FP to exceed its standard operating temperature.
- When installing the FP in a slanted panel, the panel face should not incline more than 30°.





When installing the FP in a slanted panel, and the panel face inclines more than 30°, the ambient temperature must not exceed 40 °C. You may need to use forced air cooling (fan, A/C) to ensure the ambient operating temperature is 40 °C or below.
3.1 Installation

■ Installing the FP

1) Insert the FP into the panel cut, as shown here.



2) Insert the installation fasteners into the FP unit's insertion slots, at the top and bottom of the unit. (total:4 slots)



Bottom

3) Insert each of the fasteners as shown right. Be sure to pull the fastener back until it is flush with the rear of the attachment hole.



4) Use a Phillips screw driver to tighten each fastener screw and secure the FP in place.





Do not use too much force, since it may damage the FP unit. A torque of only 0.5 N•m is sufficient to tighten these screws.



- Depending on the panel condition, you can improve moisture resistant effect by increasing the number of installation fasteners.
- Installation fasteners are sold by your local FP distributor.

3.2 Wiring Cautions

3.2.1 Connecting the Power Cord





- To prevent the Ring Terminals from causing a short when the terminal block attachment screws are loosened, be sure to use sleevetype Ring Terminals.
- The SG and FG terminals are connected internally in the FP unit.
- When connecting the SG line to another device, be sure that the design of the system/connection does not produce a shorting loop.



- Wherever possible, use thick wires (max 2mm²) for power terminals, and twist the exposed wire ends when connecting the Ring Terminals.
- Please use the following size crimp-on type Ring Terminals.

Under 6.0mm[0.24in.]

Over ø3.2mm[0.13in.]

Connecting the Power Supply Terminals



Connect the power cable according to the following procedures.

- 1) Confirm that the FP unit's Power Cord is unplugged from the power supply.
- 2) Use a screwdriver to remove the Power Input Terminal Block's clear plastic cover.
- 3) Unscrew the screws from the middle three (3) terminals, align the Ring Terminals and reattach the screws.



- Confirm that the ring terminal wires are connected correctly.
- A torque of only 0.5 to 0.6 N•m is required to tighten an attachment screw.

4) Replace the Power Input Terminal Block's clear plastic cover.

3.2.2 Connecting the USB Cable Strap Attachment

USB Cable Strap Attachment Procedure

- 1) Insert the USB cable into the USB connector.
- 2) Tighten the strap until the cable is secured in place and insert the cable strap into the cable strap holder as shown in the following figure.





USB Cable Strap Removal Feature

- 1) Push in the cable strap's stopper with a standard flat-blade screwdriver until the cable strap band is unlocked, and remove the strap.
- 2) Disconnect the USB cable.



• If the stopper will not move, press on <A> (shown in figure) to free the strap from the strap holder.

3.2.3 Connecting the Power Supply





- When supplying power to the FP unit, be sure to separate the input/output and operation unit lines, as shown.
- To increase the noise resistance quality of the power cable, be sure to twist each power wire before attaching the Ring Terminal.
- The power supply cable must not be bundled or positioned close to main circuit lines (high voltage, high current), or input/output signal lines.
- When surge (indirect lightning stroke etc.) which corresponds to surge-resistance specifications or more occurs, control surge by a surge absorber etc. as shown in the diagram.

Reference 2.1.2 Environmental

• To avoid excess noise, make the power cable as short as possible.



- Be sure to ground the surge absorber (E1) separately from the FP unit (E2).
- Select a surge absorber that has a maximum permissible circuit voltage greater than the power supply's peak voltage.

3.2.4 Precautions: Grounding

(a) Exclusive grounding (BEST)



(b) Common grounding (OK)



(c) Common grounding (BAD)

other FP unit equipment



- Connect the FP unit's FG terminal to an exclusive ground. [diagram (a) -Grounding resistance of under 100Ω.]
- If exclusive grounding is not possible, use a common connection point. [diagram (b)]
- The grounding wire should have a cross sectional area greater than 2mm². Make the connection point as close to the FP unit as possible, and make the wire as short as possible. When using a long grounding wire, replace the thin wire with a thicker wire placed in a duct.
- If this equipment does not function properly when grounded, disconnect the ground wire from the FG terminal.

3.2.5 Precautions: Input/Output Signal Lines

• Input and output signal lines <u>must</u> be separated from operating circuit power cables. If this is not possible, use a shielded cable and connect the shield to the FP chassis. **Chapter 4**

2. Screen Display Adjustment

Setting up and Adjusting the FP unit

4.1 Operation Mode Setup

4.1.1 Dip Switch Preset Settings and Adjustments

The FP unit's dip switches are located behind the Dip Switch Cover.



SW No.	Function	Description	Factory Settings
1-1	Switch between USB and RS- 232C for touch panel data transmission.	Used to set the touch panel data input (command control) method to either USB or RS-232C. ON : USB OFF : RS-232C (Default setting)	
1-2	Display/hide the OSD.	Used to display or hide the OSD. ON :Hide OFF:Display (Default setting)	
1-3	Reserved	Set this switch to OFF	All OFF
1-4			741011
1-5	Switch between analog RGB and DVI-D input.		
1-6			
1-7	Reserved	Be sure these switches are always set to OFF	
1-8			



Dip switch settings are effective only when starting up the FP unit. After changing any dip switch settings, be sure to restart your FP unit.

LED	OFF (Not Lit)	Green	Orange	Green/ Red Flash	Orange Flash
Panel	Power OFF	Power ON	Power ON	Power ON	Power ON
Backlight	-	Normal	Normal	Burned-out	Burned-out
Image Input	-	Yes	No	Yes	No

4.1.2 Status of Front LED in Operation Modes

4.2 Screen Display Adjustment

4.2.1 Calibration of OSD Display Position

Simply touch the touch panel to call up the OSD (On Screen Display) screen. This screen allows you to perform detailed display adjustment.

■ Starting the OSD

To start the OSD and enter OSD mode, press the three corners of the touch panel in the following order ((1)upper left, (2)upper right and (3)lower right) within 5 seconds. In OSD mode, the setting screen is displayed in the center of the screen and the touch panel cannot be used to communicate with external devices until the OSD setup is completed.





OSD is not displayed when DIP SW 1-2 is ON.

■ Using the OSD

The setting screen uses icons to (select and) enter settings. When you start up the OSD, the main menu appears. Touching an icon displays its submenu or setting change screen. In the setting screen, \blacksquare and \blacktriangleright icons are used to change the setting. To apply the setting, press the **SET** button. Press the **SAVE** button to save the defined settings.



4.2 Screen Display Adjustment

Quitting the OSD

To quit the OSD, press the **ESC** button in the main menu or leave the OSD as it is for at least 30 seconds. If the OSD is automatically closed after 30 seconds of inactivity, the values set before the OSD was closed will be applied.

Item		Function		
	CONTRAST	Adjusts the contrast.	(Analog RGB only) ^{*1}	
Ŏ.	BLACK LEVEL	Adjusts the color brightness.	(Analog RGB only) ^{*1}	
œ	H-POS	Adjusts the horizontal position of the sci	reen.	
⊕	V-POS	Adjusts the vertical position of the screen.		
	H-SIZE	Adjusts the screen size in the horizontal	direction. (Analog RGB only) ^{*1}	
\sum	PHASE	Adjusts the input signal and the dot cloo	ck position. (32 levels) (Analog RGB only) ^{*1}	
DIM	BACKLIGHT	Adjusts the backlight brightness. (9 leve	els)	
AGC	AUTO GAIN CONTROL	Automatically adjusts the contrast and t	he brightness. (Analog RGB only) ^{*1}	
DSP	DISPLAY MODE	Displays the resolution of the input imag	ge data.	
RST	OSD CLEAR (RESET)	Resets the current OSD value to the de	fault value.	
SAVE	OSD SAVE	Save the current value and quit the OSI	Э.	
I	SYSTEM	Changes settings such as activating the	e click sound.	
ESC	ESCAPE	Cancels the setting and returns to the u menu, this command closes the OSD.	pper level. In the main	

*1 When using DVI-D, the message "DO NOT NEED SETUP FOR DVI-D" is displayed and no settings are required.



4.2 Screen Display Adjustment





In this screen, touching the value displayed on the panel changes the value of the time period.

SAVE SAVE

Saves all the adjusted settings in the EEPROM.



In the OSD, pressing the SET button applies the set value and enables the setting. The set value won't be canceled unless the power is turned OFF or the value is reset.

If the power is turned OFF without saving the set value, that data will disappear. The last saved data will be read into the system when the FP starts. To enable the changed value, be sure to press the SAVE button.

• When the OSD automatically closes after 30 seconds of inactivity, the set value that you were modifying at the time will be retained. If you quit the OSD using the ESC button, the value you were modifying will be ignored and the previously set value will remain in effect.

Memo

5.1 Touch Interface Data

1. Touch Interface Data

Chapter 5

Touch Panel Data

5.1 Touch Interface Data

The FP-2650-T41 unit use an analog type touch panel. This touch panel needs a calibration program to adjust the actual touch position.

Touch Panel Coordinate Data

The screen display origin point, with 1024 x 768 for FP-2650-T41 unit, is normally at the upper left corner of the screen. Therefore, a software to convert the touch coordinates to display coordinates is needed.

(1) Resolution

Both the X and Y coordinates have a resolution of 1024. The origin point (0,0) is located in the upper left corner of the screen.



5.1 Touch Interface Data

(2) Data Format

Touch Panel coordinate data is sent to the host using the following format.

All data is in binary format.



Added when touch is released.

<Example> If the coordinate (X=23(11h), Y=500(1F4h)) is touched and moved to the coordinate (X=63(3Fh), Y=250(FAh)).

11h 0h 17h 1h F4h	touched
11h 0h 17h 1h F4h	continuous output with the same location
11h 0h 18h 1h F3h	moving without releasing touch
•	:
:	•
11h 0h 3Fh 1h FAh	continuous data output unless finger is released
11h 0h 3Fh 1h FAh 10h	when released, only 1 unit of data is sent

OS	Touch Panel Handler	Calibration
Windows [®] 95,		
Windows [®] 98,		
WindowsNT [®] 4.0,	Mouse Emulator V2 (PL-TD000) ^{*1}	
Windows [®] 2000,		
Windows [®] XP		

Coordinate Data Conversion Software

Windows[®]95 needs OSR2 or more. Windows[®]98 needs 2nd Edition or more. WindowsNT[®]4.0 needs SP6a or more.

*1 Mouse Emulator V2 (PL-TD000) is optional software. This program is used for both English and Japanese.



Mouse Emulator V2 cannot automatically detect your PC COM Port used to connect the FP unit.

As a result, select your PC COM Port via the Mouse Emulator V2 Installer window and enter the settings given in this manual for the Allocated I/O address and Interrupt.

When changing the COM Port on your PC used to connect the FP unit, change the setting using Window's [Start]-[Program]-[Updd]-[Operation Setup]-[Hardware].

Memo

Chapter 6

Troubleshooting
Error Message

Troubleshooting

6.1 Troubleshooting

6.1.1 Possible Device Problems

This section assumes that the FP is the cause of a problem, not the host.

Note: • When the host is the problem, please refer to its corresponding manual.

Possible types of trouble while using this unit are as follows.

Screen does not display normally

- No display appears after the unit is switched on.
- The screen disappears during standard operation.
- The screen does not display normally.

Touch panel does not respond

- The touch panel does not respond when pressed.
- The touch panel reaction time is abnormally long.

6.1.2 No Display

When the screen does not display when powering up, or if the screen turns OFF by itself, use the flowchart below to find an appropriate solution.



6.1 Troubleshooting



6.1.3 Touch Panel Does Not Respond

When the touch panel does not react, or its reaction is very slow after it is pressed, follow the flowchart below to find the origin of the problem and the appropriate solution.



6.2 Error Message

This section explains the messages that appear when an error has occurred in the

FP unit during RUN mode. The problem causing the error message and its

related countermeasure are explained in the table below.

(Only the latest error message will appear on the FP screen)

Error Message	Problem	Countermeeasure
Out of Range 1 to 3	Signal timing has been input that is not	Set the FP output settings so that they match the
	compatible with the FP unit.	PC's frequency and resolution.
	The dot clock has greatly exceeded of the FP	Reference 2.3 Interface Specifications
	unit's usable timing range.	
	Resolution has been set that is not compatible	
	with the FP unit.	
No Signal	The PS-2000B unit or a Windows-compatible	Turn on the PS-2000B unit or a Windows-
	PC's power has not been turned ON.	compatible PC's power.
	The PS-2000B unit or a Windows-compatible	Connect the RGB cable/DVI-D cable correctly.
	PC has not been correctly connected to the FP	
	unit	
	The input I/F and the image input signal type	Set the Dip Switch correctly.
	are not the same.	Reference 4.1.1 Dip Switch Preset
		Settings and Adjustments

6.2.1 Error Message List

Memo

Chapter 7

Maintenance

- 1. Regular Cleaning
- 2. Periodic Check Points
- 3. Backlight Replacement

7.1 Regular Cleaning

7.1.1 Cleaning the Display





When the display surface or frame become dirty, use a soft cloth moistened with neutral detergent to wipe away any dust or stains.



Thinner Organic solvent Strong acid



Δ

Do <u>not</u> clean the unit with thinner, organic solvents, or strong acids.





Attach the screen protection sheet when using the FP in extremely dirty or dusty areas.

7.1.2 Installation Gasket Replacement

The installation gasket protects the FP and improves its water resistance. For instructions on installing the FP unit's gasket, refer to **Reference** Chapter 3 Installation and Wiring



A gasket which has been used for a long period of time may have scratches or dirt on it, and could have lost much of its water resistance. Be sure to change the gasket at least once a year, or when scratches or dirt become visible.

Installation Gasket Replacement Procedure

- Place the FP on a flat, level surface with the display facing downwards.
- 2) Remove the old gasket from the FP.
- 3) Attach the new gasket to the FP. Be sure to insert the gasket into the FP unit's groove so that the gasket's groove sides are vertical.
- Check if the gasket is attached to the FP correctly. The upper surface of the gasket should protrude approximately 2mm out from the groove.





- The gasket must be inserted correctly into the groove for the FP unit's moisture resistance to be equivalent to IP65f.
- Be sure the gasket's seam is not inserted into any of the unit's corners, only in the straight sections of the groove. Inserting it into a corner may lead to its eventually tearing.
- The upper surface of the gasket should protrude approximately 2mm out from the groove. Be sure to check that the gasket is correctly inserted before installing the FP into a panel.



7.2 Periodic Check Points

To keep your FP unit in its best condition, please inspect the following points periodically.

FP Operation Environment

- Is the ambient temperature within the allowable range $(0^{\circ}C \text{ to } 50^{\circ}C)$?
- Is the ambient humidity within the specified range (10% RH to 90% RH, dry bulb temperature of 39°C or less)?
- Is the operating atmosphere free of corrosive gasses?

Electrical Specifications

• Is the Rated Voltage Range appropriate ?

FP Model Number	Rated Voltage Range
FP2650-T41	AC85 to 264V

Related Items

- Are all power cords and cables connected properly? Have any become loose?
- Are all installation fasteners holding the unit securely?
- Are there any scratches or traces of dirt on the installation gasket?

7.3 Backlight Replacement

The backlight is a cold-cathode tube. Although the FP uses a long-life backlight, replacement may be required earlier than expected depending on the environment where the FP is used.

The life span of the backlight is as follows:

(Time period until the backlight becomes half as bright as a new one)

50,000 hours (approx. 5.7 years)

When a burned-out backlight is detected, the status LED flashes alternately green and red, or a steady orange.

- To prevent an electric shock, be sure to turn the FP unit's power OFF before replacing the backlight.
- The backlight and the FP itself will be very hot just after turning off the power. To avoid burning your skin, be sure to wear gloves when replacing the backlight.
- The backlight is very fragile. To avoid possible injury, do not directly touch the glass or pull the cable.



• Normally, the FP unit detects a backlight burnout by monitoring the backlight's current flow. However, the FP may fail to detect backlight burnout, or may only detect it before the backlight burns out completely, depending on the type of backlight problem.



Please check that the replacement backlight is compatible with the FP.

FP	Backlight Model Number
FP2650-T41	CA5-BLU12XGA-01

Backlight Replacement

Follow the procedures given below to replace the FP unit's backlights. Be sure to wear gloves during replacement.



Be sure to protect the FP front panel's surface to prevent damage. The FP-2650-T41 unit has only one backlight.

7.3 Backlight Replacement

FP2650-T41



Rear Attachment Screws

Turn the FP unit's power OFF (i.e. disconnect the FP unit's power cord). Remove the three (3) I/F covers, and use a Phillips screwdriver to remove the case's seven (7) rear attachment screws and USB holder. Pivot the rear cover open, starting from the top of the unit.



Since the attachment screws are small, be sure not to lose them or allow them to fall inside the FP unit's case.

2) The cover is fastened at the bottom, and hinges open.



- Be sure not to break the rear cover's four (4) alignment tabs when you open it.
- To prevent FP unit damage, be sure the FP unit's rear cover open/close direction is correct.



3) Loosen the three (3) circuit board attachment screws.



7.3 Backlight Replacement



4) The circuit board is connected on one side, and hinges open.



When the FP unit's power has just been turned OFF, the circuit board chassis is still very hot! Be sure to wear gloves to prevent being burned.

5) Disconnect the backlight's one (1) power connector.





6) Loose the backlight unit attachment screw. Next, slide the backlight in the direction shown and lift it forward and remove it from the FP.



- 7) Insert the new backlight in the FP. Insert the unit by sliding it in the direction shown in step 6).
- 8) Connect the backlight's one (1) power connector. Next, close the circuit board and secure the rear case in place using the attachement screws removed in steps 1), 2) and 3).



- Be sure not to pinch or cut any of the FP unit's internal wiring when closing the case.
- If any of the attachment screws becomes misplaced, check to be sure that they have not fallen inside the FP. If a screw has fallen inside the FP, do not connect the unit's power cord until it has been removed.

Memo